



Manuals.plus /

› Panasonic /

› Panasonic Lamdash Men's Shaver ES-ST2S-W Instruction Manual

Panasonic ES-ST2S-W

Panasonic Lamdash Men's Shaver ES-ST2S-W Instruction Manual

Model: ES-ST2S-W | Brand: Panasonic

INTRODUCTION

This manual provides essential instructions for the safe and effective use, maintenance, and troubleshooting of your Panasonic Lamdash Men's Shaver, model ES-ST2S-W. Please read this manual thoroughly before using the product and retain it for future reference.

IMPORTANT SAFETY INFORMATION

- Do not disassemble, repair, or modify the shaver. This may cause injury or malfunction.
- Keep the shaver away from children.
- Do not use if the outer foil or inner blades are damaged, as this may cause skin injury.
- Ensure the charging adapter is kept dry. Do not handle with wet hands.
- Only use the specified charging adapter.
- Avoid using shaving creams (excluding foam), facial cleansers with scrubs, or bar soap, as these may clog the blades or prevent foam generation.

PARTS IDENTIFICATION

Familiarize yourself with the components of your shaver:

- **Outer Foil:** Covers the inner blades and contacts the skin.
- **Inner Blades:** Cut the beard.
- **Power Button:** Turns the shaver on/off.
- **Wet/Dry Indicator:** Indicates suitability for wet or dry use.
- **Travel Lock Indicator:** Shows if the travel lock is engaged.
- **Charging Indicator:** Displays charging status.
- **Trimmer:** For pre-shaving longer hairs or shaping sideburns.
- **Shaver Holder:** For convenient storage.
- **Charging Port:** For connecting the charging adapter.





Figure 1: Front view of the Panasonic Lamdash ES-ST2S-W shaver, showing the outer foil, power button, and indicators.

SETUP AND INITIAL CHARGE

1. **Unpacking:** Carefully remove all components from the packaging. Ensure the shaver, shaver holder, dedicated oil, and cleaning brush are present.
2. **Initial Charge:**
 - Connect the charging adapter to the shaver's charging port.
 - Plug the adapter into a power outlet.
 - The charging indicator will illuminate. Allow the shaver to charge fully before first use. A full charge typically takes approximately 1 hour.
 - Once fully charged, disconnect the adapter.
3. **Travel Lock:** The shaver features a travel lock to prevent accidental activation. To engage, press and hold the power button for approximately 2 seconds until the travel lock indicator illuminates. To disengage, repeat the process.

OPERATING INSTRUCTIONS

Dry Shaving

1. Ensure your face is clean and dry.
2. Press the power button to turn on the shaver.
3. Hold the shaver at a right angle to your skin and shave against the direction of beard growth.
4. Stretch your skin with your free hand to ensure a close shave.
5. After shaving, press the power button to turn off the shaver.

Wet Shaving (Foam Making Mode)

The shaver is designed for wet shaving with foam, providing a gentle experience.



洗顔剤※やボディソープが使える 肌にやさしくシェービング



※シェービング剤(フォーム除く)、スクラブ入りの洗顔剤、せっけんは、刃の詰まりの原因になったり、泡が立たないので、使用しないでください。

©画像はイメージです。

Figure 2: Illustrates the use of the shaver with foam for a gentle wet shave.

1. Wet your face and apply a small amount of facial cleanser (non-scrub, non-bar soap) or body soap directly to the shaver head.
2. Press the power button to activate the shaver. The foam-making mode will automatically generate rich foam.
3. Gently move the shaver across your face, allowing the foam to spread and the blades to cut the beard.
4. Rinse your face and the shaver thoroughly after use.

Note: The high-speed linear motor maintains power even during wet shaving, ensuring efficient performance.



お風呂剃りでも パワーが落ちない! ※1



日本製

(本体のみ)

お風呂
剃り



※2

防水
設計
IPX7基準

※3



※4

- ※1: ストローク値において、当社2014年発売ES-RL13との比較。当社調べ。
- ※2: ACアダプターは除く。
- ※3: IPX7基準(水深1メートルに30分間水に浸けても有害な影響を生じる量の水の浸入がない)検査をクリアしています。
- ※4: 海外でご使用の場合には、国や地域に合わせて別途プラグアダプターをお買い求めください。

©画像はイメージです。

Figure 3: The shaver is designed for use in wet conditions, maintaining full power.

Using the Sharp Trimmer

30° 鋭角
ナノエッジ内刃

硬いヒゲも
スパッとカット

エッジR0.3 μm
30°

マルチ
フィットアーク刃

肌にムリなく
密着

ES-ST8S-A(青)

刃先角
45°

トリマー刃

シャープトリマー

モミアゲそろえや長く伸びたヒゲの
プレシェービングに便利。

©画像・イラストはイメージです。

Figure 4: The sharp trimmer, with a 45-degree blade tip, is useful for pre-shaving long beards and shaping sideburns.

The built-in sharp trimmer is ideal for:

- Pre-shaving longer beard hairs before using the main shaver head.
- Trimming and shaping sideburns or mustaches.

To use, slide the trimmer switch upwards. Hold the shaver with the trimmer facing your skin and carefully trim as desired.

[Lamdash AI \(Beard Sensor\)](#)

ラムダッシュAI[※]

(センシング約200回/秒)

ヒゲの濃さを検知し
自動でパワーをコントロール

※ヒゲの濃さや、シェーバーヘッド内部のヒゲクズによって、センサーが反応(駆動音の変化)しない場合がありますが、異常ではありません。

©画像はイメージです。

Figure 5: Lamdash AI detects beard density approximately 200 times per second and automatically adjusts shaving power for optimal performance.

The Lamdash AI feature automatically detects the density of your beard approximately 200 times per second and adjusts the motor power accordingly. This ensures consistent, powerful shaving even in areas with dense beard growth, and reduces unnecessary strain on the skin in areas with lighter growth.

Note: The sensor may not always react (change in drive sound) depending on beard density, but this is not a malfunction.

MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and hygiene.

1. **Daily Cleaning:**

- After each use, turn off the shaver.
- Rinse the shaver head thoroughly under running water. The outer blade does not need to be removed for cleaning.
- Shake off excess water and wipe the shaver dry with a soft cloth.
- Allow the shaver to air dry completely before storing.

2. **Deep Cleaning (Weekly/Bi-weekly):**

- Remove the outer foil frame.
- Use the provided cleaning brush to gently brush away any trapped beard clippings from the inner blades and the shaver body.
- Rinse all parts under running water.
- Apply a drop of the dedicated oil to each inner blade and the outer foil to maintain smooth operation.
- Reattach the outer foil frame securely.

3. **Blade Replacement:** For optimal shaving performance, it is recommended to replace the outer foil and inner blades periodically. Refer to the product packaging or Panasonic's official website for replacement part numbers and recommended replacement intervals.



外刃はずさず！そのまま洗淨！

©画像はイメージです。

Figure 6: The shaver can be easily cleaned by rinsing directly under running water without removing the outer blade.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Shaver does not turn on.	Battery is depleted. Travel lock is engaged.	Charge the shaver. Disengage the travel lock by pressing and holding the power button for 2 seconds.
Shaving performance is poor.	Blades are dull or clogged. Insufficient charge.	Clean the shaver thoroughly. Apply oil to blades. Consider replacing outer foil and inner blades. Ensure shaver is fully charged.
Shaver makes unusual noise or vibration.	Foreign object lodged in blades. Damaged blades.	Clean the shaver. If noise persists or blades are visibly damaged, discontinue use and contact customer support.
Foam is not generated in foam-making mode.	Incorrect type of facial cleanser/soap used. Insufficient amount of cleanser.	Ensure you are using a non-scrub, non-bar soap facial cleanser. Apply a sufficient amount.

SPECIFICATIONS

Feature	Detail
Model Number	ES-ST2S-W
Brand	Panasonic
Blade System	3-Blade Reciprocating
Motor Type	High-Speed Linear Motor (approx. 13,000 strokes/minute)
Beard Sensor	Lamdash AI (approx. 200 detections/second)
Shaving Type	Wet/Dry (Bath Shaving Compatible)
Power Source	Rechargeable Battery
Waterproofing	Yes (Dry & Wet Shaving)
Dimensions (approx.)	5 x 6.5 x 15.5 cm
Weight (approx.)	0.42 kg (420g)
Included Accessories	Shaver holder, dedicated oil, cleaning brush
Special Features	Travel Lock, Foam Making Mode, Sharp Trimmer

CUSTOMER SUPPORT AND WARRANTY

For product repairs, inquiries, or warranty information, please contact Panasonic Customer Support:

- **Panasonic Repair Consultation Desk:** TEL: 0120-878-554
- **Operating Hours:** 9:00 AM - 7:00 PM (Daily)
- **Holiday Hours:** 9:00 AM - 5:30 PM (Sundays, Public Holidays, Year-end/New Year)
- You can also search for "Panasonic Repair" online for more information.

Please retain your proof of purchase for warranty claims.

