

UpStart Components LM-691035-DL233

UpStart Components 691035 Fuel Filter User Manual

Model: LM-691035-DL233 | Brand: UpStart Components

1. INTRODUCTION

This manual provides essential information for the proper installation, maintenance, and troubleshooting of your UpStart Components 691035 Fuel Filter. This fuel filter is designed as a replacement part compatible with Briggs & Stratton 21B807-0140-H1 engines and 493629 Fuel Filter 40 Micron specifications. It is crucial to read and understand these instructions before attempting any installation or maintenance.

The fuel filter plays a vital role in protecting your engine by preventing contaminants from reaching the carburetor and engine components, ensuring optimal performance and longevity.

2. SAFETY INFORMATION

Always prioritize safety when working with fuel systems and engines. Failure to follow these safety guidelines may result in personal injury or damage to equipment.

- **Disconnect Power:** Before beginning any work, ensure the engine is turned off and cooled down. Disconnect the spark plug wire to prevent accidental starting.
- **Fuel Handling:** Fuel is highly flammable. Work in a well-ventilated area away from open flames, sparks, or other ignition sources. Have a fire extinguisher readily available.
- **Eye Protection:** Always wear safety glasses or goggles to protect your eyes from fuel splashes or debris.
- **Gloves:** Wear fuel-resistant gloves to protect your hands from fuel and other fluids.
- **Spill Containment:** Place a suitable container under the fuel lines to catch any spilled fuel during removal or installation. Dispose of fuel properly.
- **Professional Assistance:** If you are unsure about any step or uncomfortable performing the installation, consult a qualified service technician.

3. PRODUCT OVERVIEW

The UpStart Components 691035 Fuel Filter is a clear-bodied filter designed to trap impurities in the fuel before they reach the engine. It features a pleated filter element and inlet/outlet ports for connection to the fuel lines.



Figure 3.1: Front view of the UpStart Components 691035 Fuel Filter, showing the clear casing and internal filter element.



Figure 3.2: Side view of the fuel filter, highlighting the direction of fuel flow indicated by an arrow on the filter body. Ensure this arrow points towards the engine during installation.



Figure 3.3: Angled view of the fuel filter, showing both inlet and outlet ports and the transparent housing.

4. SETUP AND INSTALLATION

This section outlines the steps for replacing an existing fuel filter. Ensure you have the necessary tools and follow all safety precautions.

Tools Required:

- Pliers (for hose clamps)
- Fuel-resistant gloves
- Safety glasses
- Drain pan or suitable container for fuel
- Clean rags

Installation Steps:

1. **Prepare the Area:** Park the equipment on a level surface in a well-ventilated area. Ensure the engine is cool. Disconnect the spark plug wire.
2. **Locate the Fuel Filter:** Identify the existing fuel filter in the fuel line, typically between the fuel tank and the carburetor.
3. **Clamp Fuel Lines (Optional but Recommended):** If possible, use fuel line clamps on both sides of the filter to minimize fuel leakage.
4. **Remove Old Filter:** Place a drain pan underneath the filter. Use pliers to loosen and slide back the hose clamps on both ends of the old filter. Carefully pull the fuel lines off the filter ports. Expect some fuel to spill.
5. **Inspect Fuel Lines:** Check the fuel lines for any cracks, hardening, or damage. Replace them if necessary.

- 6. **Install New Filter:** Note the direction of the arrow on the new UpStart Components 691035 Fuel Filter. This arrow must point towards the engine (away from the fuel tank). Push the fuel lines onto the new filter's ports until they are fully seated.
- 7. **Secure Clamps:** Slide the hose clamps back over the connections to secure the fuel lines to the filter. Ensure a tight seal to prevent leaks.
- 8. **Check for Leaks:** Remove any fuel line clamps. Reconnect the spark plug wire. Start the engine and carefully check for any fuel leaks around the new filter connections. If leaks are present, turn off the engine immediately and re-tighten the clamps or re-seat the lines.
- 9. **Dispose of Old Filter:** Dispose of the old fuel filter and any spilled fuel according to local environmental regulations.

5. OPERATION

The UpStart Components 691035 Fuel Filter operates passively within your engine's fuel system. Its primary function is to filter out impurities such as dirt, rust, and debris from the fuel before it reaches sensitive engine components like the carburetor or fuel injectors. This ensures a clean fuel supply, which is critical for efficient combustion and preventing damage or clogging of fuel system parts. Once installed correctly, the filter continuously performs its function as fuel flows through it during engine operation.

6. MAINTENANCE

Regular inspection and timely replacement of the fuel filter are essential for maintaining engine health and performance.

Inspection:

Periodically inspect the clear body of the fuel filter. Look for:

- **Visible Debris:** Accumulation of dirt, rust, or other particles inside the filter element.
- **Discoloration:** The filter element may darken over time, indicating it is trapping contaminants.
- **Fuel Flow Restriction:** A heavily clogged filter may show reduced fuel flow or air bubbles if the filter is struggling to pass fuel.
- **Leaks:** Check for any signs of fuel leakage around the filter connections.

Replacement Schedule:

The frequency of fuel filter replacement depends on the equipment's usage, fuel quality, and operating environment. As a general guideline, it is recommended to replace the fuel filter:

- Annually, or at the beginning of each operating season.
- Every 50-100 hours of engine operation.
- Immediately if signs of clogging or damage are observed.

Refer to your engine's specific service manual for precise recommendations.

7. TROUBLESHOOTING

A clogged or faulty fuel filter can lead to various engine performance issues. Here are common symptoms and potential solutions:

Symptom	Possible Cause (Fuel Filter Related)	Solution
---------	--------------------------------------	----------

Symptom	Possible Cause (Fuel Filter Related)	Solution
Engine hard to start or won't start	Severely clogged fuel filter restricting fuel flow.	Inspect and replace the fuel filter.
Engine sputters, runs rough, or loses power under load	Partially clogged fuel filter causing inconsistent fuel delivery.	Inspect and replace the fuel filter.
Engine stalls after running for a short period	Fuel starvation due to a heavily restricted filter.	Inspect and replace the fuel filter.
Visible fuel leak around filter connections	Loose hose clamps or improperly seated fuel lines.	Tighten hose clamps or re-seat fuel lines. Ensure correct hose size.

If replacing the fuel filter does not resolve the issue, further diagnosis of the fuel system (fuel pump, carburetor, fuel lines) or other engine components may be required. Consult a qualified technician if problems persist.

8. SPECIFICATIONS

- **Product Type:** Replacement Fuel Filter
- **Brand:** UpStart Components
- **Model Number:** LM-691035-DL233
- **Compatible Part Numbers:** 4129, 492386, 492836, 493629, 691035
- **Micron Rating:** 40 Micron (for compatible 493629 Fuel Filter)
- **Engine Compatibility:** Designed for Briggs & Stratton 21B807-0140-H1 Engine (and similar models requiring specified filter types)
- **Material:** Premium quality material

9. WARRANTY AND SUPPORT

This product is an UpStart Components Brand replacement part. It is not an OEM (Original Equipment Manufacturer) product. All mentions of brand names or model descriptions are made strictly to illustrate compatibility. All brand names and logos are registered trademarks of their respective owners. This product is not affiliated with any brands and is not covered under any warranties offered by the original manufacturers.

Any warranties for this product are offered solely by UpStart Components. For specific warranty details or technical support regarding this fuel filter, please contact UpStart Components directly through their official channels or the retailer from whom the product was purchased. Ensure you have your purchase information and the product model number (LM-691035-DL233) available when contacting support.

© 2024 UpStart Components. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question