

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [VASAGLE](#) /

› [VASAGLE L-Shaped Computer Desk ULWD72MB User Manual](#)

VASAGLE ULWD72MB

VASAGLE L-Shaped Computer Desk ULWD72MB User Manual

Model: ULWD72MB

1. INTRODUCTION

Thank you for choosing the VASAGLE L-Shaped Computer Desk. This manual provides essential information for the safe assembly, proper use, and maintenance of your new desk. Please read these instructions carefully before beginning assembly and retain them for future reference.

2. SAFETY INFORMATION

- **Children must not climb on the product for safety reasons.**
- Ensure all parts are securely fastened before use.
- Do not exceed the maximum load capacities specified in the 'Specifications' section.
- Assemble the product on a soft, clean surface to prevent scratches.
- Keep small parts and packaging materials away from children.

3. PACKAGE CONTENTS

Before assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- 1 x L-Shaped Computer Desk (Greige + Black)
- 1 x Accessory Kit (includes all necessary screws and a screwdriver)
- 1 x User Manual

4. SETUP AND ASSEMBLY INSTRUCTIONS

Assembly is designed to be straightforward. We recommend two people for assembly to ensure stability and ease of handling. All parts are clearly labeled, and the accessory kit includes all necessary tools.

1. **Unpack and Identify Parts:** Lay out all components on a soft, clean surface. Each panel and beam is labeled with a

letter or number, and corresponding screws are individually packaged. Refer to the included diagram for identification.

2. **Initial Fastening:** Follow the step-by-step diagrams in the included manual. When attaching components, initially tighten screws only partially. This allows for minor adjustments during assembly.
3. **Final Tightening:** Once all components are in place and the desk is fully assembled, gradually tighten all screws firmly. Avoid overtightening to prevent damage to the materials.
4. **Placement:** Position the desk in its desired location. The adjustable feet can be used to level the desk on uneven floors.



Figure 4.1: Desk Dimensions and Load Capacities



Figure 4.2: Removable Middle Shelf for PC Tower or Storage



Figure 4.3: Steel Frame Reinforcement Bar



Figure 4.4: Adjustable Feet for Stability

5. OPERATING INSTRUCTIONS (USAGE)

The VASAGLE L-Shaped Computer Desk is designed for optimal workspace utilization and functionality.

- **L-Shaped Design:** The L-shape allows the desk to fit efficiently into corners, maximizing your available space. It can comfortably accommodate multiple monitors (up to 3-4).
- **Double Work Surface:** One side of the desk is suitable for laptops, monitors, and other devices, while the other side provides ample space for books, documents, or other office supplies, enhancing productivity.

- **Removable Shelf:** The central shelf is designed to be removable. You can use it for storing small items or remove it to create space for a computer tower.
- **Cable Management:** The angled rear edge of the desk facilitates easy routing of cables, helping to keep your workspace tidy and organized.
- **Stability:** The robust steel frame and reinforcement bars ensure a stable and durable work surface. Adjustable feet allow for minor height adjustments to compensate for uneven flooring.



Figure 5.1: Optimized Workspace with L-Shaped Desk




Figure 5.2: Cable Management Feature

6. MAINTENANCE

Proper care will extend the life and appearance of your desk.

- **Cleaning Particleboard Surfaces:** Wipe with a damp cloth. Avoid using abrasive cleaners, harsh chemicals, or excessive moisture, as these can damage the finish.
- **Cleaning Steel Frame:** Clean the steel components with a soft cloth and a mild detergent. Dry immediately to prevent water spots or rust.

- **Environmental Conditions:** Avoid placing the desk in direct sunlight or areas with extreme temperatures and humidity fluctuations.
- **Regular Checks:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary.

7. TROUBLESHOOTING

If you encounter any issues with your VASAGLE L-Shaped Computer Desk, refer to the following common solutions:

- **Desk Wobbles:** Ensure all screws are fully tightened. Use the adjustable feet on the bottom of the desk legs to level the desk on uneven floors.
- **Parts Don't Align During Assembly:** Loosen all screws slightly, adjust the parts into their correct positions, and then retighten. Ensure you are following the assembly diagrams precisely.
- **Missing Parts:** Double-check the packaging and all contents against the 'Package Contents' list. If parts are genuinely missing, contact customer support with your purchase details.
- **Scratches or Damage:** For minor scratches, furniture repair pens or markers matching the desk color may be used. For significant damage, contact customer support.

8. SPECIFICATIONS

Attribute	Detail
Brand	VASAGLE
Model	ULWD72MB
Dimensions (L x W x H)	138 x 138 x 76 cm (54.3 x 54.3 x 29.9 inches)
Color	Greige + Black
Material	Particleboard, Steel
Tabletop Thickness	18 mm
Max. Static Load Capacity (Tabletop)	50 kg (110 lbs)
Max. Static Load Capacity (Each Shelf)	10 kg (22 lbs)
Number of Shelves	2
Assembly Required	Yes
Recommended Persons for Assembly	2
Included Tools	Screwdriver
Special Features	L-shaped design, removable shelf, cable management edge, adjustable feet

9. WARRANTY AND SUPPORT

This product comes with a **Limited Warranty**. For specific warranty terms and conditions, please refer to the documentation provided at the time of purchase or contact your retailer.

For any questions, concerns, or assistance with your VASAGLE L-Shaped Computer Desk, please contact the retailer where you purchased the product or visit the official VASAGLE website for customer support information.

