

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Numatic](#) /
- › [Numatic Nupro ReFlo PRP180 Canister Vacuum Cleaner User Manual](#)

## Numatic 911899

# Numatic Nupro ReFlo PRP180 Canister Vacuum Cleaner User Manual

Model: PRP180 (911899)

## 1. PRODUCT OVERVIEW

---

The Numatic Nupro ReFlo PRP180 is a compact and high-performance canister vacuum cleaner designed for daily cleaning in various environments. It features exceptional stability and maneuverability. This model incorporates ReFlo technology, meaning it is constructed from up to 75% recycled plastic. It is equipped with a Tritex filter and Hepaflo bag for high-level filtration, and a NUPLUG socket for simplified maintenance.



**Figure 1:** Numatic Nupro ReFlo PRP180 Vacuum Cleaner. This image shows the Numatic Nupro ReFlo PRP180 vacuum cleaner. It features a black cylindrical body with the 'Nupro Re-Flo' logo. The flexible hose is attached to the front, and the metal wand with a floor tool is connected to the side. The yellow power cord is coiled and stored in the top compartment.

## 2. SAFETY INSTRUCTIONS

- Always disconnect the vacuum cleaner from the power supply before cleaning or performing maintenance.
- Do not use the appliance if the power cord or plug is damaged. Contact qualified service personnel for repair.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Do not vacuum liquids, hot ashes, sharp objects, or flammable/explosive materials.
- Ensure all filters and bags are correctly installed before operation.
- Keep hair, loose clothing, fingers, and all parts of the body away from openings and moving parts.
- Use only manufacturer-recommended attachments.

## 3. PACKAGE CONTENTS

Please check the box for the following items:

- Numatic Nupro ReFlo PRP180 Vacuum Cleaner Unit
- Flexible Hose
- Metal Wand
- Floor Tool
- Tritex Filter (pre-installed or separate)
- Hepaflo Dust Bag (one pre-installed or separate)
- User Manual (this document)

## 4. SETUP

---

1. **Unpacking:** Carefully remove all components from the packaging. Retain packaging for future storage or transport.
2. **Filter and Bag Installation:**
  - Open the vacuum cleaner head by releasing the clips.
  - Ensure the Tritex filter is securely in place over the motor housing.
  - Insert a new Hepaflo dust bag into the drum, ensuring the collar is correctly seated over the inlet.
  - Close the vacuum cleaner head, ensuring the clips are securely fastened.
3. **Attaching the Hose:** Insert the flexible hose cuff into the inlet port on the front of the vacuum cleaner until it clicks into place.
4. **Assembling the Wand and Floor Tool:** Connect the metal wand sections together, then attach the floor tool to the end of the wand. Connect the other end of the wand to the hose handle.
5. **Power Cord:** Uncoil the power cord from the head storage area. The head is designed to neatly store the power cord when not in use.

## 5. OPERATING INSTRUCTIONS

---

1. **Power Connection:** Plug the power cord into a suitable 220 Volt electrical outlet.
2. **Switching On/Off:** Locate the power switch on the vacuum cleaner unit. Press it to turn the appliance ON. Press it again to turn it OFF.
3. **Vacuumping:** Guide the floor tool over the surfaces to be cleaned. For different surfaces, adjust the floor tool settings if applicable (e.g., brush up for hard floors, brush down for carpets).
4. **Accessory Use:** Utilize various accessories (not explicitly listed but implied by "stocker les accessoires") for specific cleaning tasks, such as crevices, upholstery, or dusting.
5. **After Use:** Turn off the vacuum cleaner and unplug it from the power outlet. Coil the power cord and store it in the designated head storage area.

## 6. MAINTENANCE

---

Regular maintenance ensures optimal performance and extends the life of your vacuum cleaner.

- **Emptying/Replacing Dust Bag:**
  - When the suction power decreases significantly or the bag full indicator (if present) illuminates, the Hepaflo dust bag needs to be replaced.
  - Disconnect from power. Open the head, remove the full bag, and dispose of it responsibly.

- Install a new Hepaflo bag, ensuring it is correctly seated.
- **Cleaning the Tritex Filter:**
  - Periodically check the Tritex filter for dust buildup.
  - Remove the filter and gently tap it to dislodge dust. Do not wash the Tritex filter unless specified by the manufacturer.
  - Replace the filter if it is damaged or excessively dirty.
- **Cleaning the Exterior:** Wipe the exterior surfaces of the vacuum cleaner with a damp cloth. Do not use abrasive cleaners or solvents.
- **Checking for Blockages:** If suction power is low, check the hose, wand, and floor tool for any blockages. Carefully remove any obstructions.

## 7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Vacuum cleaner does not turn on.	No power supply; Power switch off; Damaged cord/plug.	Check power outlet; Ensure switch is ON; Inspect cord/plug for damage (contact service if damaged).
Low suction power.	Full dust bag; Clogged filter; Blockage in hose/wand/floor tool.	Replace dust bag; Clean/replace Tritex filter; Clear any blockages.
Unusual noise during operation.	Blockage in fan/motor area; Loose component.	Disconnect power and check for blockages; If noise persists, contact service.

If troubleshooting steps do not resolve the issue, please contact customer support.

## 8. SPECIFICATIONS

<b>Brand</b>	Numatic
<b>Model Number</b>	PRP180 (911899)
<b>Power</b>	151 Watts
<b>Voltage</b>	220 Volts
<b>Noise Level</b>	72 Decibels
<b>Weight</b>	7.68 Kilograms
<b>Filter Type</b>	Tritex and Hepaflo
<b>Power Source</b>	Electric Cable
<b>Cordless</b>	No
<b>Maximum Suction</b>	48 Centimeters

<b>Included Components</b>	Vacuum cleaner, Filter, User manual
----------------------------	-------------------------------------

## 9. WARRANTY AND SUPPORT

---

The Numatic Nupro ReFlo PRP180 vacuum cleaner comes with a **2-year warranty** from the date of purchase, covering manufacturing defects under normal use.

For technical assistance, spare parts, or warranty claims, please contact your local Numatic dealer or visit the official Numatic website for support information.

**Online Resources:** [www.numatic.com](http://www.numatic.com)