Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Plantronics 215496-01

Plantronics Calisto 5300 USB-A/BT600 Speakerphone User Manual

Model: CL5300 (215496-01) | Brand: Plantronics

Introduction

The Plantronics Calisto 5300 is a portable Bluetooth conference speakerphone designed for clear and reliable communication. It offers flexible connectivity options via USB-A and Bluetooth, making it suitable for various devices such as PCs, tablets, and mobile phones. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your Calisto 5300 speakerphone.



Image: The Plantronics Calisto 5300, highlighting its design as a personal portable Bluetooth speakerphone.

Package Contents

- Plantronics Calisto 5300 Speakerphone
- USB-A Cable (integrated or separate, depending on model variant)
- BT600 USB Bluetooth Adapter (for BT600 variant)
- Carrying Case (for select models)
- Quick Start Guide (not included in this manual)



Image: The Plantronics Calisto 5300 speakerphone shown with its accompanying BT600 USB Bluetooth adapter.

Setup

1. Charging the Speakerphone

Before first use, fully charge your Calisto 5300. Connect the integrated USB-A cable from the speakerphone to a USB port on your computer or a USB wall charger. The LED indicator will show charging status.

2. Connecting to a Computer (USB)

Plug the USB-A cable from the Calisto 5300 directly into an available USB-A port on your computer. The device will be recognized automatically, and it will be ready for use as an audio device.

3. Connecting to a Computer (Bluetooth via BT600 Adapter)

1. Insert the BT600 USB Bluetooth adapter into a USB-A port on your computer.
2. The adapter's LED will flash blue, indicating it is searching for the speakerphone.

3. Power on your Calisto 5300. It will automatically attempt to connect to the BT600 adapter.
4. Once connected, the BT600 adapter's LED will turn solid blue, and the speakerphone's LED will indicate a successful connection.

4. Connecting to a Mobile Device (Bluetooth)

1. Power on your Calisto 5300.
2. Press and hold the Bluetooth pairing button on the speakerphone until the LED flashes red and blue, indicating pairing mode.
3. On your mobile device, go to Bluetooth settings and select "Poly Calisto 5300" from the list of available devices.
4. Once paired, the speakerphone's LED will turn solid blue.



Image: The Calisto 5300 speakerphone positioned between a laptop with the BT600 adapter and a smartphone, illustrating wireless connectivity to multiple devices.

Operating Instructions

Speakerphone Controls

- **Volume Up/Down:** Use the **+** and **-** buttons to adjust the listening volume.
- **Mute/Unmute:** Press the (microphone with slash) button to mute or unmute the microphone.
- **Call Answer/End:** Press the ☎ (phone receiver) button to answer or end a call.
- **Bluetooth Pairing:** Press and hold the Bluetooth icon button to enter pairing mode.

Audio Quality and Microphone

The Calisto 5300 features a 360-degree microphone, ensuring clear audio pickup from all directions during conference calls. Position the speakerphone centrally in your meeting space for optimal performance.



Image: A close-up view of the Calisto 5300 speakerphone, emphasizing its 360-degree microphone capability for clear conference call audio.

Battery Life

The speakerphone provides up to 16 hours of talk time on a full charge, allowing for extended use without needing to recharge frequently.



Image: A woman seated in a living room setting, using the Calisto 5300 speakerphone placed on a coffee table, illustrating its use for extended talk time.

Plantronics Hub App

For advanced settings, firmware updates, and device management, download and install the Plantronics Hub application on your computer or mobile device. This app provides additional customization and diagnostic tools.



Image: The Calisto 5300 speakerphone connected via USB to a laptop, demonstrating the use of the Plantronics Hub app for device settings and updates.

Maintenance

- **Cleaning:** Use a soft, dry, lint-free cloth to clean the speakerphone. Do not use abrasive cleaners, solvents, or spray directly onto the device.
- **Storage:** When not in use, store the speakerphone in its carrying case (if included) to protect it from dust and damage. Store in a cool, dry place.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the device regularly, even if not in constant use.



Image: The Calisto 5300 speakerphone neatly stored inside its compact, zippered carrying case, emphasizing its portability and protection.

Troubleshooting

Problem	Possible Solution
No audio from speakerphone	• Ensure the speakerphone is powered on and charged. • Check USB connection or Bluetooth pairing. • Verify the Calisto 5300 is selected as the default audio device in your computer's sound settings or mobile device's Bluetooth settings. • Increase the volume on both the speakerphone and your connected device.

Problem	Possible Solution
Microphone not picking up sound	• Ensure the microphone is not muted (check the mute button LED). • Verify the Calisto 5300 is selected as the default microphone in your communication application settings. • Adjust microphone input levels in your device's sound settings.
Bluetooth connection issues	• Ensure the speakerphone is in pairing mode if connecting for the first time. • Delete "Poly Calisto 5300" from your device's Bluetooth list and re-pair. • Move the speakerphone closer to your device. • Restart both the speakerphone and your connected device.
Speakerphone not charging	• Try a different USB port or wall charger. • Ensure the USB cable is securely connected.

Specifications

Brand	Plantronics (Poly)
Model Name	Calisto 5300 (CL5300)
Item Model Number	215496-01
Connectivity Technology	USB-A (Wired), Bluetooth
Special Features	USB Port, 360-degree microphone, Portable
Battery Type	1 Lithium-polymer (included)
Rechargeable Battery	Yes
Talk Time	Up to 16 hours
Item Weight	12 Ounces (approx. 0.34 kg)
Included Components	Speakerphone, BT600 USB Adapter (for BT600 variant)

Warranty and Support

For warranty information, technical support, or further assistance with your Plantronics Calisto 5300 speakerphone, please visit the official Poly (formerly Plantronics) support website or contact their customer service. Keep your proof of purchase for warranty claims.
Note: Specific warranty terms and conditions may vary by region.
Official Poly Support: www.poly.com/us/en/support

© 2023 Plantronics. All rights reserved. Plantronics and Poly are trademarks of Plantronics, Inc.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B086WNDB4Z

More documents and user manuals: **https://manuals.plus/**