

ROTTOGOON floorlamp0122

ROTTOGOON Floor Lamp Instruction Manual

Model: floorlamp0122

1. SAFETY INFORMATION

Please read all instructions carefully before assembly and use. Retain this manual for future reference.

- **Electrical Safety:** Ensure the lamp is unplugged before assembly, cleaning, or bulb replacement. Do not operate with a damaged cord or plug.
- **Indoor Use Only:** This lamp is designed for indoor use. Do not expose to water or high humidity. The product is not waterproof.
- **Bulb Compatibility:** Use only E26 base bulbs. Do not exceed a maximum wattage of 60 Watts. The included LED bulb is 9 Watts.
- **Stable Placement:** Place the lamp on a flat, stable surface to prevent tipping.
- **Ventilation:** Ensure adequate ventilation around the lampshade to prevent overheating.

2. PACKAGE CONTENTS

Verify that all components are present before beginning assembly.

- Floor Lamp Base and Pole Sections
- Beige Fabric Lampshade
- 9W E26 LED Bulb (3 Color Temperatures)
- User Manual (this document)



Image: Components included in the ROTTOGOON Floor Lamp package.

3. ASSEMBLY INSTRUCTIONS

Assembly is straightforward and typically takes less than 10 minutes.

1. **Unpack Components:** Carefully remove all parts from the packaging.
2. **Assemble Lamp Pole:** Screw the pole sections together clockwise until secure. Ensure the power cord runs freely through the pole.
3. **Attach Pole to Base:** Screw the assembled pole into the lamp base clockwise until firmly tightened.
4. **Assemble Lampshade:** The fabric lampshade may require minor assembly. Follow the specific instructions provided with the lampshade to attach the fabric to the metal rings.
5. **Install Lampshade:** Place the assembled lampshade onto the lamp harp and secure it with the provided finial or ring.
6. **Insert Bulb:** Screw the included E26 LED bulb into the lamp socket clockwise until snug. Do not overtighten.




Image: Visual guide for lamp assembly, showing key features like the sturdy base and adjustable shade.

4. OPERATING INSTRUCTIONS

The ROTTOGOON Floor Lamp features a convenient foot switch and a 3-color temperature LED bulb.

- **Power On/Off:** Plug the lamp into a standard 120V AC outlet. Press the foot switch located on the power cord to turn the lamp on or off.
- **Changing Color Temperature:** The included LED bulb supports three color temperatures: 3000K (Warm White), 4000K (Natural White), and 5000K (Daylight White). To cycle through these settings, quickly press the foot switch repeatedly. Each press will switch to the next color temperature.

3 color temperatures Bulb Included



Image: The lamp displaying its three distinct color temperature options.

5. MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your lamp.

- **Cleaning:** Disconnect the power before cleaning. Wipe the lamp pole and base with a soft, dry cloth. For the fabric lampshade, use a lint roller or a soft brush to remove dust. Do not use liquid cleaners or abrasive materials.
- **Bulb Replacement:** Ensure the lamp is unplugged and the bulb has cooled down completely. Unscrew the old E26 bulb counter-clockwise and replace it with a new E26 base LED bulb, not exceeding 60 Watts.

6. TROUBLESHOOTING

If you encounter issues with your ROTTOGOON Floor Lamp, refer to the following common solutions:

- **Lamp Does Not Turn On:**
 - Check if the power cord is securely plugged into the wall outlet.
 - Ensure the wall outlet is functional by testing it with another device.

- Verify that the bulb is screwed in tightly and is not burnt out. Replace the bulb if necessary.
- Inspect the power cord for any visible damage. If damaged, discontinue use and contact support.

- **Light Flickers:**

- Ensure the bulb is screwed in securely.
- Try a different E26 bulb to rule out a faulty bulb.

If these steps do not resolve the issue, please contact ROTTOGOON customer support.

7. SPECIFICATIONS

Detailed technical specifications for the ROTTOGOON Floor Lamp.




Image: Dimensional overview of the ROTTOGOON Floor Lamp and its components.

Feature	Detail
Model Number	floorlamp0122

Product Dimensions	11.02"D x 11.02"W x 61.22"H (28cm D x 28cm W x 155.5cm H)
Item Weight	9.75 pounds (4.42 kg)
Material	Metal (Base), Linen (Shade)
Finish Type	Painted
Shade Color	Beige
Bulb Base	E26
Included Bulb Wattage	9 Watts LED
Maximum Compatible Wattage	60 Watts
Color Temperature	3000K, 4000K, 5000K (selectable via included bulb)
Power Source	Corded Electric
Voltage	120 Volts
Switch Type	Foot Switch
Cable Length	1.8 Meters (70.87 inches)
Indoor/Outdoor Usage	Indoor
Assembly Required	Yes

8. WARRANTY AND SUPPORT

For warranty information or technical support, please visit the official ROTTOGOON store or contact their customer service.

ROTTOGOON Store: [Visit ROTTOGOON on Amazon](#)

Extended protection plans may be available for purchase separately.