

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [OTO](#) /

› [OTO Q Seat QS-88 Foot Massager Spa Comfy Seat User Manual](#)

## OTO QS-88

# OTO Q Seat QS-88 Foot Massager Spa Comfy Seat User Manual

Model: QS-88

[Introduction](#)   [Safety Information](#)   [Product Overview](#)   [Setup](#)   [Operating](#)  
[Instructions](#)   [Maintenance](#)   [Troubleshooting](#)   [Specifications](#)   [Warranty & Support](#)

## 1. INTRODUCTION

---

Thank you for choosing the OTO Q Seat QS-88 Foot Massager Spa Comfy Seat. This device is designed to provide a relaxing foot massage experience with multiple functions, including kneading, scraping, air-pressing, tapping, and heat. It also functions as a comfortable seat or ottoman. Please read this manual thoroughly before use to ensure proper operation and maintenance.

## 2. IMPORTANT SAFETY INFORMATION

---

To reduce the risk of electric shock, burns, fire, or injury, always follow these basic safety precautions:

- Read all instructions before using this appliance.
- Do not use while sleeping or drowsy.
- Unplug from outlet when not in use and before putting on or taking off parts.
- Do not operate under a blanket or pillow. Excessive heating can occur and cause fire, electric shock, or injury to persons.
- Close supervision is necessary when this appliance is used by, on, or near children, invalids, or disabled persons.
- Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended by the manufacturer.
- Never operate this appliance if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or dropped into water. Return the appliance to a service center for examination and repair.
- Do not carry this appliance by supply cord or use cord as a handle.
- Keep the cord away from heated surfaces.

- Never drop or insert any object into any opening.
- Do not use outdoors.
- Do not operate where aerosol (spray) products are being used or where oxygen is being administered.
- To disconnect, turn all controls to the OFF position, then remove plug from outlet.
- This appliance is intended for household use only.

### 3. PRODUCT OVERVIEW

---

The OTO Q Seat QS-88 combines a foot massager with a comfortable seating option. Familiarize yourself with its main components.



**Figure 3.1:** OTO Q Seat QS-88 with the top cover open, revealing the foot massage compartments and the control panel. The device features a grey fabric exterior and wooden legs.

#### Key Components:

- **Massage Compartments:** Two foot compartments with internal rollers and airbags.
- **Control Panel:** Buttons for power, program selection, strength adjustment, and heat function.
- **Top Cover:** Functions as a comfortable seat or ottoman, with a separate heat function.
- **Power Cord Inlet:** Located at the rear of the unit.

### 4. SETUP

---

1. **Unpacking:** Carefully remove the OTO Q Seat QS-88 from its packaging. Retain packaging for future storage or transport.
2. **Placement:** Place the unit on a flat, stable surface. Ensure there is adequate space around the unit for ventilation and comfortable use.
3. **Power Connection:** Insert the power cord into the power inlet at the back of the unit, then plug the

other end into a suitable AC 100-240V / 50-60Hz electrical outlet.

4. **Initial Inspection:** Before first use, inspect the unit for any visible damage. Do not use if damaged.



**Figure 4.1:** The OTO Q Seat QS-88 positioned as an ottoman in a living room, demonstrating its dual function as a foot massager and a piece of furniture.

## 5. OPERATING INSTRUCTIONS

---

The OTO Q Seat QS-88 offers various massage programs and settings for a personalized experience.

### 5.1 Powering On/Off

- To turn on the massager, press the **Power button** on the control panel. The unit will start in a default program.
- To turn off the massager, press the **Power button** again.

### 5.2 Selecting Massage Programs

The unit features 4 auto massage programs. Press the **Program button** to cycle through the available programs:

- **Program 1:** Focuses on Kneading and Scraping.
- **Program 2:** Focuses on Air-Pressing and Tapping.
- **Program 3:** Combines Kneading, Scraping, and Air-Pressing.
- **Program 4:** Combines all functions: Kneading, Scraping, Air-Pressing, and Tapping.

### 5.3 Adjusting Strength Levels

There are 3 strength levels for the massage. Press the **Strength button** to adjust the intensity:

- **Level 1:** Gentle massage.
- **Level 2:** Medium intensity massage.

- **Level 3:** Strong massage.

## 5.4 Heat Function

The unit includes a heat function for added comfort. Press the **Heat button** to activate or deactivate the heat. The heat function can be used concurrently with any massage program.

The top cover also has a separate heat function. To activate, ensure the unit is powered on and press the dedicated **Top Cover Heat button** (if available, refer to control panel markings).

## 5.5 Using as a Comfy Seat/Ottoman

When not in use as a foot massager, close the top cover to utilize the unit as a comfortable seat or ottoman. Ensure the cover is securely closed before sitting on it.

## 6. MAINTENANCE

---

Proper care and maintenance will ensure the longevity of your OTO Q Seat QS-88.

- **Cleaning:** Always unplug the unit before cleaning. Wipe the exterior with a soft, damp cloth. Do not use abrasive cleaners, solvents, or harsh chemicals.
- **Storage:** When not in use, store the massager in a cool, dry place. Avoid direct sunlight and extreme temperatures.
- **Cord Care:** Do not wrap the power cord around the appliance. Avoid sharp bends or kinks in the cord.
- **Internal Components:** The internal massage mechanisms do not require user maintenance. Do not attempt to open the unit.

## 7. TROUBLESHOOTING

---

If you encounter any issues with your OTO Q Seat QS-88, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Unit does not power on.	Power cord not properly connected. No power from outlet.	Ensure power cord is securely plugged into both the unit and the wall outlet. Test the outlet with another appliance.
Massage function is weak or inconsistent.	Incorrect strength level selected. Obstruction in foot compartments.	Increase the strength level using the Strength button. Ensure feet are properly placed and there are no obstructions.
Heat function is not working.	Heat function not activated.	Press the Heat button to activate. Allow a few minutes for the heat to become noticeable.
Unusual noise during operation.	Normal operating sound. Internal malfunction.	Some operational noise is normal. If the noise is excessive or unusual, discontinue use and contact customer support.

If the problem persists after attempting these solutions, please contact OTO customer support.

## 8. SPECIFICATIONS

---

<b>Product Name</b>	OTO Q Seat
<b>Model Number</b>	QS-88
<b>Input</b>	AC 100-240V / 50-60Hz
<b>Output</b>	DC 24V~2.0A
<b>Power Consumption</b>	50W
<b>Net/Gross Weight</b>	7.7 kg / 9 kg
<b>Product Dimensions (L x W x H)</b>	41 x 36 x 29 cm
<b>Material</b>	Plastic, Rubber
<b>Special Features</b>	4 Auto Massage Programs, 3 Strength Levels, Kneading, Scraping, Air-Pressing, Tapping, Heat (foot spa & top cover)

## 9. WARRANTY AND SUPPORT

---

OTO products are manufactured to high-quality standards. For information regarding warranty coverage, terms, and conditions, please refer to the warranty card included with your purchase or visit the official OTO website.

For technical support, service inquiries, or to purchase replacement parts, please contact OTO customer service through their official channels. Contact information can typically be found on the product packaging or the OTO official website.

**Online Support:** [Visit the OTO Store on Amazon](#)