

Deerma DX700s

Deerma DX700s Corded Bagless Vacuum Cleaner User Manual

Model: DX700s | Brand: Deerma

1. IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before using the Deerma DX700s vacuum cleaner. Retain this manual for future reference.

- Always ensure the power supply voltage matches the rating label on the appliance.
- Do not use the vacuum cleaner on wet surfaces or to pick up liquids.
- Do not pick up burning or smoking materials, such as cigarettes, matches, or hot ashes.
- Keep hair, loose clothing, fingers, and all parts of the body away from openings and moving parts.
- Unplug from the electrical outlet when not in use and before cleaning or servicing.
- Do not operate the vacuum cleaner with a damaged cord or plug.
- This appliance is for household use only.

2. PRODUCT OVERVIEW

The Deerma DX700s is a versatile corded bagless vacuum cleaner designed for efficient cleaning of various surfaces. It can be used as a stick vacuum for floors or easily converted into a handheld unit for upholstery and hard-to-reach areas.



Image 2.1: The Deerma DX700s vacuum cleaner showcasing its dual functionality as a stick vacuum and a handheld unit.



Image 2.2: The Deerma DX700s vacuum cleaner demonstrating its three main configurations: full stick, handheld with crevice tool, and handheld with brush tool for versatile cleaning.

3. SETUP AND ASSEMBLY

The Deerma DX700s is designed for easy assembly and conversion between stick and handheld modes.

3.1 Assembling the Stick Vacuum

1. Insert the extension tube into the main motor unit until it clicks into place.
2. Attach the floor brush to the other end of the extension tube, ensuring it is securely fastened.
3. Ensure the dust cup is correctly installed on the main motor unit.



Image 3.1: A person using the Deerma DX700s in its stick vacuum configuration for floor cleaning.

3.2 Converting to Handheld Mode

1. Press the release button on the extension tube to detach it from the main motor unit.
2. Attach the desired accessory (e.g., crevice tool, brush tool) directly to the main motor unit.



Image 3.2: A person using the Deerma DX700s in handheld mode to clean a sofa, demonstrating its versatility for furniture and upholstery.

4. OPERATING INSTRUCTIONS

4.1 Powering On/Off

Plug the power cord into a suitable electrical outlet. Locate the power switch on the main motor unit and slide it to the 'ON' position to start the vacuum. Slide it to 'OFF' to stop the vacuum.

4.2 Using Attachments

The Deerma DX700s comes with three standard functional brush heads for various cleaning needs:

- **Ground Brush:** Ideal for cleaning hard floors and carpets in stick vacuum mode.
- **Flat Nozzle Suction:** Suitable for narrow gaps, corners, and edges.
- **Round Nozzle Brush:** Effective for cleaning upholstery, curtains, and delicate surfaces.




Image 4.1: Close-up view of the three standard functional brush heads included with the Deerma DX700s: flat nozzle suction, ground brush, and round nozzle brush, designed for multi-purpose and deep cleaning.

4.3 Storage

The vacuum cleaner can be stored upright when not in use, saving space.




Image 4.2: The Deerma DX700s vacuum cleaner standing upright against a wall, illustrating its compact and convenient storage capability.

5. MAINTENANCE AND CLEANING

Regular maintenance ensures optimal performance and extends the lifespan of your Deerma DX700s vacuum cleaner.

5.1 Emptying the Dust Cup

The dust cup should be emptied regularly, especially when the debris reaches the 'MAX' fill line. The separable dust box design makes this process convenient.

1. Ensure the vacuum cleaner is unplugged.
2. Press the dust cup release button to detach it from the main motor unit.
3. Hold the dust cup over a trash bin and open the bottom lid to empty the contents.

5.2 Cleaning the Filters

The filters (Cyclone and HEPA) are washable and reusable. Clean them regularly to maintain suction power.

1. Remove the filters from the dust cup.
2. Rinse the filters under running water until the water runs clear.
3. Allow the filters to air dry completely for at least 24 hours before reassembling. Do not use a dryer or direct heat.
4. Reassemble the dry filters and dust cup into the main motor unit.




Image 5.1: Illustration of the separable dust box and the process of emptying dust and washing the reusable filter, highlighting the ease of maintenance.

6. TROUBLESHOOTING

If you encounter issues with your Deerma DX700s, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Vacuum does not turn on	No power supply; Power cord damaged; Power switch faulty	Check if plugged in correctly; Inspect power cord for damage; Contact customer support if switch is faulty.
Loss of suction power	Dust cup full; Filters clogged; Nozzle/hose blocked	Empty dust cup; Clean or replace filters; Remove any blockages from nozzle or hose.
Unusual noise during operation	Blockage in brush head or hose; Motor issue	Check for and remove blockages; If noise persists, contact customer support.
Dust escaping from vacuum	Dust cup not properly installed; Filters missing or damaged	Ensure dust cup is securely attached; Check and properly install or replace filters.

7. SPECIFICATIONS

Key technical specifications for the Deerma DX700s vacuum cleaner:

Feature	Specification
Brand	Deerma
Model Number	DX700S-BLACK (6955578034992)
Power	600 Watts
Voltage	240 Volts
Dust Cup Capacity	0.8 Liters (implied from product title, though specifications list 2.2 Kilograms for capacity which is likely weight)
Product Dimensions (L x W x H)	16 x 22 x 66 cm
Item Weight	1.9 Kilograms
Noise Level	80 dB
Filter Type	Cyclone, HEPA filter
Special Features	Lightweight construction
Power Source	Corded Electric
Included Components	3 brush heads (flat nozzle, ground brush, round nozzle)

8. WARRANTY AND SUPPORT

8.1 Warranty Information

Specific warranty details for the Deerma DX700s vacuum cleaner are typically provided with the product packaging or on

the manufacturer's official website. Please refer to these sources for information regarding warranty duration, coverage, and terms.


8.2 Customer Support

For technical assistance, spare parts, or any other inquiries not covered in this manual, please contact Deerma customer support. Contact information can usually be found on the product packaging, the official Deerma website, or through your retailer.

Related Documents - DX700s


	Deerma Vacuum Cleaner DX700/DX700S User Manual and Safety Guide Comprehensive user manual and safety guide for the Deerma DX700/DX700S vacuum cleaner, covering assembly, operation, maintenance, troubleshooting, and technical specifications.
	Deerma DX700/DX700S Vertical Vacuum Cleaner User Manual and Guide Comprehensive user manual for the Deerma DX700 and DX700S vertical vacuum cleaner, covering setup, operation, maintenance, troubleshooting, and safety guidelines.

Documents - Deerma – DX700s




[\[pdf\]](#) User Manual Instructions

Инструкция для вертикального пылесоса Deerma Vacuum Cleaner DX700 S user manual deerma vacuu cleaner румиком Егорова Любовь 89432 cdn tpanback ru instructions 2 |||
Deerma Vacuum Cleaner - Deerma Vacuum Cleaner , , . 1. 2. 3. 4 ... , , . : Deerma Vacuum Cleaner : DX700 / **DX700S** : 260 288 1123 : 2.2 : 600 : 0.8 : 15 : 75 : 220V - 50 Hz ...
lang:i-klnglon **score:53** filesize: 484 K page_count: 6 document date: 2020-11-04



[\[pdf\]](#) User Manual Instructions


Инструкция для вертикального пылесоса Deerma Vacuum Cleaner DX700 S user manual deerma vacuu cleaner румиком Егорова Любовь output 6 mi house ru asserts instructions 2389 1 |||
Deerma Vacuum Cleaner Deerma Vacuum Cleaner , , . 1. 2. 3. 4. HEP ... , , . : Deerma Vacuum Cleaner : DX700 / **DX700S** : 260 288 1123 : 2.2 : 600 : 0.8 : 15 : 75 : 220V -50 Hz ...
lang:i-klnglon **score:52** filesize: 184.36 K page_count: 6 document date: 2021-01-07



[\[pdf\]](#) User Manual Instructions

DX700 DX700S EN RU PL PT 20220601 cdr Administrator 25 mai 2024 — PLEASE READ AND SAVE ALL INSTRUCTIONS BEFORE USING THE STICK The warnings cautions and instructions discussed in this instruction manual cannot cover all pylesos deerma dx700 pro instrukcia 144814 25052024 drv dns shop ru drivers oth P |||

EN Guangdong Deerma Technology Co., Ltd. No.4-1 Longhui Road, Malong Village Committee, Beijiao Town, Shunde District, Foshan City, Guangdong Province, China. Made in China MODEL NO.: DX700/**DX700S** Thank you for purchasing this product.Please read the instruction carefully before using, to ensure s...
lang:en score:51 filesize: 4.09 M page_count: 17 document date: 2022-06-06




[\[pdf\]](#) User Manual Instructions

deerma Vacuum Cleaner Instruction Manual Manuals User manual Official Store Deerma DX700 2 In 1 Handheld With Large Capacity Dust Box Low Noise Triple Filter Vertical Collector Grey Buy Online at Best Price in UAE Amazon ae 81iuj30u5VL m media amazon images I |||
Skip to content Manuals User Manuals Simplified. deerma Vacuum Cleaner Instruction Manual Home deerma deerma Vacuum Cleaner Instruction Manual INSTRUCTION MANUAL Vacuum Cleaner MODEL NO.: DX700 READ AND SAVE THESE INSTRUCTIONS THANK YOU FOR PURCHASING THE PRODUCT. PLEASE CAREFULLY READ THE INST...
lang:en score:50 filesize: 370.81 K page_count: 10 document date: 2021-08-19




[\[pdf\]](#) User Manual

manual cz 266 1 kB Deerma DX700s tyčový vysavač SmartPanda deerma dx700 smartpanda user related files |||
Deerma Vacuum Cleaner DX700/**DX700S** Uživatelsk prucka 2020 PRG Trading Group s.r.o. Podkovn Dkujeme Vm za nкуп vysavace znacky Deerma DX700/**DX700S**. Vme, ze Vm bude vrobek dlouho a poctiv sloužit a pinese Vm spoustu zbavy. Proto prosme vnujte chvilku casu k pecten tto prucky, aby Vm televize spolehl...
lang:hr score:47 filesize: 266.08 K page_count: 8 document date: 2022-08-12



[\[pdf\]](#) User Manual Instructions


Инструкция для вертикального пылесоса Deerma Vacuum Cleaner DX700 S user manual deerma vacuui cleaner румиком Егорова Любовь Пылесос Stick Cord Gray DX700SИнструкции к пылесосам руководства пользователей на русском языке в MOYO29769 1751277097moyo ua pub files instructions 29769 1751277097 White DX700Инструкция MOYOИнструкции MOYO29767 1751273929moyo 29767 ||| ||| Deerma Vacuum Cleaner Deerma Vacuum Cleaner , , . 1. 2. 3. 4. HEPA- 5. 6. 7. 8. 9. 10. 11. 12. * : 1 , . 2 , . 1 , . 3 , . 2 . 4 . . 1 , HEPA , , . HEPA . 2. * , . 3 , . 1 , . ; 2 , . , . ; 3 ; 4 . , , . ; 5 , . ; 6 , . , . ; 7.
Deerma Vacuum Cleaner Deerma Vacuum Cleaner , , . 1. 2. 3. 4. HEPA ... , , - . : Deerma Vacuum Cleaner : DX700/**DX700S** : 260 288 1123 : 2.2 : 600 : 0.8 : 15 : 75 : 220V -50 Hz Deerma Vacuum ...
lang:i-klngon score:40 filesize: 1.56 M page_count: 16 document date: 2023-08-08



[pdf]


Filtr do odkurzacza Deerma DX700 DX700s Sklep internetowy stylem pl filtr deerma dx700 dx700s 287606 upload files product |||

Filtr do odkurzacza Deerma DX700 / DX700s Indeks: 287606 Producent: Deerma
Kod producenta: DX700 Cena: 26.78 zł Opis Filtr do odkurzacza Deerma DX700 / DX700s Producent: deerma Szczegółowe Techniczne Kompatybilno z mark: Deerma Typ produktu: Filtr Kompatybilny z: DX700 / **DX700S** Materiały: Tworzywo szt...
lang:i-klngon score:40 filesize: 102.22 K page_count: 2 document date: 2023-09-07




[pdf] User Manual Instructions

Инструкция для вертикального пылесоса Deerma Vacuum Cleaner DX700 S user manual deerma vacuui cleaner румиком Егорова Любовь Xiaomi DX700Инструкция DX700Пылесос EU — купить в интернет магазине mi house ru с доставкой по Москве и всей РоссииПылесос Россииoutput boutput 6mi asserts instructions 1967 1 output 6 ручного DX700S GrayИнструкция DX700Ручной пылесос РоссииРучной Россиими 4584 ||| ||| Deerma Vacuum Cleaner Deerma Vacuum Cleaner , , . 1. 2. 3. 4. HEPA- 5. 6. 7. 8. 9. 10. 11. 12. * : 1 , . 2 , . 1. , . 3. , . 2. . 4. . : , . 1. , HEPA- , . HEPA 1- . 2. * , . 3. , . 1. , ; 2. , . ; 3. ; 4. , . , ; 5. . ; 6. , . , ; 7.
Deerma Vacuum Cleaner Deerma Vacuum Cleaner , , . 1. 2. 3. 4. HEP ... , . . :
Deerma Vacuum Cleaner : DX700 / **DX700S** : 260 288 1123 : 2.2 : 600 : 0.8 : 15 : 75 : 220V -50 Hz ...
lang:i-klngon score:40 filesize: 184.36 K page_count: 6 document date: 2021-01-07



[pdf] User Manual

Инструкция для вертикального пылесоса Deerma Vacuum Cleaner DX700 S user manual deerma vacuui cleaner румиком Егорова Любовь 2021 01 07 — ruchnoj pylesos xiaomi handheld vacuum dx700s700 mi92 ru
Deerma Vacuum Cleaner Deerma Vacuum Cleaner , , . 1. 2. 3. 4. HEP ... , . . :
Deerma Vacuum Cleaner : DX700 / **DX700S** : 260 288 1123 : 2.2 : 600 : 0.8 : 15 : 75 : 220V -50 Hz ...
lang:i-klngon score:40 filesize: 563.26 K page_count: 6 document date: 2021-01-07



[pdf]

Aspiradora Deerma DX700 plata Sklep internetowy stylem pl aspiradora deerma dx700 70484 upload files product |||


Aspiradora Deerma DX700 plata Indeks: 70484 Producent: Deerma Kod producenta: 6955578033858 Cena: ... e Deerma DX 700 doskonale sprawdzi si rwnie w Twoim domu. Specyfikacja Producent Deerma Model DX700/**DX700S** Moc ssania 15 kPa Napiecie znamionowe 220-240V-50-60Hz Zasilanie Sieciowe Poziom halasu 75 dB ... lang:pl **score:39** filesize: 300.56 K page_count: 5 document date: 2022-08-04



[pdf] User Manual Instructions

Deerma DX700 2 In1 Corded Stick Vacuum User Manual Administrator hand held vacuum cleaner bacf7494e7df6e443f4d71f858123ddfd0b gzhlis at blob ldb 9 b 0 3 |||


EN Guangdong Deerma Technology Co., Ltd. No.4-1 Longhui Road, Malong Village Committee, Beijiao Town, Shunde District, Foshan City, Guangdong Province, China. MODEL NO.: DX700/**DX700S** IMPOR TANT SAFETY INSTRUCTIONS The appliance is not to be used by persons including children with reduced physi... lang:en **score:38** filesize: 3.64 M page_count: 12 document date: 2023-05-15



[pdf]

Wielofunkcyjny odkurzacz pionowy z kablem 4 5m Deerma DX700s Szary Sklep internetowy stylem pl wielofunkcyjny deerma dx700s szary 53163 upload files product |||

Wielofunkcyjny odkurzacz pionowy z kablem 4,5m Deerma DX700s Szary Indeks: 53163 Producent: Deerma Kod producenta: DX700s Cena: 198.52 zł Opis Wielofunkcyjny odkurzacz pionowy z kablem 4,5m Deerma DX700s Szary Producent: Deerma Deerma DX700 - Jeden odkurzacz, wiele moliwoci Jeli szukasz wielofun... lang:pl **score:38** filesize: 141.76 K page_count: 4 document date: 2022-08-03




[pdf]

az docId 151FDB67CF5924DD5CC46B6CF3B0B543 DEERMA DX700 GR files innpro pl s3 amazonaws

Deerma DX700S |||

deerma t . DX700/**DX700S** 1 . . 2 . . 3 . .

lang:i-klngon **score:37** filesize: 1011.55 K page_count: 10 document date: 2023-09-22



[pdf]


Пылесос вертикальный Deerma DX700S VC20 plus VC25 VC40 Назначение устройства Данное устройство предназначено для уборки пыли и загрязнений с различных пылесосов deerma vc25 belyj

instrukcia drv dns shop ru Manuals P |||

Deerma **DX700S**, VC20 plus, VC25, VC40 , , , . . . , , - - 5 40 80 . , , . . . , ,

...

lang:i-klngon **score:37** filesize: 88.67 K page_count: 2 document date: 2021-02-10



[pdf] User Manual


Инструкция для вертикального пылесоса Deerma Vacuum Cleaner DX700 S user manual deerma vacuu cleaner румиком Егорова Любовь ДД½ÑÑÑÑÑÑÑÑÑÑ ДД,Д»Д¼ÑД¼Ñ DX700ДД,Д²Д,ÑД,ÑÑ â¢ WO UA 2porx6w8c9vc910qvhbzlqfo8su4r807 wo ua upload iblock c39 |||

Deerma Vacuum Cleaner Deerma Vacuum Cleaner , , . 1. 2. 3. 4. HEPA , - . . :

Deerma Vacuum Cleaner : DX700/**DX700S** : 260 288 1123 : 2.2 : 600 : 0.8 : 15 : 75 :

220V -50 Hz Deerma Vacuum ...

lang:i-klngon **score:36** filesize: 1.38 M page_count: 16 document date: 2023-08-08



[Deerma DX700/DX700S Vertical Vacuum Cleaner User Manual and Guide](#)

Comprehensive user manual for the Deerma DX700 and DX700S vertical vacuum cleaner, covering setup, operation, maintenance, troubleshooting, and safety guidelines.

lang:i-klngon **score:36** filesize: 1.56 M page_count: 16 document date: 2023-08-08




[pdf]

az docId 1B697D6F44C71AD32FD8E15B95163D99 DEERMA DX700 SK files innpro pl s3 amazonaws
Deerma DX700S |||

deerma t . Vysvac DX700/**DX700S** Nvod na obsluhu Pozorne si prectajte pokyny.
akujeme vm za nkup. Pred pouzitim vrobku si prectajte tento nvod a uschovajte si ho
pre budce pouzitie. Ilustrcie a informcie obsiahnut v tejto prrucke slzia len na ilustracn
cely a nemusia plne odrza skutocn vrobok. Nase...


lang:sk score:34 filesize: 932.96 K page_count: 8 document date: 2023-09-22



[pdf]

Oficina Santo Toribio Términos y condiciones de Garantía Manuales usuario Deerma Perú TERMINOS Y
CONDICIONES DE LA GARANTIA DEERMA 1 v 1720113905 cdn shopify s files 0679 9766 3456 |||
TRMINOS DE LA GARANTA DEERMA PER Los productos comercializados por
Deerma Per estn garantizados cont ... M-FD10W DEM-FD15W CM1300 CM1900
CM800 DX1000 TJ200 BY200 DX1000 DX115C DX118C DX118C_GR DX600
DX700 **DX700S** DX888 DX900_NG TJ200 VC01 VC01MAX VC03S VC20PLUS
VC20PRO VC20S VC25 VC25PLUS DEM-ZQ600 DEM-ZQ...

lang:es score:34 filesize: 435.05 K page_count: 4 document date: 2024-06-17




[\[pdf\]](#) User Manual Diagram

DX700 MANUAL DE USO digital Administrator Ver manualOferta Especial |Tiempo Limitado!cdn shopify s files 1 0679 9766 3456 v 1716584529 |||

Aspiradora Deerma Con una fuerte succin continua, puede eliminar el polvo. Es excelente para recoger el polvo fino de forma rpida y flexible de cada rincn. Es eficaz para almacenar el polvo sin reflujos para brindarle un entorno limpio. Manual de usuario DX700/**DX700S** Gracias por la compra de nuestro ...

lang:es **score:34** filesize: 829.74 K page_count: 8 document date: 2024-05-24



[\[pdf\]](#)

Deerma DX700 DX700s Filter PL Instrukcja obsługi pol porszřívó szűrő 44780 20085

5fcb7387746c4af8ec784fc686698a0d puputeve hu media wysiwyg attachments |||

Filtr do odkurzacza Deerma DX700 / DX700s Instrukcja obsługi Opis Ze wzgldw bezpieczeŝstwa oraz certyfikacji nie mona w aden sposb przebudowywa lub zmienia urzdzienia. W przypadku korzystania z produktu w celach innych ni opisane, produkt moe zosta uszkodzony. Ponadto uytkowanie niezgodne z przeznac...

lang:pl **score:33** filesize: 395.99 K page_count: 2 document date: 2024-02-19

VACUUM CLEANER/DX700 DEERMA	
RU:ELKO: 1420423	
Name: VACUUM CLEANER/DX700 DEERMA	
Značka/model: VACUUM CLEANER/DX700	
Kód produktu: 1420423	
Kód produktu: 1420423	
Page: 1/26	
Deerma Stick Vacuum Cleaner Cord White	
Deerma Stick Vacuum Cleaner Cord White	
Name	VACUUM CLEANER/DX700 DEERMA
Model name	DX700
Vacuum cleaner type	Upright
Vacuum cleaner features	Big bag containerEasy maintenanceFull dustbin indicator
Rated power	600 W (max)
Cord length	4.50 m
Working range	4.50 m
Dust bin capacity	0.80 l
Noise level, max	71.00 dB
Colour	White
Included Accessories	Vacuum cleaner, Extension handle, extension cable, furniture brush, motor brush, instructions
Dimensions	260 x 238 x 1223 mm
Shipping box quantity	1/26
Unit Weight Volume	0.60 cubic
Unit Net Weight	2.20 kg
Unit Gross Weight	2.75 kg

[pdf] Instructions Dimension Guide Accessories

Product1420423 Ручний пилосос Deerma Stick Vacuum Cleaner Cord 600 Вт білий DX700 купити в Україні Харкові Києві за доступною ціною 7fe060ceb3fbc02f5b41654effead297 svetum ua upload iblock 7fe |||

VACUUM CLEANER/DX700 DEERMA ELKO: 1420423 : VACUUM CLEANER/DX700 DEERMA : DX700 -: 6955578033858 : 8508110000 : 1 Deerma Stick Vacuum Cleaner Cord White. deerma.com.ua/ruchnoy-pylesos-deerma-stick-vacuum-cleaner-cord-white-mezhdunarodnaya-versiya-dx700.html Name VACUUM CLEANER/DX700 DEE...

lang:fr score:33 filesize: 40.1 K page_count: 2 document date: 2024-07-29

VACUUM CLEANER/DX700S DEERMA	
RU:ELKO: 1420422	
Name: VACUUM CLEANER/DX700S DEERMA	
Značka/model: VACUUM CLEANER/DX700S	
Kód produktu: 1420422	
Kód produktu: 1420422	
Page: 1/26	
Deerma Stick Vacuum Cleaner Cord Gray	
Deerma Stick Vacuum Cleaner Cord Gray	
Name	VACUUM CLEANER/DX700S DEERMA
Model name	DX700S
Vacuum cleaner type	Upright
Vacuum cleaner features	Easy maintenanceFull dustbin indicator
Rated power	600 W (max)
Cord length	4.50 m
Working range	4.50 m
Dust bin capacity	0.80 l
Noise level, max	71.00 dB
Colour	Gray
Included Accessories	Vacuum cleaner, Extension handle, extension cable, furniture brush, motor brush, instructions
Dimensions	260 x 238 x 1223 mm
Shipping box quantity	1/26
Unit Weight Volume	0.60 cubic
Unit Net Weight	2.20 kg
Unit Gross Weight	2.75 kg

[pdf] Instructions Dimension Guide Accessories

Product1420422 Ручний пилосос Deerma Stick Vacuum Cleaner Cord 600 Вт сірий DX700S купити в Україні Харкові Києві за доступною ціною a3890d5d65e0cb8e7d6827659e79de1a svetum ua upload iblock a38 |||

VACUUM CLEANER/DX700S DEERMA ELKO: 1420422 : VACUUM CLEANER/DX700S DEERMA : DX700S -: 6955578034992 : 8508110000 : 1 Deerma Stick Vacuum Cleaner Cord Gray. deerma.com.ua/ruchnoy-pylesos-deerma-stick-vacuum-cleaner-cord-gray-mezhdunarodnaya-versiya-dx700s.html Name VACUUM CLEANER/DX700S ...

lang:fr score:32 filesize: 49.28 K page_count: 2 document date: 2024-07-29




[pdf]

Deerma Porszívó b9b1b0256a3ceaa8625bec2a275fff1d DX700S MAGYAR bestpiac hu custom image data srattached |||

_J Megjegyzs: A jelen kziknyv gondosan ellenrzt, amennyiben nyomdai hiba vagy flirerts merl fel a ta ... z. Hatkonyan trolja a port visszaramls nlkl, hogy tiszta letteret biztostson nnek. MODEL NO.: DX700/DX700S _J FONTOS BIZTONSGI UTASTSOK A kszlket nem hasznlhatjk cskkent fizikai, rzkszervi vagy sze...

lang:no score:32 filesize: 734.06 K page_count: 5 document date: 2022-01-18



[pdf] User Manual

az docId F9D104848E0F23286C635FEED7ACEAED DEERMA DX700 RO files innpro pl s3 amazonaws Deerma |||

deerma t . Aspirator DX700/DX700S Instruciuni de utilizare Citii cu atenie instruciunile. V mulumim pentru achiziia dumneavoastr. V rugm s citii acest manual nainte de a utiliza produsul i s l pstrai pentru referine viitoare. Ilustraiile i informaiile coninute n acest manual au doar scop ilustra...

lang:it score:32 filesize: 1011.55 K page_count: 10 document date: 2023-09-22



[\[pdf\] User Manual](#)

Administrator Deerma Инструкция по вакуумному пылесосу DX700 pro При наличии каких либо
 Модель продукции Номинальное напряжение частота 220В 50Гц file 0 4128 360 tqbH1g object
 psccloud io cms Uploads |||

Deerma DX700 pro - , , , Reed instruction manual carefully before use : : DX700 pro / :
 220-50 : 600 : 0,8 : 15 : 75 : GB4706.1-2005, GB4706.7-2014 GB4343.1-2009,
 GB17625.1-2012 1 1 1 1 1 1 1 1. , ...

lang:i-klnglon **score:29** filesize: 375.62 K page_count: 11 document date: 2023-02-22



[Deerma Vacuum Cleaner DX700/DX700S User Manual and Safety Guide](#)

Comprehensive user manual and safety guide for the Deerma DX700/DX700S vacuum cleaner, covering assembly, operation, maintenance, troubleshooting, and technical specifications.

lang:en **score:29** filesize: 3.98 M page_count: 12 document date: 2022-10-29




[\[pdf\]](#)

Deerma Vysávač Spotřebič nesmú používať osoby vrátane detí so zníženými fyzickými zmyslovými alebo
 duševnými schopnosťami s nedostatkom skúseností a znalostí deerma DX700 SK bendr sk data
 documents |||

_J L Poznмка: Tto prrucka je starostlivo prepracovan, v prpade akchkovek tlacovch
 chb alebo nedoro ... o rohu. Je efektvne uklada prach, nie bamflow, aby ste zskali
 dekansk obytn plochu MODEL NO.: DX700/**DX700S** akujeme, ze ste si zakpili tento
 produkt. Pozorne si prectajte tento nvod 7 _J DLEZIT BEZP...


lang:sk **score:29** filesize: 1.49 M page_count: 5 document date: 2022-08-12



[Deerma DX700 Vacuum Cleaner Instruction Manual](#)

Comprehensive instruction manual for the Deerma DX700 vacuum cleaner, covering safety precautions, assembly, usage, cleaning, maintenance, and storage.

lang:en **score:28** filesize: 335.88 K page_count: 8 document date: 2021-05-17



[\[pdf\]](#)


Czeski dodatek A5 ai Návod k obsluze cze Deerma DX700s álló porszívó szűrke 41911 18849

b92db26c6babb204417312c80d6e490d puputeve hu media wysiwyg attachments |||

Deerma Vysavac MODEL NO.: DX700/**DX700S** DLEZIT BEZPECNOSTN POKYNY

Spotebic nesm pouzvat osoby vcetn dt se snzenmi fyzickmi, smyslovmi nebo dusevnmi schopnostmi nebo s nedostatkem zkusenost a znalost, pokud jim osoba odpovdn za jejich bezpecnost neposkytla dohled nebo je nepoucila o pouzvn spotebi...

lang:hr **score:27** filesize: 1.41 M page_count: 10 document date: 2023-04-07



[\[pdf\]](#) User Manual


Administrator Deerma 400154578 teamplush by 2024 06 |||

Deerma DX700/**DX700S** - , , , Reed instruction manual carefully before use : :

DX700/**DX700S** / : 220-50 : 600 : 0,8 : 15 : 75 : GB4706.1-2005, GB4706.7-2014

GB4343.1-2009, GB17625.1-2012 1 1 1 1 1 1 1 1. ...

lang:i-klngon **score:27** filesize: 257.19 K page_count: 11 document date: 2024-06-29



[\[pdf\]](#)

docId A2F2FABCA20F89BEF236BC8899104231 DEERMA DX700 CZ files innpro pl s3 amazonaws

Deerma DX700W |||

_J Vysavac DX700/**DX700S** Nvod k pouzit L 3. Nepouzvejte vysavac s poskozenm Pecliv si pectte pokyny Dkujeme vm za vs nkup. Ped pouzitm vrobku si prosim pectte tento nvod a uschovejte jej pro budouc pouzit. Obrzky a informace obsazen v tto prucce jsou pouze ilustrativn a nemus pln odpovdat skutecnmu...

lang:es **score:26** filesize: 646.66 K page_count: 4 document date: 2023-04-07



[pdf]

DX700Pro EN RU PL 20240328 QU Administrator Instrukcja obsługi pol Deerma DX700 PRO álló porszívó 57451 43663 4074982252c3b1f28792e1b517412f0f puputeve hu media wysiwyg attachments ||| Odkurzacz pionowy Deerma DX700 PRO Przed uyciem naley uwanie przeczyta instrukcj obsługi. Ponadto instrukcja ta jest dostpna na nastpujcej stronie internetowej: <http://www.deerma.com> Ostrzeen e 1. Odkurzacz jest urzdzieniem elektrycznym. Naley go uywa zgodnie z warunkami eksploatacji okrelonymi w i...
lang:pl score:25 filesize: 13.26 M page_count: 5 document date: 2024-07-18




[pdf] User Manual

Administrator Deerma 3 juil 2023 — Пылесос представляет собой электрическое устройство и необходимо использовать его в соответствии с условиями использования указанными инструкции по 84547915 ins cdn leroymerlin ru lmr image upload v1654774317 lrcode ET6MQxlrUiHYPOkruT Ww ||| Deerma DX700/DX700S - , , , Reed instruction manual carefully before use : : DX700/DX700S / : 220-50 : 600 : 0,8 : 15 : 75 : GB4706.1-2005, GB4706.7-2014 GB4343.1-2009, GB17625.1-2012 1 1 1 1 1 1 1 1 1. ...
lang:i-klngon score:24 filesize: 370.1 K page_count: 11 document date: 2020-10-15



[pdf]

DX700Pro EN RU PL 20240328 QU Administrator odkurzacz pionowy deerma dx700 pro instrukcja Max ElektroOdkurzacz jest urzdzieniem elektrycznym Naley go uywa zgodnie z warunkami eksploatacji okrelonymi w instrukcji obslugiproxymaxelektro pl storage file pimcore import 2025 2 7 cf2759d3ccd497aba3a4b48532864c10 ||| Odkurzacz pionowy Deerma DX700 PRO Przed uyciem naley uwanie przeczyta instrukcj obsługi. Ponadto instrukcja ta jest dostpna na nastpujcej stronie internetowej: <http://www.deerma.com> Ostrzeen e 1. Odkurzacz jest urzdzieniem elektrycznym. Naley go uywa zgodnie z warunkami eksploatacji okrelonymi w i...
lang:pl score:24 filesize: 12.61 M page_count: 5 document date: 2024-07-18




[pdf]

Instrukcja obsługi pol Deerma DX700 álló porszívó ezüst 13099 18865 67498904dd5fe5e5586c92c1afd49e7d puputeve hu media wysiwyg attachments ||| Wyjmij filtr HEPA i opr6i:nij pojemnik z kurzu. Czyszczenie i konserwacja Owiri przew6d zasilajq ... zasilajqcego Zasil; g pracy Waga Poziom glosnoci Material Moc znamionowa Odkurzacz pionowy DX700/DX700S 22 0-240V- 50-60Hz 4,5m Sm 2,75kg 75dB ABS / poliwl; glan 60 0W Moc ssania 15 kPa Ochrona ...
lang:pl score:23 filesize: 2.1 M page_count: 3 document date: 2022-09-14



[pdf] User Manual

User Manual EN eng Deerma DX700s álló porszívó szürke 2671 18849 055ffd6bbc754d35349bd2fa17d45ec3 puputeve hu media wysiwyg attachments ||| ...
lang:pl score:22 filesize: 2.05 M page_count: 5 document date: 2020-09-29



[\[pdf\]](#)

LD220 HU docId 9F2C2A7368CE1C68F4F3D4D8F986C393 Használati utasítás hun Deerma DX700 álló porszívó ezüst 55544 18865 2179988a843147ef5a6ac9dd0e202943 puputeve hu media wysiwyg attachments |||

Használati útmutató DX700/**DX700S** Porszívó Olvassa el figyelmesen az utasításokat. Kérjük a vásárlást követően, olvassa el ezt a kézikönyvet a termék használatával kapcsolatban, és tartsa meg későbbi hivatkozásként. A kézikönyvben szereplő információk csak szemléltetésre szolgálnak, és nem feltétlenül tükrözik teljes mértékben a valóságot...

lang:no score:22 filesize: 1.22 M page_count: 15 document date: 2024-07-03



[\[pdf\]](#) User Manual

Δείτε το manual του προϊόντος ΕΔΩ !! Xiaomi Deerma Handheld vacuum cleaner DX700W AllSmart4u DX700 series allsmart4u gr 2022 10 |||

...

lang:no score:21 filesize: 2.05 M page_count: 5 document date: 2020-09-29




[\[pdf\]](#) User Manual

BG Deerma DX700 DX700s smart Ръководство на потребителя натисни и изтегли Прахосмукачка Купи от SmartX bg!KXG0005070 manual bgcdn shopify s files 1 2680 7864 KXG0005070 bg |||

...

lang:no score:21 filesize: 3.08 M page_count: 10 document date: 2022-02-17

[illegible][illegible]



Pravna zaštita marky.

Pravna zaštita marky. Marky je zadržava pravo na korišćenje i distribuciju svojih proizvoda. Svi drugi proizvodi koji imaju sličan izgled ili naziv mogu biti registrovani kao kopije ili falsifikati. Marky ne može biti odgovoran za bilo kakve štete ili gubitke koje mogu nastati upotrebom bilo kojeg od svojih proizvoda. Marky ne može biti odgovoran za bilo kakve štete ili gubitke koje mogu nastati upotrebom bilo kojeg od svojih proizvoda.



Pravna zaštita marky.

Pravna zaštita marky. Marky je zadržava pravo na korišćenje i distribuciju svojih proizvoda. Svi drugi proizvodi koji imaju sličan izgled ili naziv mogu biti registrovani kao kopije ili falsifikati. Marky ne može biti odgovoran za bilo kakve štete ili gubitke koje mogu nastati upotrebom bilo kojeg od svojih proizvoda. Marky ne može biti odgovoran za bilo kakve štete ili gubitke koje mogu nastati upotrebom bilo kojeg od svojih proizvoda.

Odobravanje distributivnog insitituta državi

Pravna zaštita marky.

Pravna zaštita marky. Marky je zadržava pravo na korišćenje i distribuciju svojih proizvoda. Svi drugi proizvodi koji imaju sličan izgled ili naziv mogu biti registrovani kao kopije ili falsifikati. Marky ne može biti odgovoran za bilo kakve štete ili gubitke koje mogu nastati upotrebom bilo kojeg od svojih proizvoda. Marky ne može biti odgovoran za bilo kakve štete ili gubitke koje mogu nastati upotrebom bilo kojeg od svojih proizvoda.

[\[pdf\]](#)

Has clic para ver la tabla de garantíaOferta Especial ¡Tiempo Limitado!Tabla plazos garantia por codigo y productocdn shopify s files 1 0679 9766 3456 Tabla producto v 1718744527 |||

4. Tabla de plazos de garantía por código y producto CODIGO DEM-FB15W DEM-KZ130W DEM-KZ200 BM-DH060B ... M-FD10W DEM-FD15W CM1300 CM1900 CM800 DX1000 TJ200 BY200 DX1000 DX115C DX118C DX118C_GR DX600 DX700 **DX700S** DX888 DX900_NG TJ200 VC01 VC01MAX VC03S VC20PLUS VC20PRO VC20S VC25 VC25PLUS DEM-ZQ600 DEM-ZQ...

lang:i-klingon score:21 filesize: 340.89 K page count: 2 document date: 2024-06-18

[\[pdf\]](#)

евразийский экономический союз сертификат соответствия «Deerma» модели Handheld Wirelees Vacuum Cleaner VC20 CM700 CM900 DX700S DX900 DX900M Strong Suction Steel Filter 1734211
other cdn vseinstrumenti ru instruction nomenclaturecontent 202106 6992018 |||

...

lang:i-klingon score:21 filesize: 3.43 M page_count: 2 document date: 2020-07-29

[\[pdf\]](#)

Untitled docId A5C354C72080099C27A1D80B550BB0C2 Használati utasítás hun Deerma DX700s álló
porszívó szürke 55585 18849 52e04936db8019cb079de5cae221606c puputeve hu media wysiwyg
attachments |||

Hasznlati utasts **DX700/DX700S** porszv FONTOS BIZTONSGI UTASTSOK A kszlket nem hasznlhatjk olyan szemlyek belertve a gyerekeket is , akik korltozott fizikai, rzkszervi vagy szellemi kpessgekkel rendelkeznek, vagy akiknek nincs tapasztalatuk s ismeretk, kivve, ha a biztonságukrt felels szemly felgyel...


lang:no score:20 filesize: 1.36 M page count: 14 document date: 2024-07-03

[\[pdf\]](#)

PobierzOdkurzacz pionowy Deerma DX700S w Max Kuchnieproxysklep maxkuchnie.pl storage file
pimcore import 2024 12 23 b0cf12990f725ea6267080908b390bbf odkurzacz deerma dx700s instrukcja
obsługi |||

Szczegółowe informacje o warunkach gwarancji dystrybutora / producenta dostępne na stronie internetowej <https://serwis.innpro.pl/gwarancja> ...

lang:no score:16 filesize: 2.51 M page count: 3 document date: 2022-09-14




[pdf] Declaration of Conformity

Бурмистренко Елена Александровна presale black friday 02 19 11 2023 files foxtrot ua StaticContent Ext doc |||

. - 01/11-2023/01 01 2023. - . : 1. - 1 ... EFAL BI520D10 Kettle/metall TEFAL KI513D10 Vac/accum DEERMA Deerma Stick Vacuum Cord Gray Global **DX700S** Vac/vert DEERMA Vacuum Cleaner DX700W smart/tel OPPO A53 4/64GB electric black smart/tel O...

lang:sw score:15 filesize: 337.73 K page_count: 10 document date: 2023-11-01




[pdf] Declaration of Conformity

Гончарова Юлія Анатоліївна Halloween 19 10 01 11 2023 files foxtrot ua StaticContent Ext doc |||

- . 13/10-2023/03 13 2023. - - foxtrot.ua. ... EFAL BI520D10 Kettle/metall TEFAL KI513D10 Vac/accum DEERMA Deerma Stick Vacuum Cord Gray Global **DX700S** Vac/vert DEERMA Vacuum Cleaner DX700W smart/tel OPPO A53 4/64GB electric black smart/tel O...

lang:so score:15 filesize: 361.06 K page_count: 9 document date: 2023-10-18



[pdf]

евразийский экономический союз Foshan Shunde Deerma Electric Appliances Co LTD Место DEERMA модели DX115C DX118C DX600S DX700S DX600 DX800 TJ200 DX900 DX700 671108 cdn vseinstrumenti ru img certificate compliance 2071846 |||

...

lang:so score:14 filesize: 3.94 M page_count: 2 document date: 2019-12-23



[\[pdf\]](#)

DX700S 20191030 cdr Administrator eerma 4bf13176c72f2c9b85ac3db843108b82 Deerma DX700
porszívó robofox hu custom 7mallhu image data srattached |||

eerma Hasznlati utasts Porszv MODELSZM:**DX700S** KSZNJK A TERMK VSRLST
KRJK, FIGYELMESEN OLVASSA EL A HASZNLAT ELTT A HASZNLATI TMUTATT
BIZTONSGI UTASTSOK A kszlket nem használhatjk olyan személyek belertve a
gyermeket is , akiknek cskkent fizikai, rzkszervi vagy mentlis kpessgeik vannak,
vagy nin...

lang:no score:14 filesize: 907.45 K page_count: 8 document date: 2020-12-08