Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Janome 859-801-027

Janome Presser Foot Holder 859-801-027 Instruction Manual

Model: 859-801-027 | Brand: Janome

1. Product Overview

The Janome Presser Foot Holder 859-801-027 is an essential accessory designed for specific Janome sewing machines. This component securely holds various presser feet, enabling different sewing techniques. It is particularly suited for machines with a 9mm stitch width, horizontal full rotary hook, and advanced features such as embroidery functions and feeding mechanisms.
This holder is an updated version, replacing the 859-801-005 model, and features a black lever for easy operation.

Compatibility

This presser foot holder is compatible with a wide range of Janome and Elna computer sewing machine models, including but not limited to:

- Elna Excellence 730 (858TH2 type)
- Elna Excellence 760 (858TU type)
- Secio 9700 / 9710 (861B type)
- Hypercraft 900 (861C type)
- Secio 14000 (862G type)
- Hypercraft 1500 (862H type)
- Atelier 7 / 7S (863CUx type)
- Memory Craft H8800 (863CUx type)
- MC6700P (866B type)
- MC9450



Figure 1.1: Front view of the Janome Presser Foot Holder 859-801-027, showing its metallic body and black lever.

2. Setup and Installation

Before installing the presser foot holder, ensure your sewing machine is turned off and unplugged from the power outlet for safety.

1. **Prepare the Machine:** Raise the presser foot lever to its highest position. If a presser foot holder is already installed, gently push the black lever on the side of the holder to release the attached presser foot. Then, loosen the screw that secures the holder to the presser bar and remove the old holder.
2. **Attach the New Holder:** Align the new Janome Presser Foot Holder 859-801-027 with the presser bar. Ensure the opening at the top of the holder fits securely onto the presser bar.
3. **Secure the Holder:** Tighten the screw on the presser bar to firmly secure the holder in place. Do not overtighten.
4. **Attach a Presser Foot:** Lower the presser foot lever so that the slot on the presser foot aligns with the pin on the presser foot holder. Push the presser foot up until it clicks into place.



Figure 2.1: The presser foot holder shown from a slight distance, illustrating its compact size relative to a sewing machine's components.

For detailed instructions specific to your sewing machine model, please refer to your machine's main instruction manual.

3. Operating the Presser Foot Holder

The presser foot holder acts as the interface between your sewing machine and various specialized presser feet. Its primary function is to allow quick and easy attachment and detachment of different presser feet required for various sewing tasks.

- **Changing Presser Feet:** To change a presser foot, simply raise the presser foot lever, press the black release lever on the side of the holder, and the attached foot will drop off. To attach a new foot, align it under the holder and lower the presser foot lever until the pin on the holder snaps into the groove of the foot.
- **Embroidery Function:** For machines with embroidery capabilities, this holder ensures stable and precise movement of the fabric, crucial for intricate designs.
- **Feeding Mechanism:** The holder works in conjunction with the machine's feeding mechanism (feed dogs) to ensure smooth and even fabric feeding, especially important for models with advanced feeding systems.



Figure 3.1: A side view of the presser foot holder, highlighting the black release lever and its metallic construction.

4. Maintenance

Proper maintenance ensures the longevity and optimal performance of your presser foot holder.

- **Cleaning:** Periodically wipe the presser foot holder with a soft, dry cloth to remove any lint, dust, or fabric fibers that may accumulate. Avoid using harsh chemicals or abrasive materials, as these can damage the finish.
- **Storage:** When not in use, store the presser foot holder in a clean, dry place, preferably in a sewing machine accessory box, to protect it from dust and potential damage.
- **Inspection:** Regularly inspect the holder for any signs of wear, bending, or damage. If any issues are observed, consider replacing the part to maintain sewing quality.

5. Troubleshooting

If you encounter issues with your presser foot holder, consider the following common problems and solutions:

Problem	Possible Cause	Solution
Presser foot does not attach securely.	Incorrect alignment; debris in the mechanism; worn out foot/holder.	Ensure the presser foot is correctly aligned with the holder's pin. Clean any lint or debris. Inspect both the foot and holder for wear and replace if necessary.
Holder feels loose on the presser bar.	Securing screw is loose.	Tighten the securing screw on the presser bar. Do not overtighten.
Stitches are uneven or skipped.	Holder is bent or damaged; incorrect presser foot for fabric.	Inspect the holder for any visible damage. Ensure you are using the appropriate presser foot for your fabric and sewing task.

6. Specifications

Attribute	Detail
Model Number	859-801-027
Replaces Model	859-801-005
Type	Presser Foot Holder (Black Lever Type)
Compatibility	9mm stitch width horizontal full rotary hook computer sewing machines, including models with embroidery and feeding mechanisms.
Dimensions (Approx.)	31 x 23 x 3 cm (Packaging Size)
Manufacturer	Janome Sewing Machine Industry Co., Ltd.

7. Warranty and Support

Warranty Information

This product comes with a manufacturer's warranty of**1 year** from the date of purchase from our company. Please retain your proof of purchase for warranty claims.

Customer Support

For any questions, technical assistance, or warranty claims regarding your Janome Presser Foot Holder 859-801-027, please contact Janome customer support or the retailer from whom you purchased the product.
You may find contact information on the official Janome website or through your product's original packaging.

© 2024 Janome Sewing Machine Industry Co., Ltd. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0872L9XK4

More documents and user manuals: **https://manuals.plus/**