Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Villeroy & Boch 10-4240-3932

Villeroy & Boch Manufacture Rock Blanc Dip Bowl

Model: 10-4240-3932

1. Product Overview

The Villeroy & Boch Manufacture Rock Blanc Dip Bowl is a premium porcelain serving piece designed for finger food, dips, and sauces. Its unique surface texture, reminiscent of natural slate, adds a distinctive touch to any table setting. This bowl is crafted for both aesthetic appeal and practical use.



Image 1.1: The Manufacture Rock Blanc Dip Bowl integrated into a full table setting, showcasing its elegant design.

2. Setup and Initial Use

2.1 Unpacking

Carefully remove the dip bowl from its packaging. Inspect the item for any signs of damage during transit. If any damage is observed, please contact customer support immediately.

2.2 Initial Cleaning

Before first use, wash the bowl thoroughly with warm water and a mild dish soap. Rinse completely and dry with a soft cloth. The bowl is also dishwasher safe for convenient cleaning.

3. Operating (Usage)

The Manufacture Rock Blanc Dip Bowl is versatile and suitable for various culinary presentations.

- **Serving Dips and Sauces:** Ideal for individual servings of dips, chutneys, or sauces to accompany appetizers and main courses.
- **Finger Food:** Can hold small portions of nuts, olives, or other finger foods.
- **Brunch Items:** Perfect for serving honey, jam, or cream cheese during brunch.



Image 3.1: The dip bowl used to serve breadsticks and grapes, demonstrating its suitability for various snacks.



Image 3.2: A dip bowl containing seaweed salad, illustrating its use for international cuisine.



Image 3.3: Small dip bowls used for sauces alongside sushi, highlighting their functional elegance.

4. Maintenance and Care

4.1 Cleaning

The Villeroy & Boch Manufacture Rock Blanc Dip Bowl is designed for easy care:

- **Dishwasher Safe:** This bowl can be safely cleaned in a dishwasher. Place it securely to prevent movement during the wash cycle.
- **Hand Washing:** For hand washing, use warm water, a mild detergent, and a non-abrasive sponge or cloth. Rinse thoroughly and dry immediately to prevent water spots.

4.2 Microwave Use

This porcelain bowl is microwaveable. Exercise caution when removing from the microwave as the bowl may become hot.

4.3 Storage

Store the bowl in a manner that prevents chipping or scratching. If stacking, consider using felt protectors between items.

5. Troubleshooting

As a durable porcelain item, the dip bowl requires minimal troubleshooting. However, consider the following:

- **Chipping or Cracking:** Porcelain is strong but can chip or crack if dropped or subjected to sudden temperature changes. Handle with care.
- **Stains:** Most food stains can be removed with standard dishwashing. For stubborn stains, a gentle porcelain cleaner or a paste of baking soda and water can be used, followed by thorough rinsing.

6. Specifications

Feature	Detail
Model Number	10-4240-3932
Material	Premium Porcelain
Color	White
Capacity	100 Milliliters
Dimensions (W x H)	3.31 inches x 1.57 inches
Item Weight	0.1 Kilograms
Dishwasher Safe	Yes
Microwaveable	Yes
Included Components	1 x bowl

7. Warranty and Support

For detailed warranty information, please refer to the documentation included with your purchase or visit the official Villeroy & Boch website. For product support, inquiries, or to report any issues, please contact Villeroy & Boch customer service through their official channels.
Manufacturer: Villeroy & Boch
Model Number: 10-4240-3932

© 2026 Villeroy & Boch. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0873TNSXY

More documents and user manuals: **https://manuals.plus/**