Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

SENCOR SEC 106 BU

SENCOR SEC 106 BU Scientific Calculator User Manual

Model: SEC 106 BU

1. Introduction

Welcome to the user manual for your SENCOR SEC 106 BU Scientific Calculator. This guide provides detailed instructions on how to set up, operate, and maintain your calculator, ensuring you can utilize its full range of 56 scientific functions effectively for academic and professional tasks.

The SENCOR SEC 106 BU is designed for students and professionals, featuring a large 10-digit LCD display and a comprehensive set of mathematical functions, including trigonometric, hyperbolic, logarithmic, and exponential calculations, as well as coordinate and angle conversions.




Figure 1: SENCOR SEC 106 BU Scientific Calculator. This image displays the calculator's front view, highlighting its black and blue casing, the clear 10-digit LCD screen, and the arrangement of its function keys.

2. Setup

2.1. Battery Installation

Your SENCOR SEC 106 BU calculator requires battery power. Please follow these steps to install or replace batteries:

1. Locate the battery compartment cover on the back of the calculator.
2. Using a small screwdriver (if necessary), gently remove the cover.
3. Insert new batteries (typically AAA or button cell, refer to the compartment for specific type) ensuring the correct polarity (+/-) as indicated inside the compartment.
4. Replace the battery compartment cover and secure it.

Note: Always use fresh batteries of the specified type. Remove batteries if the calculator will not be used for an extended period to prevent leakage.

2.2. Turning On/Off

- To turn on the calculator, press the **ON** button.
- To turn off the calculator, press the **SHIFT** button followed by the **OFF** button (often shared with another key).

3. Operating Instructions

3.1. Basic Operations

- **Number Entry:** Use the numeric keypad (0-9) to enter numbers.
- **Decimal Point:** Press the **.** key for decimal values.
- **Arithmetic Operations:** Use **+**, **-**, **×**, **÷** for addition, subtraction, multiplication, and division.
- **Equals:** Press **=** to display the result of a calculation.
- **Clear Entry (CE):** Press **CE** to clear the last entered number.
- **All Clear (AC):** Press **AC** to clear all calculations and memory, resetting the calculator.

3.2. Scientific Functions

The SEC 106 BU offers 56 scientific functions. Many functions are accessed by pressing the **SHIFT** key first, followed by the desired function key (indicated by secondary labels above the keys).

3.2.1. Trigonometric and Hyperbolic Functions

- **Trigonometric:** **SIN**, **COS**, **TAN**. Use **SHIFT** + **SIN** ($\sin^{-1}$), **SHIFT** + **COS** ($\cos^{-1}$), **SHIFT** + **TAN** ($\tan^{-1}$) for inverse functions.
- **Hyperbolic:** Look for **HYP** or similar key to access hyperbolic functions (sinh, cosh, tanh, etc.).
- **Angle Units:** Press **DRG** or **MODE** to cycle through DEG (degrees), RAD (radians), and GRAD (gradians). Ensure the correct mode is selected for trigonometric calculations.

3.2.2. Logarithmic and Exponential Functions

- **Logarithm (base 10):** **LOG**
- **Natural Logarithm (base e):** **LN**
- **Exponential (10^x):** **SHIFT** + **LOG**
- **Exponential (e^x):** **SHIFT** + **LN**

3.2.3. Power and Root Functions

- **Square:** x^2
- **Square Root:** $\sqrt{}$
- **Cube:** **SHIFT** + x^2 (x^3) or dedicated key.
- **Cube Root:** **SHIFT** + $\sqrt{}$ ($\sqrt[3]{}$) or dedicated key.
- **Power (y^x):** **^** or y^x

3.2.4. Memory Functions

- **Store to Memory:** **STO** or **M+** (adds current value to memory).
- **Recall from Memory:** **RCL** or **MR**.
- **Clear Memory:** **SHIFT** + **MC** or **AC** (clears all).

3.2.5. Coordinate and Angle Conversions

- **Polar to Rectangular (Pol→Rec):** Convert polar coordinates (r, θ) to rectangular coordinates (x, y).
- **Rectangular to Polar (Rec→Pol):** Convert rectangular coordinates (x, y) to polar coordinates (r, θ).
- Refer to the calculator's key labels for specific button sequences, often involving **SHIFT** and dedicated conversion keys.

4. Maintenance

4.1. Cleaning

- Wipe the calculator's exterior with a soft, dry cloth.
- For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Do not use strong solvents.
- Avoid getting liquids inside the calculator.

4.2. Storage

- Store the calculator in a cool, dry place, away from direct sunlight and extreme temperatures.
- If storing for an extended period, remove the batteries to prevent leakage and potential damage.

5. Troubleshooting

Problem	Possible Cause	Solution
Display is blank or dim.	Low or dead batteries; calculator is off.	Replace batteries; press **ON** button.
Incorrect calculation results.	Incorrect mode (e.g., angle unit); incorrect input; previous calculation in memory.	Check and change angle mode (DEG/RAD/GRAD); press **AC** to clear all; re-enter calculation carefully.
Buttons are unresponsive.	Dirt or debris under keys; internal malfunction.	Clean around keys; if problem persists, contact customer support.
Calculator freezes.	Temporary software glitch.	Remove and reinsert batteries to perform a hard reset. Note: This will clear all memory.

6. Specifications

- **Model:** SEC 106 BU (Manufacturer Model: 45012538)
- **Brand:** SENCOR
- **Display:** Large 10-digit LCD
- **Functions:** 56 scientific functions
- **Power Source:** Battery (type not specified, typically AAA or button cell)
- **Color:** Black-Blue
- **ASIN:** B0873VTCCS

7. Warranty and Support

For warranty information, technical support, or service inquiries regarding your SENCOR SEC 106 BU Scientific Calculator, please refer to the warranty card included with your product or visit the official SENCOR website. Contact details for customer support are typically available on the manufacturer's website.

© 2023 SENCOR. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0873VTCCS

More documents and user manuals: **https://manuals.plus/**