

[Manuals.plus](#) /

› [Lock'er Down](#) /

› Lock'er Down® EXxtreme Console Safe User Manual

Lock'er Down LD2028EX

Lock'er Down® EXxtreme Console Safe User Manual

Model: LD2028EX | Brand: Lock'er Down

1. INTRODUCTION

The Lock'er Down Console Safe is designed to safeguard your valuables within your vehicle. This product provides secure storage, meeting high standards for both security and design. It is constructed from durable materials to ensure peace of mind when storing personal items.

This manual provides essential information for the proper installation, operation, and maintenance of your Lock'er Down EXxtreme Console Safe.



Image: The Lock'er Down EXxtreme Console Safe in its closed position, showcasing its robust black finish and compact design.

2. COMPATIBILITY

This EXxtreme console safe is specifically designed for compatibility with the following vehicle models:

- 2009-2018 Dodge Ram 1500, 2500, and 3500 with Full Floor Consoles.
- 2019 Dodge Ram 1500 Classic with full floor consoles.

Important Note:

This model will **not** fit if your vehicle has a CD player integrated into the center console.



Image: The Lock'er Down EXxtreme Console Safe securely installed within a vehicle's center console, demonstrating its seamless integration.

3. KEY FEATURES

- **Enhanced Security:** Constructed from solid domestic 12 gauge cold rolled steel, providing robust protection for your valuables.
- **EXxtreme Protection:** Features an improved door design with an additional 10 gauge domestic cold rolled steel plate. This plate overlaps the safe frame, eliminating pry points and stiffening the entire assembly for maximum security.
- **Accessible Combination Lock:** Equipped with a 4-digit combination lock for quick and easy access to contents.
- **Durable Finish:** Features a black powder coat finish for enhanced durability and corrosion resistance.
- **Spring-Assisted Hinge:** The door hinge is spring-assisted for smooth opening and closing.



Image: The console safe with its lid open, revealing the spacious interior and the robust hinge mechanism.

4. SETUP AND INSTALLATION

The Lock'er Down EXxtreme Console Safe is designed for easy installation. While specific steps may vary slightly depending on your vehicle's console configuration, the general process involves securing the safe within the existing console space.

General Installation Steps:

1. **Clear Console:** Ensure your vehicle's center console is empty and clean before installation.
2. **Position Safe:** Carefully place the Lock'er Down safe into the console opening. Ensure it sits flush and is properly aligned.
3. **Secure Safe:** Utilize the provided hardware (if any, typically bolts or screws) to secure the safe to the console's base or sides. Refer to any specific vehicle-model instructions that may accompany the product for precise mounting points.
4. **Test Fit:** After securing, gently test the safe's stability and ensure the console lid (if applicable) closes properly over

it.

For detailed, vehicle-specific installation instructions, please refer to any supplementary guides provided with your safe or consult the manufacturer's website.



Image: An overhead view of the Lock'er Down safe integrated into a vehicle's center console, showing its secure fit.

5. OPERATING THE COMBINATION LOCK

Your Lock'er Down EXxtreme Console Safe is equipped with a 4-digit combination lock for secure access.

Setting Your Combination:

The safe comes with a factory-set combination, usually indicated on a sticker or tag. It is highly recommended to change this to a personal combination immediately after installation.

1. **Open the Safe:** Use the current combination to open the safe door.
2. **Locate Reset Mechanism:** Inside the safe door, locate the reset button or lever. This is typically a small button or a lever that needs to be pushed or moved.
3. **Set New Combination:** While holding the reset mechanism (or with it in the reset position), rotate the dials to your desired 4-digit combination. Choose a memorable but secure combination.
4. **Release Reset Mechanism:** Release the reset button or return the lever to its original position.
5. **Test New Combination:** With the safe door open, scramble the dials and then enter your new combination to

ensure it opens correctly. Do this several times before closing the safe.

Opening the Safe:

1. Rotate the dials to align with your 4-digit combination.
2. Turn the knob or handle to unlock the safe.
3. The spring-assisted hinge will help lift the lid for easy access.



Image: A detailed view of the 4-digit combination lock mechanism on the safe's lid.

6. MAINTENANCE

The Lock'er Down EXxtreme Console Safe is built for durability and requires minimal maintenance. Following these simple guidelines will help ensure its longevity and continued performance:

- **Cleaning:** Wipe the exterior of the safe with a soft, damp cloth to remove dust and grime. Avoid abrasive cleaners or solvents that could damage the powder coat finish.

- **Lock Mechanism:** Periodically check the combination lock dials for smooth operation. If they become stiff, a small amount of graphite powder (not oil-based lubricants) can be applied to the mechanism, but this is rarely needed.
- **Hinges:** The spring-assisted hinges are designed for long-term use. If any squeaking occurs, a small amount of silicone spray lubricant can be applied to the hinge pins.
- **Interior:** Keep the interior of the safe clean and free of debris to prevent interference with the locking mechanism or damage to stored items.

7. TROUBLESHOOTING

If you encounter any issues with your Lock'er Down EXxtreme Console Safe, consider the following troubleshooting steps:

- **Safe Will Not Open with Combination:**
 - Ensure you are entering the correct 4-digit combination. Double-check each digit.
 - Verify that the dials are precisely aligned with the indicator mark.
 - If you recently changed the combination, ensure you followed all steps correctly and tested it before closing the safe.
- **Lid is Stiff or Does Not Open Smoothly:**
 - Check for any obstructions around the lid or hinges.
 - Apply a small amount of silicone spray lubricant to the hinge pins if necessary.
- **Safe Feels Loose After Installation:**
 - Re-check all mounting hardware to ensure it is securely tightened.

If these steps do not resolve the issue, please contact Lock'er Down customer support for further assistance.

8. SPECIFICATIONS

Attribute	Detail
Manufacturer	Lock'er Down®
Brand	Lock'er Down
Model Number	LD2028EX
Item Model Number	LD2028EX EXxtreme Console Safe
Parcel Dimensions	37.08 x 37.08 x 27.43 cm
Item Weight	7.51 kg
Lock Type	Combination
Colour	Black
Material	Alloy Steel
Mounting Type	In-vehicle console

Attribute	Detail
Date First Available	May 18 2020




Image: A diagram illustrating the key dimensions of the Lock'er Down EXxtreme Console Safe.

9. WARRANTY AND SUPPORT

Lifetime Warranty: All Lock'er Down Safe products are proudly manufactured in the United States of America and come with a comprehensive Lifetime Warranty. This warranty covers defects in materials and workmanship under normal use.

For warranty claims, technical support, or any inquiries regarding your Lock'er Down EXxtreme Console Safe, please contact the manufacturer directly. Refer to the product packaging or the official Lock'er Down website for current contact information.

When contacting support, please have your product model number (LD2028EX) and purchase details readily available.

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question