

[Manuals.plus](#) /

› [T3 Micro](#) /

› T3 SoftTouch 3 Diffuser Instruction Manual

T3 Micro 76882

T3 SoftTouch 3 Diffuser Instruction Manual

Model: 76882

Brand: T3 Micro

INTRODUCTION

The T3 SoftTouch 3 Diffuser is an essential accessory designed to enhance your hair drying experience, specifically for wavy, curly, or coily hair types. It effectively volumizes, defines curls, and eliminates frizz, providing soft and shiny results.



Image: Top-down view of the T3 SoftTouch 3 Diffuser, highlighting its vented surface and finger extensions designed for even air distribution.

COMPATIBILITY

This diffuser is specifically engineered for seamless integration with select T3 hair dryer models. Ensure your hair dryer is one of the compatible models listed below for optimal performance and secure attachment.

- T3 AireLuxe Hair Dryer
- T3 Featherweight StyleMax Hair Dryer
- T3 Featherweight 3i Hair Dryer

Note: This diffuser is not universal and will not fit other hair dryer brands or T3 models not listed above. Always verify compatibility before use.

Compatible with
T3 AireLuxe, T3 Featherweight StyleMax,
and T3 Featherweight 3i dryers only.*



T3 AireLuxe



T3 Featherweight
StyleMax



T3 Featherweight 3i

*Dryers sold separately.

Image: Visual representation of the T3 SoftTouch 3 Diffuser alongside the compatible T3 AireLuxe, T3 Featherweight StyleMax, and T3 Featherweight 3i hair dryers.




Image: A compatibility chart indicating which T3 hair dryer models are compatible with the SoftTouch 3 Diffuser.

SETUP: ATTACHING AND REMOVING THE DIFFUSER

Proper attachment and removal of the T3 SoftTouch 3 Diffuser are crucial for its longevity and effective performance. Follow these steps carefully:

Attaching the Diffuser:

1. Hold your T3 hair dryer by the vented end with one hand.
2. Align the diffuser with the hair dryer's nozzle. Ensure the grooves on the diffuser align with the corresponding parts on the dryer.
3. Gently push the diffuser onto the nozzle until it clicks securely into place. Do not force it.

Removing the Diffuser:

1. Hold the hair dryer by its handle.
2. Instead of pulling the diffuser straight off, gently angle it slightly while pulling. This helps to disengage the locking mechanism smoothly.
3. The diffuser should pop off easily. Avoid excessive force to prevent damage to the attachment tabs.

For a visual guide on attaching and removing the diffuser, please watch the official T3 instructional video below:

Your browser does not support the video tag. You can view the video at [this link](#).

Video: Official T3 Micro guide on how to attach and remove concentrators and diffusers from T3 hair dryers.

OPERATING INSTRUCTIONS

The T3 SoftTouch 3 Diffuser is designed to dry hair gently and evenly, promoting defined curls and reducing frizz. Follow these tips for best results:

- **Prepare Hair:** After washing, gently towel-dry your hair to remove excess water. Apply your preferred curl-defining product.
- **Set Dryer:** Attach the diffuser to your compatible T3 hair dryer. Set the dryer to a low heat and low speed setting to prevent frizz and heat damage.
- **Diffuse Hair:** Gently cup sections of your hair with the diffuser, bringing it up towards your scalp. Hold for a few seconds, then move to the next section. Avoid vigorous shaking or rubbing.
- **Even Heat Distribution:** The vented finger extensions are designed to distribute air evenly, ensuring fast drying and consistent results.
- **Finish:** Continue until your hair is mostly dry or completely dry, depending on your desired look. For added volume, you can flip your head upside down while diffusing.

Vented finger extensions for
fast drying.



Image: A close-up view of the diffuser's vented finger extensions, which facilitate fast and gentle drying.

Even heat distribution for
soft & shiny results.



Image: A user demonstrating the application of the T3 SoftTouch 3 Diffuser to curly hair, illustrating how it provides even heat for soft and shiny results.

CARE AND MAINTENANCE

To ensure the longevity and optimal performance of your T3 SoftTouch 3 Diffuser, follow these maintenance guidelines:

- **Cleaning:** Ensure the diffuser is completely cool before cleaning. Wipe the surface with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** Store the diffuser in a cool, dry place, away from direct sunlight and moisture. Protect it from impacts that could damage the finger extensions or attachment tabs.
- **Handle with Care:** Always attach and remove the diffuser as instructed to prevent damage to the locking mechanism.

TROUBLESHOOTING

If you encounter any issues with your T3 SoftTouch 3 Diffuser, please refer to the common troubleshooting tips below:

- **Diffuser not attaching securely:** Ensure you are using a compatible T3 hair dryer model (AireLuxe, Featherweight StyleMax, or Featherweight 3i). Verify that the diffuser is aligned correctly with the dryer's nozzle before pushing it into place. A gentle click indicates proper attachment.
- **Diffuser difficult to remove:** When removing, angle the diffuser slightly as you pull it off. Avoid pulling straight out, as this can create resistance and potentially damage the tabs.
- **Hair not drying evenly or frizzing:** Ensure your hair dryer is set to a low heat and low speed. The diffuser is designed for gentle, even drying. Avoid high heat or strong airflow, which can disrupt curl patterns and cause frizz.
- **Reduced airflow:** Check for any lint or debris that might be obstructing the vents on the diffuser or the hair dryer's filter. Clean as per maintenance instructions.

If the issue persists, please contact T3 Micro customer support for further assistance.

SPECIFICATIONS

Feature	Detail
Product Dimensions	3.5 x 3.5 x 5.3 inches
Item Weight	4.13 ounces
Model Number	76882
UPC	883349001736
Manufacturer	AmazonUs/T3MIC

WARRANTY AND SUPPORT

For information regarding the product warranty, please refer to the documentation included with your T3 hair dryer or visit the official T3 Micro website.

If you have any questions, require technical assistance, or need to report an issue, our friendly T3 support team is available to help. You can reach us at:

Email: support@T3micro.com

Please have your product model number (76882) and purchase details ready when contacting support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question