

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Home Zone](#) /

› [Home Zone Security ES04128V Smart Wi-Fi 1080p Full HD Indoor Smart Pan and Tilt Camera User Manual](#)

Home Zone ES04128V

Home Zone Security ES04128V Smart Wi-Fi Camera User Manual

Model: ES04128V

INTRODUCTION

This manual provides comprehensive instructions for the setup, operation, and maintenance of your Home Zone Security ES04128V Smart Wi-Fi 1080p Full HD Indoor Pan and Tilt Camera. This camera is designed to provide reliable indoor surveillance with advanced features such as 1080p Full HD resolution, a 150-degree viewing angle, infrared night vision, two-way audio communication, and smart motion detection. It operates via your home's 2.4 GHz Wi-Fi network and is controlled through the Home Zone app, with compatibility for Alexa voice commands.

WHAT'S IN THE BOX

Verify that all components are present before proceeding with installation.

- Home Zone Security ES04128V Smart Wi-Fi Camera
- Power Adapter
- Mounting Accessories
- User Manual (this document)



Image: The Home Zone Security ES04128V Smart Wi-Fi Camera, showing its compact dome design with the lens, speaker, and microphone visible.

SETUP GUIDE


- 1. Download the Home Zone App:** Search for "Home Zone" in your smartphone's app store (iOS or Android) and download the official application.
- 2. Power On the Camera:** Connect the provided power adapter to the camera and plug it into a standard electrical outlet. The camera will initiate its startup sequence, indicated by an LED light.
- 3. Prepare for Pairing:** Ensure your smartphone is connected to a 2.4 GHz Wi-Fi network. The camera only supports 2.4 GHz Wi-Fi.
- 4. Add Device in App:** Open the Home Zone app, create an account or log in. Follow the in-app instructions to add a new device. Select your camera model from the list.

5. **Connect to Wi-Fi:** The app will guide you through connecting the camera to your Wi-Fi network. This typically involves scanning a QR code displayed on your phone with the camera's lens or entering Wi-Fi credentials.
6. **Placement:** Position the camera in your desired indoor location. It can be placed on a flat surface or mounted to a ceiling using the included accessories. Ensure it has a clear line of sight to the area you wish to monitor.

OPERATING INSTRUCTIONS

Live View and Pan/Tilt Control

Once connected, access the live video feed through the Home Zone app. Use the on-screen controls to remotely pan (horizontal) and tilt (vertical) the camera lens to adjust your viewing angle up to 150 degrees.



EXTEND YOUR VIEW

Remotely adjust **150°** camera view with pan/tilt controls

Image: An illustration demonstrating the 150-degree pan and tilt capability of the Home Zone Security camera, showing its wide range of motion.

Two-Way Audio

The camera features a built-in microphone and speaker, enabling two-way audio communication. Tap the microphone icon in the app to speak through the camera, and listen to audio from the camera's surroundings.



TWO WAY AUDIO

Listen and talk remotely through the app

Image: Close-up view of the Home Zone Security camera highlighting the built-in speaker and microphone for two-way audio communication.

Motion Detection and Night Vision

Configure motion detection settings within the app to receive push notifications when activity is detected. The camera is equipped with infrared night vision for clear monitoring in low-light or no-light conditions. It also features automatic motion tracking.



PERSONAL PATROL GUARD

Equipped with automatic motion tracking
and night vision



Image: The Home Zone Security camera in a dark setting, with its infrared lights illuminated, demonstrating its night vision capability and indicating its "Personal Patrol Guard" feature for motion tracking.

Recording and Storage

The camera supports local storage via a microSD card (not included). Insert a compatible microSD card to record video footage. You can view and download recorded events directly from the app. No subscription is required for local storage.

NO SUBSCRIPTION NEEDED

Save and download events from local memory card storage



Image: The Home Zone Security camera placed on a wooden surface next to a plant and books, illustrating its ability to save and download events from local memory card storage without a subscription.

Alexa Integration

The Home Zone Security ES04128V camera is compatible with Amazon Alexa. Link your Home Zone account to Alexa through the Alexa app to enable voice commands for viewing your camera feed on compatible Alexa-enabled devices.




Image: A person in a kitchen, with a speech bubble indicating "Alexa, show my baby room camera.", demonstrating the camera's compatibility with Amazon Alexa voice commands.

Staying Connected

The Home Zone app allows you to stay connected to your home from anywhere. Receive real-time push notifications for motion and sound detection, ensuring you are always aware of activity in your monitored areas.




Image: A person viewing the Home Zone Security camera's live feed on a smartphone, with the app interface showing pan/tilt controls and indicating push notifications for motion and sound detection.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the camera lens and body. Avoid using harsh chemicals or abrasive cleaners.
- **Firmware Updates:** Regularly check the Home Zone app for available firmware updates to ensure optimal performance and security.
- **Power Supply:** Ensure the camera is connected to a stable power source.
- **Network Stability:** A stable 2.4 GHz Wi-Fi connection is crucial for consistent performance.

Troubleshooting

Problem	Possible Cause / Solution
---------	---------------------------

Problem	Possible Cause / Solution
Camera offline / Cannot connect to Wi-Fi	Ensure camera is powered on. Verify your Wi-Fi network is 2.4 GHz. Check Wi-Fi signal strength at camera location. Restart your router and the camera. Re-pair the camera with the app.
Poor video quality	Check Wi-Fi signal strength. Clean the camera lens. Ensure adequate lighting (for non-night vision).
Motion detection not working	Verify motion detection is enabled in the app settings. Adjust sensitivity settings. Ensure camera has a clear view of the area.
Two-way audio issues	Check volume settings on your phone and in the app. Ensure microphone and speaker are not obstructed. Verify network stability.

SPECIFICATIONS

Feature	Detail
Model Number	ES04128V
Resolution	1080p Full HD
Viewing Angle	150 Degrees (Pan/Tilt)
Connectivity	Wi-Fi (2.4 GHz only)
Indoor/Outdoor Usage	Indoor
Special Features	Motion Sensor, Night Vision, Two-Way Audio, Pan/Tilt, Alexa Compatible
Power Source	AC/DC
Dimensions (L x W x H)	12.2 x 8.7 x 8.7 inches
Item Weight	6.4 ounces
Color	White
Storage	Supports MicroSD card (not included)
Control Method	App, Voice (Alexa)


WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the official Home Zone Security website or contact their customer service directly. Keep your purchase receipt for warranty claims.

Visit the [Home Zone Security Store](#) for more products and information.

Related Documents - ES04128V

 <p>The bright way to do home security.</p>	<p>Home Zone Security Smart Wireless Indoor Camera Quick Start Guide Concise guide for setting up and using the Home Zone Security Smart Wireless Indoor Camera. Covers unboxing, installation, network connection, app registration, functions, and troubleshooting FAQs.</p>
	<p>Wyze Cam Pan v2 Quick Start Guide This guide provides instructions for setting up and using the Wyze Cam Pan v2, including configuration, light indicators, and FCC compliance information.</p>
	<p>Laxihub P2F Smart Pan Tilt Wi-Fi Camera Quick Guide A quick start guide for the Laxihub P2F Smart Pan Tilt Wi-Fi Camera, detailing setup, product description, specifications, and support. Compatible with Amazon Alexa and Google Assistant.</p>
	<p>Tapo C200 Pan/Tilt Home Security Wi-Fi Camera Datasheet Datasheet for the Tapo C200 Pan/Tilt Home Security Wi-Fi Camera, featuring 1080p HD, night vision, two-way audio, motion detection, and secure storage.</p>
	<p>D-Link DCS-6501LH Compact Full HD Pan & Tilt Wi-Fi Camera User Manual Comprehensive user manual for the D-Link DCS-6501LH Compact Full HD Pan & Tilt Wi-Fi Camera, detailing setup, installation, app integration, device settings, troubleshooting, technical specifications, and regulatory information.</p>
	<p>SONOFF CAM-PT2 Wi-Fi Smart Security Camera User Manual Comprehensive user manual for the SONOFF CAM-PT2 Wi-Fi Smart Security Camera, detailing its features, specifications, installation, and compliance information. Includes 1080p HD, 360° view, night vision, two-way audio, and motion detection.</p>



[\[pdf\]](#) Quick Start Guide Installation Guide Guide

ES04128V sheet Home Zone Security security QUICK START GUIDE This device only supports 2.4GHz frequency and does not support 5GHz. Please ensure router is set for band before connecting your to 7 About 20cm Step 3 Input WiFi password click Confirm Be sure chosen network Continue Face QR code in front of the camera until you hear a 'beep' homezonesecurity 2020 09

Smart Wireless Indoor Camera security QUICK START GUIDE the bright way to do home security. What's in the box Camera Power adapter USB cable x 3 x 3 Screws Bracket Pin I/M 1 Status light Microphone Micro SD card slot Reset Power Speaker Description Power Status light Microphone Micro SD ...

lang:en score:22 filesize: 7.22 M page_count: 12 document date: 2020-06-26



[Home Zone Security Smart Wireless Indoor Camera Quick Start Guide](#)

Concise guide for setting up and using the Home Zone Security Smart Wireless Indoor Camera. Covers unboxing, installation, network connection, app registration, functions, and troubleshooting FAQs.

lang:en score:22 filesize: 1.48 M page_count: 12 document date: 2021-12-13