

[Manuals.plus](#) /

› [Giantex](#) /

› Giantex 4 Ft Foldable Outdoor Bench Instruction Manual (Model GT70303-OP)

## Giantex GT70303-OP

# Giantex 4 Ft Foldable Outdoor Bench Instruction Manual

Model: GT70303-OP

## 1. INTRODUCTION

---

Thank you for choosing the Giantex 4 Ft Foldable Outdoor Bench. This bench is designed for outdoor use, offering a comfortable seating solution with the added convenience of a foldable design for easy storage. Crafted from high-grade acacia wood, it provides durability and a weight capacity of up to 705 lbs.

Key features include:

- High-grade acacia wood construction for strength and longevity.
- Space-saving foldable design with secure locks for easy storage and transport.
- Ergonomic slatted seat and backrest for optimal comfort.
- Curved armrests and an elegant back cross-line design.



Figure 1: Giantex 4 Ft Foldable Outdoor Bench (Assembled and Folded)

## 2. SETUP AND ASSEMBLY

---

The Giantex 4 Ft Foldable Outdoor Bench requires minimal assembly. All necessary hardware and instructions are included. Please ensure all parts are present before beginning assembly.

### 2.1 Package Contents

- Bench Seat and Backrest Assembly
- Left Armrest/Leg Frame
- Right Armrest/Leg Frame
- Hardware Pack (screws, wrench)

### 2.2 Assembly Steps

1. Carefully unpack all components and verify against the package contents list.
2. Place one armrest/leg frame on a flat, stable surface.

3. Align the bench seat and backrest assembly with the appropriate grooves on the armrest/leg frame. Ensure the holes for the screws are correctly aligned.
4. Position the second armrest/leg frame onto the other side of the bench seat and backrest assembly, ensuring all screw holes align.
5. Insert and hand-tighten all screws into the designated holes. Once all screws are in place, use the provided wrench to fully tighten them. Do not overtighten.

**Assembly Tip:** To ensure proper alignment, it is recommended to place one armrest piece on the floor, set the bench portion into its grooves, and then place the other armrest in position on top before screwing. This method can help ensure correct screw and hole placement.

## 3. OPERATING THE FOLDABLE MECHANISM

---

The Giantex outdoor bench features a convenient folding design for easy storage and portability. Follow these steps to fold and unfold your bench:

### 3.1 Unfolding the Bench

1. Ensure the bench is on a flat, stable surface.
2. Gently pull the armrests outwards until the seat and backrest fully extend and lock into place.
3. Verify that the locking latches (if present) are securely engaged to prevent accidental folding during use.

### 3.2 Folding the Bench for Storage

1. Locate the locking latches on the bench (refer to Figure 2). Unlock the hasps to release the mechanism.
2. Gently raise the seat upwards.
3. Rotate the armrests inwards, allowing the bench to collapse into its compact folded position.
4. Ensure the bench is fully folded and stable before moving or storing.

# 4 FT Acacia Wood Garden Bench



Selected material for long time using

Reinforced frame of large weight capacity

Spacious seat accommodates 2-3 people

Figure 2: Folding Mechanism Steps

## 4. MAINTENANCE

Proper care and maintenance will extend the life and appearance of your Giantex outdoor bench.

### 4.1 Routine Cleaning

- Wipe the bench with a dry cloth regularly to remove dust and debris.
- For more thorough cleaning, use a damp cloth with mild soap and water. Rinse thoroughly and dry immediately to prevent water spots or wood damage.

### 4.2 Wood Care

- Acacia wood benefits from regular oiling, especially if exposed to direct sunlight, to maintain its natural luster and protect against weathering. Teak oil or other suitable outdoor wood oils are recommended.
- Consider a light sanding and application of an outdoor wood stain or sealant for enhanced protection and to customize the finish.

### 4.3 Storage

- When not in use, especially during harsh weather conditions (heavy rain, snow, extreme temperatures), store the bench in a dry, sheltered area. The foldable design facilitates compact storage.
- Protect the bench from prolonged exposure to moisture and direct sunlight to prevent warping, fading, or cracking.



Figure 3: Bench Features and Construction Details

## 5. TROUBLESHOOTING

This section addresses common issues you might encounter with your outdoor bench.

### 5.1 Bench Feels Unstable or Wobbly

- **Check all screws:** Ensure all assembly screws are fully tightened. Loose screws can cause instability.
- **Level surface:** Make sure the bench is placed on a flat, level surface. Uneven ground can make the bench feel wobbly.
- **Re-assembly:** If instability persists, disassemble and carefully re-assemble the bench, paying close attention to aligning all parts before tightening screws.

### 5.2 Difficulty Folding/Unfolding

- **Check latches:** Ensure the locking latches are fully disengaged before attempting to fold.
- **Clear obstructions:** Verify there are no obstructions preventing the movement of the seat or armrests.
- **Lubrication:** If hinges feel stiff, apply a small amount of silicone-based lubricant to the hinge points.

### 5.3 Wood Discoloration or Cracking

- **Weather exposure:** Prolonged exposure to sun and rain can cause wood to fade or crack. Regular application of wood oil or sealant can mitigate this.
- **Storage:** Store the bench indoors or under cover during off-seasons or harsh weather to protect the wood.

## 6. SPECIFICATIONS

Feature	Detail
Brand	Giantex
Model Number	GT70303-OP
Product Dimensions	22"D x 47.5"W x 35.5"H
Seat Height	17.5 Inches
Color	Natural
Furniture Finish	Teak
Maximum Weight Recommendation	705 Pounds
Seating Capacity	2
Item Weight	24.5 pounds
Product Care Instructions	Wipe with Dry Cloth
UPC	791617165106

## Space-Saving Foldable Wood Bench




Figure 4: Product Dimensions

## 7. WARRANTY AND SUPPORT

For specific warranty information regarding your Giantex 4 Ft Foldable Outdoor Bench, please refer to the documentation included with your purchase or contact Giantex directly. Warranty terms typically cover manufacturing defects and material flaws under normal use.

### 7.1 Customer Support

If you have any questions, require assistance with assembly, or need to report a missing or damaged part, please contact Giantex customer service. You can often find contact information on the manufacturer's website or through the retailer where the product was purchased.

Visit the official [Giantex Store on Amazon](#) for more information and support resources.

## 8. ADDITIONAL INFORMATION

**Important Safety Information:** Do not exceed the maximum weight limit of 705 lbs. Always ensure the bench is fully unfolded and stable before use. Keep children and pets away from the bench during folding and unfolding operations.

**Video Resources:** No official product videos from the seller were available for embedding in this manual. Please check the product page or manufacturer's website for any available video guides.

© 2025 Giantex. All rights reserved.