

Hironpal HG-5

Hironpal HG-5 Gaming Chair Instruction Manual

Model: HG-5 | Brand: Hironpal

INTRODUCTION

Thank you for choosing the Hironpal HG-5 Gaming Chair. This manual provides essential information for the safe assembly, operation, and maintenance of your new chair. Please read these instructions carefully before use and retain them for future reference.

SAFETY WARNINGS

- Always follow the assembly instructions carefully to ensure proper and safe installation.
- Do not exceed the maximum weight capacity of 150 kg (330 lbs). Overloading the chair can cause damage or injury.
- Operate the tilt and height adjustment mechanisms with caution to prevent sudden movements or instability.
- Ensure all bolts and screws are tightened securely before use. Periodically check and re-tighten as necessary.
- Keep hands and fingers clear of moving parts during adjustment.
- Do not stand on the chair or use it as a step stool.

PRODUCT FEATURES

The Hironpal HG-5 Gaming Chair is designed for comfort and durability, featuring:

- **High-Quality Material:** Robust metal frame, premium PU leather upholstery, high-resilience foam cushioning, and a high-strength plastic five-star base.
- **Adjustable Recline:** Backrest reclines from 90 to 180 degrees with a locking mechanism.
- **Height Adjustment:** Gas lift mechanism for easy seat height adjustment.
- **3D Adjustable Armrests:** Armrests can be adjusted in three directions (up/down, left/right, forward/backward).
- **Retractable Footrest:** Integrated padded footrest for extended comfort.
- **Ergonomic Support:** Includes removable headrest and lumbar support cushions.
- **Smooth Mobility:** 360-degree swivel and durable, silent PU casters designed to prevent floor scratches.



Image: Overview of Hironpal HG-5 Gaming Chair key features, highlighting premium PU leather, deluxe PP plastic handles, retractable padded footrest, high resilience foam, SGC certified gas lift, and premium universal wheels.

ASSEMBLY INSTRUCTIONS

While specific step-by-step diagrams are not provided here, the general assembly process involves attaching the base, casters, gas lift, seat mechanism, armrests, backrest, and cushions. Please refer to the included assembly guide that came with your product for detailed instructions.

General Assembly Steps:

1. **Unpack Components:** Carefully remove all parts from the packaging and verify against the parts list in your product's assembly guide.
2. **Assemble Base:** Insert the casters into the five-star base.
3. **Install Gas Lift:** Place the gas lift cylinder into the center hole of the assembled base.
4. **Attach Seat Mechanism:** Secure the seat mechanism to the underside of the seat cushion using the provided screws.

5. **Connect Seat to Gas Lift:** Place the assembled seat onto the gas lift cylinder.
6. **Attach Armrests:** Fasten the armrests to the seat cushion.
7. **Mount Backrest:** Secure the backrest to the seat and armrests using the designated screws.
8. **Add Cushions:** Attach the headrest and lumbar support cushions as desired.
9. **Final Check:** Ensure all connections are tight and the chair is stable before use.



Image: An assembled Hironpal HG-5 Gaming Chair in red and black, showcasing its design with the footrest extended.

OPERATING INSTRUCTIONS

1. Seat Height Adjustment

To adjust the seat height, locate the lever on the right side, beneath the seat. While seated, pull the lever upwards to lower the seat. To raise the seat, stand up and pull the lever upwards. Release the lever at the desired height to lock it in place.

2. Backrest Recline Adjustment

The backrest can be reclined from 90 to 180 degrees. Locate the recline lever on the right side of the chair, near the backrest. Pull

the lever up to unlock the backrest, lean back to your desired angle, and then release the lever to lock the position. To return to an upright position, pull the lever and lean forward.

3. Retractable Footrest

To use the footrest, pull it out from beneath the seat. Extend it fully for support. To retract, push it back under the seat until it is fully stored.



Image: A close-up view of the comfortable retractable footrest, designed to support your feet and legs for relaxation.

4. 3D Armrest Adjustment

The armrests can be adjusted in three dimensions: up and down, left and right, and forward and backward. Use the buttons or levers on the armrests to unlock and adjust them to your preferred position. Release to lock.

5. 360-Degree Swivel

The chair features a 360-degree swivel function, allowing for easy rotation without moving the base.

PRODUCT FEATURES



Image: A diagram illustrating the flexible adjustments of the chair, including backrest recline from 90 to 180 degrees, 360-degree swivel, and seat height adjustment.

MAINTENANCE

Proper maintenance will extend the life and appearance of your Hironpal HG-5 Gaming Chair.

- **Cleaning:** Wipe the PU leather surfaces with a soft, damp cloth. For stubborn stains, use a mild soap solution and immediately wipe dry. Avoid harsh chemicals or abrasive cleaners.
- **Hardware Check:** Periodically check all screws and bolts to ensure they are tight. Re-tighten if necessary to maintain stability and safety.
- **Caster Care:** Keep the casters clean from dust and debris to ensure smooth movement and prevent floor scratches.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause the PU leather to fade or crack.

TROUBLESHOOTING

Chair is unstable or wobbly:

- Check all assembly screws and bolts. Tighten any loose connections.
- Ensure the casters are fully inserted into the base.

Gas lift not adjusting height:

- Ensure the height adjustment lever is fully engaged when attempting to raise or lower the seat.
- Check for any obstructions around the gas lift mechanism.

Backrest not reclining or locking:

- Verify that the recline lever is functioning correctly and not obstructed.
- Ensure no foreign objects are lodged in the recline mechanism.

Casters not rolling smoothly:

- Remove any hair, dust, or debris that may be caught in the caster wheels.
- Ensure casters are properly inserted into the base.

PRODUCT SPECIFICATIONS

PRODUCT SIZE

160
KG



Image: A detailed diagram showing the dimensions of the Hironpal HG-5 Gaming Chair, including seat width, backrest height, and overall height range.

Feature	Detail
Brand	Hironpal
Model Number	HG-5
Color	Red
Material	Metal, Polyurethane (PU Leather)
Overall Dimensions (L x W x H)	70 x 70 x 127-137 cm (approx. 27.5 x 27.5 x 50-54 inches)
Product Weight	20 Kilograms (approx. 44 lbs)
Maximum Load Capacity	150 kg (approx. 330 lbs)
Backrest Recline Angle	90-180 degrees

Armrest Type	3D Adjustable
Caster Material	PU (Silent, Floor-friendly)
Special Features	Retractable Footrest, Removable Headrest & Lumbar Support, 360° Swivel, Safety Gas Lift (Certified)

WARRANTY AND SUPPORT

Hironpal is committed to product quality and customer satisfaction.

- **30-Day Return Guarantee:** Please refer to your retailer's return policy for details.
- **12-Month Broken Parts Replacement Warranty:** In the event of a manufacturing defect or broken part within 12 months of purchase, please contact customer service for a replacement.
- **Online Customer Service:** For any inquiries, assistance, or warranty claims, please contact Hironpal customer service through the platform where you purchased the product.

Note: Return shipping costs may need to be negotiated and agreed upon between the seller and buyer before returning an item. Express delivery may be delayed due to weather or other special circumstances.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question