

[Manuals.plus](#) /

› [TUREWELL](#) /

› TUREWELL FC162 Water Dental Flosser Instruction Manual

TUREWELL FC162

TUREWELL FC162 Water Dental Flosser Instruction Manual

Model: FC162

INTRODUCTION

Thank you for choosing the TUREWELL FC162 Water Dental Flosser. This device is designed to provide deep cleaning for your teeth and gums, promoting overall oral health. Please read this manual thoroughly before use to ensure proper operation and maintenance.

IMPORTANT SAFETY INSTRUCTIONS

- Keep out of reach of children.
- Avoid aiming the water jet directly at the throat or eyes.
- Slightly close your lips around the tip during use to prevent water from spraying out, allowing water to flow into the sink from the corner of your mouth.
- Change nozzles every 3 months for optimal hygiene and performance.
- For first-time users or individuals with sensitive teeth, it is recommended to start with a soft pressure mode.

PACKAGE CONTENTS

The TUREWELL FC162 Water Dental Flosser package includes the following items:

- 1 x TUREWELL FC162 Water Dental Flosser Main Unit
- 1 x 600ML Water Tank
- 3 x Standard High-Pressure Jet Tips (for general cleaning)
- 1 x Orthodontic Tip (for braces)
- 1 x Tongue Cleaner Tip (for fresh breath)
- 1 x Periodontal Tip (for gumline cleaning)
- 1 x Dental Plaque Tip (for plaque removal)
- 1 x Toothbrush Tip (for brushing and flossing simultaneously)

8 NOZZLES With Different Functions



Figure 1: Included Water Jet Tips with their functions.

PRODUCT FEATURES

- **Deep Cleaning:** Effectively removes food debris and massages gums, preventing stains, bad breath, and other oral problems. Ideal for braces, implants, crowns, and periodontal pockets.
- **Versatile Jet Tips:** Includes 8 specialized tips for various dental needs.
- **Adjustable Pressure:** 10 pressure settings (30-125 PSI) with a pulse rate of 1250-1700 times/min for customized comfort.
- **Large Water Tank:** 600ML capacity provides 90 seconds of uninterrupted water flow.
- **Leakproof Design:** Ensures no liquid leaks during use.
- **360° Rotating Nozzle:** Allows access to all areas of the mouth for effective cleaning.

Protect The Teeth From 8 Major Oral Problems



Figure 2: Benefits of using the TUREWELL Water Dental Flosser.

SETUP

1. **Fill the Water Tank:** Lift the lid of the water tank and fill it with warm water. Close the lid securely to prevent spills.
2. **Install the Jet Tip:** Select the desired jet tip and firmly insert it into the handle until it clicks into place.
3. **Place Handle:** Place the handle into its designated slot on the unit.
4. **Plug In:** Connect the power cord to an electrical outlet.



Figure 3: Visual guide for initial setup and usage.

OPERATING INSTRUCTIONS

1. **Adjust Pressure:** Rotate the water pressure switch on the main unit to select your preferred strength (1-10). Start with a lower setting (1-4) and gradually increase as comfortable.
2. **Position the Tip:** Lean over the sink and place the jet tip into your mouth, aiming it at your teeth, gumline, or tongue.
3. **Turn On:** Slide the ON/OFF switch on the handle to the 'ON' position to start the water flow.
4. **Floss:** Guide the water jet along your gumline and between your teeth. Move the tip slowly, pausing briefly between teeth.
5. **Finish:** Once finished, slide the ON/OFF switch on the handle to the 'OFF' position. Return the handle to its slot.



Figure 4: Adjustable Water Pressure Settings.

Video 1: Demonstration of the TUREWELL Water Dental Flosser in use, showing water flow and pressure adjustment.

MAINTENANCE

- **Empty and Dry:** After each use, empty any remaining water from the reservoir and allow it to air dry to prevent mold and mildew buildup.
- **Clean the Unit:** Wipe the exterior of the unit with a soft, damp cloth. Do not immerse the main unit in water.
- **Clean Jet Tips:** Rinse jet tips under running water after each use. For deeper cleaning, tips can be soaked in a solution of 2 parts water to 1 part white vinegar for 5-10 minutes.
- **Replace Tips:** Replace jet tips every 3 months or sooner if they show signs of wear.



Figure 5: Convenient Tip Storage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No water flow	Water tank empty; Tip not properly inserted; Unit not turned on.	Refill water tank; Ensure tip clicks into place; Turn on unit and handle switch.
Weak water pressure	Pressure setting too low; Mineral buildup in tip.	Increase pressure setting; Clean or replace jet tip.
Unit leaking	Water tank not seated correctly; Damaged hose/seal.	Ensure water tank is firmly in place; Contact customer support if damage is suspected.

SPECIFICATIONS

- **Model Number:** FC162
- **Water Tank Capacity:** 600ML
- **Water Pressure Range:** 30-125 PSI
- **Pulse Rate:** 1250-1700 times/min
- **Power Source:** Corded Electric
- **Dimensions:** 8.7 x 6.22 x 5.04 inches
- **Weight:** 2.12 Pounds
- **Certifications:** FDA, CE, FCC, RoHS

Product parameters



Figure 6: Labeled Product Components.

WARRANTY AND SUPPORT

For any questions, concerns, or warranty claims regarding your TUREWELL FC162 Water Dental Flosser, please contact TUREWELL customer support. Refer to your product packaging or the official TUREWELL website for contact information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0876YT6RW>

More documents and user manuals: <https://manuals.plus/>