EQUSUPRO PG-ZD09-6MIV

EQUSUPRO Essential Oil Diffuser User Manual

Model: PG-ZD09-6MIV | Brand: EQUSUPRO

1. Introduction

Thank you for choosing the EQUSUPRO Essential Oil Diffuser. This ultrasonic aromatherapy diffuser is designed to enhance your home, office, or personal space with soothing aromas and ambient lighting. Featuring a unique handmade glass design, it offers a tranquil and visually appealing experience. Please read this manual carefully before use to ensure proper operation and maintenance.

2. Safety Information

For your safety and to ensure optimal performance, please observe the following precautions:

- Avoid direct skin contact with undiluted essential oils.
- Keep out of reach of children and pets.
- Ensure proper ventilation during use.
- Do not move or tilt the essential oil diffuser during operation.
- Always dilute essential oil or liquid air freshener with water. Never use only essential oil or liquid air freshener.
- Do not spill water into the air outlet which could damage the base. Keep the base dry.

3. Package Contents

Please check the box for the following items:

- EQUSUPRO Essential Oil Diffuser Unit (Glass Cover & Base)
- Power Adapter

- User Manual

4. Product Features


- **Unique Design:** Handmade glass cover with a cobblestone pattern, ideal for contemporary home, office, gym, spa, or studio decor.
- **Multi-Function:** Functions as an aromatherapy essential oil diffuser, cool mist ultrasonic humidifier, and night light.
- **7 LED Color Changing Lights:** Cycle through 7 colors or fix on a single color to create a relaxing atmosphere.
- **Whisper Quiet Ultrasonic Technology:** Operates silently without disturbing noise, safe for kids and pets.
- **Timer Settings:** Four timer modes: 0.5H, 1H, 2H, and continuous misting mode.
- **Auto Shut-Off Safety Design:** Automatically stops working when water runs out to prevent damage.
- **BPA Free:** Constructed with friendly PP material for safety.



The EQUSUPRO Essential Oil Diffuser featuring its unique Green Mountain glass design.



Illustration of the 7 LED color changing lights feature, creating a relaxing ambiance.



Key features including 120ml water tank, multiple timer settings, whisper-quiet operation, and waterless auto shut-off.



Diagram illustrating the easy operation of the diffuser, including mist and light button functions.



Information on the diffuser's BPA-free, eco-friendly materials, ultra-quiet operation, and automatic safety shutdown.



The versatile EQUSUPRO diffuser is suitable for various environments, including home, office, yoga, and relaxation spaces.

5. Setup

Follow these steps to set up your diffuser:

1. Place the diffuser on a flat, stable surface.
2. Gently remove the glass cover and the inner plastic lid.
3. Fill the water tank with clean tap water up to, but not exceeding, the maximum fill line (120ml).
4. Add 5-7 drops of your preferred essential oil (not included) directly into the water tank. Adjust the number of drops based on desired scent intensity.
5. Replace the inner plastic lid, ensuring it is properly seated.

6. Carefully place the glass cover back onto the base.
7. Connect the power adapter to the diffuser's power input, then plug it into a wall outlet.

6. Operating Instructions

The diffuser features two main buttons: Mist and Light.

Mist Button (Left Button)

Press the Mist button to control the mist output and set the timer:

- **1st Press:** Continuous misting mode.
- **2nd Press:** Set timer for 2 hours.
- **3rd Press:** Set timer for 1 hour.
- **4th Press:** Set timer for 0.5 hours.
- **5th Press:** Turn off the mist.

The diffuser will automatically shut off when the water level is too low, regardless of the timer setting.

Light Button (Right Button)

Press the Light button to control the LED lighting:

- **1st Press:** Activates 7-color cycling mode.
- **Subsequent Presses:** Fixes the light on the current color. Continue pressing to cycle through and select your desired color.
- **Press and Hold:** Turns off the light.

7. Maintenance

Regular cleaning is essential for optimal performance and longevity of your diffuser. It is recommended to clean the diffuser after every 7 uses or every 7 days.

1. Unplug the diffuser from the power outlet.
2. Remove the glass cover and inner plastic lid.
3. Pour out any remaining water from the water tank, ensuring no water enters the air outlet.
4. Use a cotton swab or soft cloth dampened with a small amount of mild dish soap or white vinegar to gently wipe the inside of the water tank and the ultrasonic mist disc (the small ceramic disc in the center of the tank).
5. Rinse the water tank with clean water, being careful not to get water into the air outlet.
6. Wipe the exterior of the diffuser with a soft, dry cloth.
7. Allow all parts to air dry completely before reassembling or storing.

Note: *Do not use harsh detergents, abrasive cleaners, or solvents, as these may damage the diffuser.*

8. Troubleshooting

If you encounter any issues with your diffuser, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No mist or low mist output	Insufficient water; water over max line; mist disc dirty; air outlet wet.	Ensure water is between min and max lines. Clean the mist disc with a cotton swab. Ensure the air outlet is dry.
Diffuser does not turn on	No power; unit not plugged in correctly; water tank empty.	Check power connection. Ensure water tank has sufficient water.
Leaking from the base	Water spilled into air outlet; diffuser tilted during operation.	Unplug and allow base to dry completely. Ensure water is not spilled into the air outlet during filling. Do not move when operating.
Light not working	Light function off.	Press the Light button to activate or cycle through colors.

If the problem persists after trying these solutions, please contact EQUSUPRO customer support for assistance.

9. Specifications

Product Dimensions:

5 x 5 x 9 inches; 1.98 Pounds

Item Model Number:

PG-ZD09-6MIV

UPC:

658848792375

Brand:

EQUSUPRO

Water Tank Capacity:

120ml

Material:

Glass

Timer Settings:

0.5H, 1H, 2H, Continuous

LED Lights:

7 Color Changing LED

10. Warranty and Support

EQUSUPRO products are manufactured with high-quality materials and undergo rigorous quality testing. For any product-related inquiries, technical support, or warranty claims, please contact EQUSUPRO customer service through the retailer's platform or the official EQUSUPRO website.
Please retain your proof of purchase for warranty purposes.

© 2025 EQUSUPRO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question