Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

MERITLINE B087BZT54H

MERITLINE Low Twin Over Twin Bunk Bed Instruction Manual

Model: B087BZT54H | Brand: MERITLINE

Important Safety Information

Always supervise children when using the bunk bed. Do not exceed the maximum weight capacity of 200 lbs per bed. Be cautious while assembling the bed frame to avoid injuries.

- Ensure all connections are securely fastened after assembly and periodically check for tightness.
- Only use mattresses of the specified thickness to maintain proper guardrail height.
- Do not allow jumping on the bed.
- Keep children away from the assembly area during installation.

Product Overview

The MERITLINE Low Twin Over Twin Bunk Bed is designed for compact spaces, offering sleeping arrangements for two individuals. It features a low-profile design, integrated staircase with storage, and solid pine wood construction.

Key Features:

- **Low-Profile Design:** Ideal for smaller rooms, measuring 50.6 inches in height.
- **Solid Wood Construction:** Crafted from pine wood with a painted finish for durability and style.
- **Integrated Staircase with Storage:** Provides safe access to the top bunk and includes built-in storage compartments.
- **Guardrails:** 13.7-inch height guardrails on the upper bunk for safety.
- **Slat Support:** No box spring required; mattresses can be placed directly on the slats.



Image 1: The MERITLINE Low Twin Over Twin Bunk Bed in a grey finish, featuring an integrated staircase with storage.

Setup & Assembly

This bunk bed requires assembly. Detailed instructions, along with all necessary tools, are included in the product packaging. It is recommended that two adults perform the assembly to ensure safety and efficiency.

General Assembly Guidelines:

1. **Unpack Components:** Carefully unpack all parts and hardware. Verify that all components listed in the included instruction manual are present.
2. **Identify Parts:** Refer to the parts list and diagrams in the manual to identify each piece.
3. **Follow Step-by-Step Instructions:** Adhere strictly to the sequence of steps provided in the manual. Do not overtighten screws until instructed.

4. **Secure Connections:** Ensure all bolts, screws, and fasteners are tightened securely once assembly is complete.
5. **Safety Check:** Before use, confirm the bed is stable and all guardrails are properly installed.




Image 2: Side view of the bunk bed, highlighting the staircase and guardrails.



Image 3: Detailed view of the bunk bed's staircase, showing the integrated storage compartments.

Operating Instructions

This bunk bed is designed for sleeping and light recreational use. Proper usage ensures safety and extends the product's lifespan.

Mattress Requirements:

- **Upper Bed Mattress Thickness:** Maximum 6 inches.

- **Lower Bed Mattress Thickness:** 8-10 inches.
- **Mattress Size:** Twin size for both upper and lower bunks.
- **Weight Capacity:** Each bunk has a weight capacity of 200 lbs. Do not exceed this limit.

Ensure mattresses fit snugly within the bed frame to prevent gaps. The integrated staircase provides easy and safe access to the upper bunk. Always use the staircase for climbing to and from the top bunk.



Image 4: The bunk bed shown with mattresses and bedding, illustrating its use in a bedroom.

Maintenance

Regular maintenance helps preserve the condition and safety of your bunk bed.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the

painted finish.

- **Hardware Check:** Periodically inspect all bolts, screws, and fasteners to ensure they remain tight. Retighten as necessary to maintain structural integrity.
- **Slat Inspection:** Check bed slats for any signs of damage or cracking. Replace damaged slats immediately.
- **Guardrail Integrity:** Ensure guardrails are always securely attached and free from damage.

Troubleshooting

If you encounter issues with your bunk bed, consider the following common solutions:

- **Squeaking Noises:** Squeaking often indicates loose hardware. Check and tighten all bolts and screws. Applying a small amount of lubricant to metal-on-metal contact points (if applicable) can also help.
- **Instability/Wobbling:** Ensure the bed is placed on a level surface. Re-check all assembly connections and tighten any loose fasteners.
- **Damaged Parts:** If any part is damaged or missing, refer to your warranty information or contact customer support for assistance. Do not attempt to use the bed with damaged components.

Specifications

Feature	Detail
Brand	MERITLINE
Model	B087BZT54H
Size	Twin Over Twin
Product Dimensions (L x W x H)	76"L x 39.3"W x 50.6"H
Color	Grey
Finish Type	Painted
Material	Solid Pine Wood
Included Components	Guardrails, Staircase, Slats
Compatible Mattress Size	Twin
Upper Bed Mattress Thickness	Max 6 inches
Lower Bed Mattress Thickness	8-10 inches
Weight Capacity (Each Bed)	200 lbs
Assembly Required	Yes
UPC	840130884398




Image 5: Dimensional diagram of the bunk bed, indicating key measurements.

Warranty & Support

Warranty information for your MERITLINE bunk bed is typically included with the product packaging. Please refer to the documentation provided at the time of purchase for specific warranty terms and conditions.

For technical support, missing parts, or any inquiries regarding your product, please contact MERITLINE customer service through the retailer where the product was purchased or visit the official MERITLINE website for contact details.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B087BZT54H

More documents and user manuals: **https://manuals.plus/**