

LG AKB74955603

LG AKB74955603 Air Conditioner Remote Control User Manual

Model: AKB74955603

INTRODUCTION

This manual provides detailed instructions for the proper use and maintenance of your LG AKB74955603 Air Conditioner Remote Control. Please read this manual thoroughly before operating the device to ensure optimal performance and longevity.



Image: The LG AKB74955603 Air Conditioner Remote Control, a white rectangular device with various control buttons.

SETUP

1. Battery Installation

The remote control requires two (2) AAA batteries for operation. Ensure correct polarity when inserting the batteries.

1. Open the battery compartment cover located on the back of the remote control.
2. Insert two new AAA batteries, matching the (+) and (-) terminals as indicated inside the compartment.
3. Close the battery compartment cover securely.

Note: Do not mix old and new batteries, or different types of batteries. Remove batteries if the remote control will not be used for an extended period.

OPERATING INSTRUCTIONS

Point the remote control directly at the air conditioner's receiver. Ensure there are no obstructions between

the remote and the unit.

Key Functions

- **POWER ()**: Turns the air conditioner ON or OFF.
- **MODE**: Cycles through operating modes: Auto, Cool, Dry, Fan, Heat.
- **TEMP ▲/▼**: Adjusts the desired temperature setting.
- **FAN SPEED**: Selects the fan speed (Auto, Low, Medium, High).
- **SWING**: Activates or deactivates the louver swing function.
- **TIMER**: Sets the ON/OFF timer for the air conditioner.
- **SLEEP**: Activates the sleep mode for comfortable night operation.
- **LIGHT**: Controls the display light on the air conditioner unit (if available).
- **FUNCTION/SPECIAL**: Accesses additional functions or settings.

Basic Operation

1. Press the **POWER** button to turn on the air conditioner.
2. Press the **MODE** button repeatedly to select your desired operating mode (e.g., Cool).
3. Use the **TEMP ▲/▼** buttons to set the desired temperature.
4. Adjust the fan speed using the **FAN SPEED** button if needed.
5. To turn off the unit, press the **POWER** button again.

MAINTENANCE

Battery Replacement

Replace batteries when the remote control's range decreases or if the display becomes dim. Follow the battery installation steps outlined in the Setup section.

Cleaning

Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners, abrasive materials, or chemical solvents, as these may damage the surface or internal components.

Storage

Store the remote control in a cool, dry place away from direct sunlight and extreme temperatures. If storing for an extended period, remove the batteries to prevent leakage.

TROUBLESHOOTING

- **Remote control not responding:**
 - Check if the batteries are inserted correctly and are not depleted. Replace if necessary.
 - Ensure there is a clear line of sight between the remote control and the air conditioner's receiver.
 - Verify that the remote control is pointed directly at the air conditioner.

- **Limited operating range:**

- Replace the batteries with new ones.
- Ensure no strong light sources (e.g., direct sunlight, fluorescent lights) are interfering with the infrared signal.

SPECIFICATIONS

Feature	Detail
Model Name	AKB74955603
Brand	LG
Compatible Devices	Air Conditioner
Connectivity Technology	Infrared (IR)
Number of Buttons	10
Maximum Range	10 Meters
Battery Type	2 x AAA (not included)
Special Feature	Easy to Use

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation provided with your air conditioner unit or visit the official LG website. Keep your purchase receipt as proof of purchase for any warranty claims.

For further assistance, you may contact LG customer service through their official channels.