

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Ameriwood Home](#) /
- › [Ameriwood Home Odin Glass L-Shaped Computer Desk Instruction Manual](#)

Ameriwood Home Odin Glass L-Shaped Computer Desk

Ameriwood Home Odin Glass L-Shaped Computer Desk Instruction Manual

Model: Odin Glass L-Shaped Computer Desk

INTRODUCTION

Welcome to your new Ameriwood Home Odin Glass L-Shaped Computer Desk. This manual provides detailed instructions for assembling, using, and maintaining your desk to ensure its longevity and optimal performance. Please read all instructions carefully before beginning assembly or use.



Image: The Ameriwood Home Odin Glass L-Shaped Computer Desk, gold frame with glass top, positioned in a corner of a room with a laptop and decorative items.

SETUP AND ASSEMBLY

The Ameriwood Home Odin Glass L-Shaped Computer Desk requires assembly. It is recommended that 1-2 adults complete the assembly process.

Before You Begin

- Ensure all parts are present and undamaged. Refer to the parts list in your included assembly manual.
- Clear a spacious area for assembly.
- Keep children and pets away from the assembly area.

Assembly Overview

The desk ships in one box. The assembly manual contains 6 steps, and the package includes 17 boards.



Image: An infographic showing the assembly level is medium, recommending 1-2 adults, indicating the product ships in 1 box, has 6 assembly steps, and contains 17 boards.

Assembly Steps

Follow the step-by-step instructions provided in the separate assembly manual included with your product. Ensure all screws are tightened securely but do not overtighten.




Image: A technical drawing illustrating the desk's dimensions (51"L x 32"D x 30.3"H) and weight capacities (60 lbs on each main section, 30 lbs on the corner section).

OPERATING INSTRUCTIONS

The Odin Glass L-Shaped Computer Desk is designed for use as a home office or study desk.

- Place your laptop, lamp, and other office essentials on the spacious glass top surface.
- The L-shape design allows for efficient use of corner spaces, providing ample legroom for comfortable use.
- The desk is suitable for various tasks, including computer work, writing, and studying.

Weight Capacity

The maximum recommended load for this desk is **50 lbs (approximately 22.68 kg)**. Do not exceed this weight limit to prevent damage or injury.

MAINTENANCE AND CARE

Cleaning

To clean the desk, dust and wipe with a dry cloth. If necessary, a damp cloth may be used sparingly. Avoid harsh chemicals or abrasive cleaners, which can damage the finish or glass.

General Care

- Avoid placing hot items directly on the glass surface. Use coasters or protective pads.
- Do not drag heavy objects across the glass to prevent scratches.
- Regularly check and tighten any loose fasteners to maintain stability.

TROUBLESHOOTING

Instability or Wobbling

- Ensure all assembly screws are securely tightened.
- Verify the desk is placed on a flat, level surface. Adjust leg levelers if present.

Scratches on Glass

- While the desk features a scratch-resistant surface, avoid dragging sharp or heavy objects directly on the glass. Use protective mats for keyboards, mice, or other items.

SPECIFICATIONS

Feature	Detail
Item Weight	19.62 kg
Maximum Recommended Load	50 Pounds
Finish Types	Powder Coated
Care Instructions	Dust and wipe with a dry cloth and if needed, a damp cloth may be used sparingly.
Assembly Required	Yes
Type of Guarantee	1 year limited warranty.
Batteries Required	No
Included components	Ameriwood Home Odin Glass L-Shaped Computer, Gold Desk
ASIN	B087CFTC1T
Manufacturer	Ameriwood Home
Place of Business	SAN BRUNO, CA, 94066 US
Brand	Ameriwood Home
Shape	Rectangular
Desk design	Computer Desk
Product Dimensions	129.5D x 129.5W x 77H Centimetres
Colour	Gold

Feature	Detail
Style	Contemporary
Base material	Metal
Top material type	Glass
Finish type	Powder Coated
Special feature	Scratch Resistant

WARRANTY INFORMATION

This product is covered by a **1-year limited warranty** against manufacturer defects. For warranty claims or details, please refer to the documentation included with your purchase or contact Ameriwood Home customer support.

CUSTOMER SUPPORT

For assistance with assembly, missing parts, or any other inquiries, please contact Ameriwood Home customer support. Refer to the contact information provided in your product packaging or visit the official Ameriwood Home website.