

FLEXISPOT EM7

FLEXISPOT 40" Electric Height Adjustable Standing Desk Converter User Manual

Model: EM7

[Contents](#) [Setup](#) [Operating](#) [Introduction](#) [Maintenance](#) [Safety Instructions](#) [Troubleshooting](#) [Package](#) [Specifications](#) [Warranty & Support](#)

1. INTRODUCTION

Thank you for choosing the FLEXISPOT 40" Electric Height Adjustable Standing Desk Converter. This motorized desk riser is designed to transform your existing workspace into an ergonomic sit-stand workstation, promoting better posture and productivity. Its robust construction and smooth electric lift mechanism provide a stable and convenient solution for both home and office environments.




Image: The FLEXISPOT 40" Electric Height Adjustable Standing Desk Converter in a typical office setup, showcasing its two-tier design with space for dual monitors and a laptop on the lower keyboard tray.

2. IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before assembly and use. Failure to follow these instructions may result in injury or damage to the product.

- Ensure all components are present and undamaged before assembly. Do not use if any parts are missing or broken.
- Keep children and pets away from the product during operation.
- Do not place hands or fingers near moving parts during height adjustment.
- Ensure the power cord is not pinched or damaged. Use only the provided power adapter.
- Do not overload the desk converter. Refer to the 'Specifications' section for weight capacities.
- Place the desk converter on a stable, level surface.
- Disconnect power before cleaning or performing any maintenance.
- This product is intended for indoor use only.

3. PACKAGE CONTENTS

Carefully unpack the box and ensure all items listed below are included:

- FLEXISPOT Electric Standing Desk Converter Main Unit
- Quick Release Keyboard Tray
- Power Adapter and Cable
- Cable Management Clips/Ties
- User Manual (this document)

4. SETUP AND ASSEMBLY

The FLEXISPOT Electric Standing Desk Converter is designed for quick and easy assembly. Most of the unit comes pre-assembled.

1. **Connect the Keyboard Tray:** Locate the quick-release keyboard tray. Align the tray's connectors with the slots on the underside of the main desktop plate. Slide the keyboard tray into place until it clicks securely. Ensure the levers are locked down to prevent movement.
2. **Position the Converter:** Place the assembled desk converter on your existing desk or workstation. Ensure it is centered and stable.
3. **Connect Power:** Plug the power adapter into the desk converter's power input port, then plug the adapter into a standard electrical outlet.
4. **Cable Management:** Use the provided cable management clips or ties to organize your monitor, laptop, and power cables, ensuring they do not interfere with the desk converter's movement.



Image: A visual guide illustrating the two simple steps for assembly: attaching the keyboard tray and positioning the converter on your desk.

5. OPERATING INSTRUCTIONS

The FLEXISPOT desk converter features an electric lift system for smooth height adjustments.

5.1 Adjusting Height

Locate the control panel, typically on the right side of the desktop. It features up and down arrow buttons.

- To raise the desk converter, press and hold the **UP** arrow button. The desk will smoothly ascend.
- To lower the desk converter, press and hold the **DOWN** arrow button. The desk will smoothly descend.
- Release the button at your desired height. The electric motor provides a quiet and stable transition.



Image: The control panel with intuitive up and down buttons for seamless sit-stand transitions, highlighting the ease of height adjustment.

5.2 Patented Bracing System

This desk converter is engineered with a patented bracing system that ensures smooth and even operation throughout its height range. This design prevents the common issue of risers crashing onto the desktop when lowering, providing a stable experience for your equipment.



Image: An internal view highlighting the electric motor, which facilitates labor-saving and vertical lifting for effortless height adjustments.

6. MAINTENANCE

Regular maintenance will help prolong the life and performance of your FLEXISPOT desk converter.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Inspection:** Periodically check all screws and connections to ensure they are tight.
- **Cable Management:** Ensure cables remain neatly organized and do not obstruct the movement of the desk.
- **Motor Care:** The electric motor is designed for durability. Avoid continuous operation for extended periods without rest.

7. TROUBLESHOOTING

If you encounter issues with your desk converter, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Desk does not move.	No power, loose connection, or motor protection activated.	Check if the power cable is securely plugged into the wall outlet and the desk converter. Try a different outlet. Unplug for 10 minutes to reset motor protection.
Desk moves unevenly or makes unusual noises.	Overload, obstruction, or loose components.	Ensure the weight on the desk does not exceed the maximum capacity. Check for any obstructions. Verify all assembly screws are tight.
Keyboard tray is wobbly.	Keyboard tray not fully secured.	Ensure the keyboard tray is fully slid into its slots and the locking levers are engaged.

If the problem persists after attempting these solutions, please contact FLEXISPOT customer support.

8. PRODUCT SPECIFICATIONS

- **Model:** EM7

- **Color:** Black
- **Material:** Alloy Steel, Engineered Wood
- **Product Dimensions (L x W x H):** 40 x 24.1 x 5.7 inches (minimum height)
- **Height Adjustment Range:** 5.7" to 19.7"
- **Desktop Load Capacity:** 44 lbs
- **Keyboard Tray Load Capacity:** 11 lbs
- **Total Combined Weight Capacity:** 55 lbs
- **Item Weight:** 46.3 pounds (21.03 Kilograms)
- **Number of Levels:** 2
- **Assembly Required:** Minimal (Yes)
- **Special Feature:** Electric Lift




Image: Detailed diagram illustrating the key dimensions of the desk converter, including desktop and keyboard tray load capacities.

9. WARRANTY & SUPPORT





FLEXISPOT products are manufactured with quality and durability in mind. For specific warranty information and

customer support, please refer to the warranty card included with your product or visit the official FLEXISPOT website.

For technical assistance, replacement parts, or general inquiries, please contact FLEXISPOT customer service through their official channels.

© 2024 FLEXISPOT. All rights reserved.

Related Documents

	FlexiSpot EM7L Motorized Computer Riser Installation Guide Comprehensive installation guide for the FlexiSpot EM7L Motorized Computer Riser. Features include specifications, parts list, step-by-step assembly instructions, troubleshooting tips, and limited warranty information.
	FlexiSpot E4B/E4W Electric Standing Desk User Manual Comprehensive user manual for the FlexiSpot E4B/E4W electric standing desk, covering specifications, assembly instructions, keypad operation, troubleshooting, and warranty information.
	FlexiSpot EG8B/EG8W Installation Guide and Limited Warranty This document provides a comprehensive installation guide and limited warranty information for the FlexiSpot EG8B/EG8W adjustable standing desk. It details specifications, assembly steps, keypad operation, troubleshooting, safety precautions, and warranty terms.
	FlexiSpot E7B/E7W/E7S-Plus Height Adjustable Desk User Manual & Installation Guide Detailed user manual for FlexiSpot E7B-Plus, E7W-Plus, and E7S-Plus height adjustable desks. Includes technical specifications, step-by-step installation instructions, handset operation, troubleshooting guide, and warranty information.

Documents - FLEXISPOT – EM7



[pdf] Catalog

Descargar CatálogoProductos a medida FantiniCatalogo Fantini 2024 MEDIAcdn shopify s files 1 0081 5664 3446 Catalogo MEDIA |||

HOME AND OFFICE Mobiliario con Diseo Soluciones para oficinas, comercios y hogares, adaptadas a las ... oria. Pantalla Led. Soporta hasta 100kg de carga. Rango de altura: 70cm - 119cm. Soporte de Monitor **EM7** Soporta hasta 44 lbs en bandeja superior y hata 11 lbs en la bandeja inferior. Altura ajustable ...

lang:es score:9 filesize: 7.42 M page_count: 40 document date: 2024-08-30

