

[Manuals.plus](#) /

› [Easysleep](#) /

› Easysleep White Noise Machine User Manual

Easysleep IS05

Easysleep White Noise Machine User Manual

MODEL: IS05

For Sleeping and Relaxation

1. Introduction

Thank you for choosing the Easysleep White Noise Machine. This device is designed to create a peaceful and relaxing environment, aiding in sleep, relaxation, and focus. It features 25 non-looping soothing sounds, an adjustable night light, 32 levels of volume control, and a convenient timer function. Its compact design makes it ideal for home, office, or travel use. This manual provides detailed instructions for setup, operation, and maintenance to ensure optimal performance and longevity of your device.



Figure 1: Easysleep White Noise Machine - Top View

2. Product Overview

2.1 Components

- Easysleep White Noise Machine Unit
- AC Power Adapter
- USB Cable
- User Manual (this document)

2.2 Control Panel and Functions

The control panel is located on the top surface of the device. Refer to the diagram below for button identification and their respective functions.

Your browser does not support the video tag.

Video 1: Official product video demonstrating the features and operation of the Easysleep Sound Machine, including sound selection, volume control, and night light functions.

Table 1: Control Button Functions

Button Icon	Function	Description
(Power)	On/Off Button	Press to turn the device on or off.
- (Minus)	Volume Down Button	Decreases the volume level.
+ (Plus)	Volume Up Button	Increases the volume level.
(Previous)	Last Track Button	Cycles to the previous sound.
(Next)	Next Track Button	Cycles to the next sound.
(Lightbulb)	Night Light On/Off/Brightness Button	Press to turn the night light on/off. Press and hold for 2 seconds to adjust brightness.
(Timer)	Timer Button	Sets the auto-off timer (60, 120, 180, 240 minutes, or continuous play).

3. Setup

To set up your Easysleep White Noise Machine, follow these steps:

1. Unpack the noise machine and all accessories from its packaging.
2. Connect the provided USB cable to the machine's power input port.
3. Connect the other end of the USB cable to the AC power adapter, or directly to a compatible USB power source (e.g., computer USB port, power bank).
4. Plug the AC power adapter into a standard electrical outlet.
5. Place the machine on a stable, flat surface in your desired location.

4. Operating Instructions

4.1 Power On/Off

- To turn on the device, press the **Power On/Off** button ().
- To turn off the device, press the **Power On/Off** button () again.

4.2 Sound Selection

The Easysleep White Noise Machine offers 25 non-looping soothing sounds, including white noise, fan sounds, brook, sea waves, bird, bonfire, train, piano, lullabies, and meditation. To select a sound:

- Press the **Next Track** button () to cycle through the available sounds in forward order.
- Press the **Last Track** button () to cycle through the available sounds in reverse order.



Figure 2: Variety of 25 Soothing Sounds

4.3 Volume Adjustment

The device features 32 levels of volume control. To adjust the volume:

- Press the **Volume Up** button (+) to increase the volume.
- Press the **Volume Down** button (-) to decrease the volume.

4.4 Night Light Function

The integrated night light provides a warm glow, perfect for sleeping, feeding, or reading. It has four levels of brightness.

- To turn the night light on or off, press the **Night Light On/Off/Brightness** button ().
- To adjust the brightness, press and hold the **Night Light On/Off/Brightness** button () for 2 seconds. The brightness will cycle through its levels. Release the button when the desired brightness is reached.



Figure 3: Night Light in Use

4.5 Timer Function

The machine can be set to play continuously or to automatically turn off after a set period.

- Press the **Timer** button () to cycle through the auto-off timer options: 60 minutes, 120 minutes, 180 minutes, 240 minutes, or continuous play (indicated by an infinity symbol).
- The selected timer setting will be indicated by small LED lights above the speaker grille.



Figure 4: Timer Function

The memory function will automatically restore your previous volume, sound, and timer settings when the device is turned back on.

5. Maintenance

To ensure the longevity and proper functioning of your Easysleep White Noise Machine, follow these simple maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe the exterior of the device. Do not use liquid cleaners, aerosols, or abrasive cleaning agents, as these may damage the surface or internal components.
- **Storage:** When not in use for extended periods, store the device in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Handling:** Avoid dropping the device or subjecting it to strong impacts, which could damage internal electronics.

6. Troubleshooting

If you encounter any issues with your Easysleep White Noise Machine, please refer to the following common problems and solutions:

Table 2: Common Troubleshooting Steps

Problem	Possible Cause	Solution
Device does not turn on.	No power supply or loose connection.	Ensure the power adapter is securely plugged into both the device and a working electrical outlet. Try a different outlet.
No sound or low volume.	Volume is too low or muted.	Press the Volume Up button (+) to increase the volume. Ensure a sound is selected.
Night light not working.	Night light is off or brightness is set to minimum.	Press the Night Light button () to turn it on. Press and hold to adjust brightness.
Device turns off unexpectedly.	Timer function is active.	Check the timer setting. Press the Timer button () to set it to continuous play (infinity symbol) if desired.

If the problem persists after attempting these solutions, please contact Easysleep customer support for further assistance.

7. Specifications

Table 3: Product Specifications

Feature	Detail
Product Dimensions	Approx. 3.9 x 3.9 x 2.3 inches; 6.7 ounces
Item Model Number	IS05
Brand	Easysleep
Power Source	Corded Electric (AC or USB)
Sound Options	25 Non-Looping Soothing Sounds
Volume Levels	32 Levels
Night Light	Adjustable Warm Light (4 levels)
Timer Options	60, 120, 180, 240 minutes, Continuous Play
Certifications	ETL, FCC, CE, RoHS Approved

8. Warranty and Support

8.1 Warranty Information

The Easysleep White Noise Machine comes with an **18-month warranty** from the date of purchase. This warranty covers manufacturing defects and issues arising from normal use. Please retain your proof of purchase for warranty claims.

8.2 Safety Information

Important Safety Notice: Prolonged exposure to loud noise, even white noise, can potentially damage hearing,

particularly in infants with smaller ear canals. Always use the device at appropriate volume levels.

8.3 Legal Disclaimer

Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition.

8.4 Customer Support

For any questions, concerns, or support needs regarding your Easysleep White Noise Machine, please do not hesitate to contact Easysleep customer service. Refer to the product packaging or the official Easysleep website for the most current contact information.

