**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



## Crenova DLP001

# Crenova WiFi Projector with Bluetooth

Model: DLP001 - User Manual

## 1. Introduction

Thank you for purchasing the Crenova WiFi Projector. This portable mini DLP projector is designed for versatile home entertainment and professional presentations, offering high-quality projection with convenient features. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your device.




Figure 1.1: Crenova WiFi Projector with a smartphone displaying Wi-Fi and Bluetooth symbols.

## 2. What's in the Box

Upon unboxing your Crenova projector, please ensure all the following items are present:

- Crenova WiFi Projector (DLP001)
- Power Cord
- Remote Control
- HDMI/USB Cable
- Quick User Guide

## 3. Specifications

| | |
|---|---|
| **Brand** | Crenova |
| **Model Number** | DLP001 |
| **Display Resolution** | 1920 x 1080 (1080p Supported) |

| | |
|---|---|
| **Brightness** | 170 ANSI Lumens |
| **Light Source Life** | 30,000 Hours |
| **Operating System** | Android 7.1 |
| **Battery** | 7000 mAh (Built-in) |
| **Connectivity** | Bluetooth 5.0, Wi-Fi (2.4/5 GHz), HDMI, USB, MicroSD |
| **Auto Keystone Correction** | ±45° Vertical |
| **Visible Screen Diagonal** | Up to 100 inches (254 cm) |
| **Item Weight** | 2.4 pounds |
| **Product Dimensions** | 5 x 4 x 6 inches |

## 4. Setup

### 4.1 Powering On/Off

To power on the projector, press and hold the power button on the back of the device for 5 seconds, or press the power button on the remote control. The power indicator light will illuminate. To power off, repeat the same action.

### 4.2 Focus Adjustment

Locate the focus wheel on the side of the projector. Rotate the wheel until the projected image appears clear and sharp on your screen or surface.

### 4.3 Connectivity

The Crenova projector offers multiple connectivity options:

- **HDMI:** Connect external devices such as laptops, gaming consoles (PS4), or media players using the provided HDMI cable. Select the HDMI input from the main menu.
- **USB/MicroSD:** Insert USB drives or MicroSD cards into the respective slots to access media files directly.
- **Bluetooth 5.0:** Pair with external Bluetooth speakers for enhanced audio experience. Navigate to the Bluetooth settings in the main menu to connect.
- **Wi-Fi:** Connect to your local Wi-Fi network (2.4/5 GHz) to access built-in streaming apps and online content.
- **Screen Mirroring:** Supports wireless screen mirroring via Airplay, EShare, and iOS/Android Mirror for seamless content sharing from your smartphone or tablet.




Figure 4.1: The projector offers extensive connectivity options including HDMI, USB, and wireless mirroring.




Figure 4.2: Wireless screen mirroring is supported for Android, iOS, and Windows devices.

## 5. Operating Instructions

### 5.1 Main Menu Navigation

Upon powering on, the projector will display its main menu interface. Use the remote control to navigate through options such as YouTube, Netflix, Aptoide TV, Wi-Fi, Bluetooth, Explorer, Settings, HDMI, EShare, iOS Mirror, APPS, and WPS Projector.




Figure 5.1: The main menu provides quick access to various streaming applications and settings.

### 5.2 Streaming Applications

The projector comes with popular streaming applications pre-installed or available for download via the Google Play Store (accessible through the APPS menu). Connect to Wi-Fi and log in to your accounts to enjoy content from platforms like Netflix, YouTube, Amazon Prime Video, Disney+, and Hulu.

### 5.3 External Device Projection

To project content from an external device, connect it to the projector via the HDMI port. Select the HDMI input option from the main menu. This allows projection from gaming consoles, PCs, and other HDMI-compatible devices.

### 5.4 Wireless Presentation System (WPS)

The WPS Projector feature allows for wireless presentations, ideal for business or educational environments. Refer to the Quick User Guide for detailed instructions on setting up and utilizing this function.

## 6. Maintenance

To ensure the longevity and optimal performance of your Crenova projector, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the projector. For the lens, use a specialized lens cleaning cloth and solution to avoid scratches.
- **Ventilation:** Ensure the projector's ventilation vents are clear and unobstructed to prevent overheating. Do not place the projector on soft surfaces that may block airflow.
- **Storage:** When not in use for extended periods, store the projector in a cool, dry place, away from direct sunlight and extreme temperatures.

## 7. Troubleshooting

If you encounter issues with your projector, refer to the following common troubleshooting steps:

- **No Picture:** Check power connections, ensure the correct input source is selected (HDMI, USB, etc.), and verify the focus adjustment.
- **Blurred Image:** Adjust the focus wheel. Ensure the projection surface is flat and the projector is positioned correctly for automatic keystone correction.
- **Connectivity Issues:** For Wi-Fi, ensure the network password is correct and the signal is strong. For Bluetooth, ensure the external device is in pairing mode and within range.
- **No Sound:** Check the volume settings on the projector and any connected external audio devices. Ensure external speakers are properly connected via Bluetooth or the 3.5mm audio out port.

For further assistance, please refer to the Quick User Guide or contact customer support.

## 8. Warranty and Support

The Crenova WiFi Projector comes with a**1-year warranty** from the date of purchase. This warranty covers manufacturing defects and ensures product reliability.

For technical support, warranty claims, or any inquiries, please contact Crenova customer service:

- **Email:** service@crenova.net

Please retain your proof of purchase for warranty validation.

© 2023 Crenova. All rights reserved.

### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**

---

**Open the live page**

**https://manuals.plus/asin/B087D34Q4W**

More documents and user manuals: **https://manuals.plus/**