XZL Y11S-BLACK

XZL Wireless Bluetooth Karaoke Microphone

Model: Y11S-BLACK - User Manual

Introduction

Thank you for choosing the XZL Wireless Bluetooth Karaoke Microphone. This versatile device combines a microphone and speaker into one portable unit, perfect for karaoke, music playback, and recording. Its user-friendly design and multiple connectivity options ensure an enjoyable experience for all ages.



The XZL Wireless Bluetooth Karaoke Microphone, showcasing its design and available color variants.

Setup

Charging the Microphone

The microphone is powered by a 3000 mAh Lithium Ion rechargeable battery. Before first use, fully charge the device using the provided USB charging cable. Connect the micro-USB end of the cable to the charging port at the bottom of the

microphone and the USB-A end to a compatible 5V USB power source (e.g., computer USB port, wall adapter).


Hi-Fi STEREO SOUND
superior bass boost clear treble performance
ON/OFF
MIC VOL
Reverb
Duet Mode
M/⏯
⏮
⏭
V-
V+
WORKING 8 HOURS
3000 mAh rechargeable battery

The microphone features a 3000 mAh rechargeable battery for extended use.

Initial Connection

1. **Power On:** Press and hold the ON/OFF button located on the control panel until the device powers on. A voice prompt will indicate its status.
2. **Bluetooth Pairing:** On your mobile device (smartphone, tablet, etc.), enable Bluetooth and search for available devices. Select "Y11S" from the list to pair. A voice prompt will confirm successful connection.
3. **Audio Cable Connection:** For devices without Bluetooth, use the provided 3.5mm audio cable. Connect one end to the microphone's 3.5mm jack and the other end to your device's audio output.
4. **TF Card Mode:** Insert a TF (MicroSD) card (up to 32GB, not included) into the TF card slot for direct music playback.

Operating Instructions

Control Panel Overview



Detailed view of the microphone's control panel and ports.

- **ON/OFF:** Press and hold to power on/off.
- **MIC VOL:** Adjusts the microphone's volume.
- **Duet Mode:** Activates duet singing mode (requires two Y11S microphones).
- **Echo/Reverb:** Adjusts the echo effect on your voice.
- **Play/Pause:** Plays or pauses music playback.
- **Previous/Next:** Skips to the previous or next track.
- **Vocal Remover:** Removes vocals from a song, turning it into an instrumental track for karaoke.
- **V+/V-:** Adjusts the overall music volume.

Key Features and Modes

- **Bluetooth 5.0 Technology:** Ensures stable and fast wireless connection.
- **Hi-Fi Stereo Sound:** Provides superior bass boost and clear treble performance.
- **360° Stereo Surround Sound:** Delivers an immersive audio experience.
- **Genuine Leather Handle Design:** Offers a comfortable and secure grip, preventing sweat.
- **DSP Technology:** Enhances echo reverberation for a professional sound.
- **3-Layers Noise Reduction:** Built-in sponge layers reduce unwanted noise for clearer vocals.




The microphone supports multiple functions and connectivity options.

Versatile Usage

The XZL Karaoke Microphone is designed for various applications:

- **Karaoke Machine:** Connect to your device and sing along to your favorite tracks.
- **Bluetooth Speaker:** Use it as a portable speaker to play music from your phone or other Bluetooth-enabled devices.
- **Music Player:** Play music directly from a TF card.
- **Sound Recorder:** Record your singing or voice directly to a connected device or TF card.
- **Song Practice:** Utilize the vocal remover feature to practice singing with instrumental versions of songs.



The microphone is suitable for various entertainment and practice scenarios.

Specifications

Feature	Detail
Model	Y11S-BLACK
Microphone Form Factor	Handheld
Polar Pattern	Unidirectional
Connectivity Technology	Bluetooth 5.0
Connector Type	USB, 3.5 mm Jack
Power Source	Battery Powered (1 Lithium Ion battery required)
Battery Capacity	3000 mAh
Charging Voltage	5V
Frequency Range	0.1 kHz - 10 kHz
Noise Level	115 dB
Item Weight	1.6 pounds
Product Size	3.1 x 11.3 inches

Maintenance

To ensure the longevity and optimal performance of your microphone, follow these maintenance guidelines:

- Keep the device dry and away from moisture.
- Clean the exterior with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials.
- Store in a cool, dry place when not in use, preferably in its portable case.
- Avoid dropping or subjecting the microphone to strong impacts.

Troubleshooting

- **No Power:** Ensure the battery is charged. Connect the microphone to a power source using the USB cable.
- **Cannot Pair Bluetooth:** Make sure the microphone is in pairing mode (blinking light). Turn off and on your device's Bluetooth, then try searching again. Ensure no other devices are currently connected to the microphone.

- **No Sound from Speaker:** Check the microphone's volume controls (MIC VOL, V+/V-). Ensure your connected device's volume is also turned up. Verify the audio cable is securely connected if using wired mode.
- **Poor Sound Quality/Feedback:** Ensure the microphone is not too close to the speaker. Adjust the Echo/Reverb setting. Check for obstructions on the microphone mesh.

Warranty and Support

This product comes with a warranty. Please refer to the included warranty card for details on coverage and how to register your product for free warranty support. For any technical assistance or inquiries, please contact XZL customer support through the contact information provided on the warranty card or the official product website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question