



Manuals.plus /

› ZdalaMit /

› ZdalaMit RM-AAU029 Replacement Remote Control Instruction Manual

ZdalaMit RM-AAU029

Instruction Manual

ZdalaMit RM-AAU029 Replacement Remote Control

1. INTRODUCTION

This manual provides comprehensive instructions for the operation and maintenance of your ZdalaMit RM-AAU029 Replacement Remote Control. This remote is designed as a direct replacement for specific Sony Sound Bar Systems, ensuring seamless functionality without the need for complex setup procedures. Please read this manual thoroughly before use to ensure proper operation and to maximize the lifespan of your device.

2. PRODUCT OVERVIEW

The ZdalaMit RM-AAU029 is a replacement remote control specifically designed for compatibility with Sony Sound Bar Systems. It replicates the functions of the original remote, providing control over various aspects of your sound system. This remote is compatible with the following Sony Sound Bar System models:

- HT-CT100
- SS-MCT100
- SA-WCT100
- HTCT100
- SSMCT100
- SAWCT100

It operates using infrared technology and requires two AA alkaline batteries for power.



Figure 2.1: Front view of the ZdalaMit RM-AAU029 replacement remote control, showing all buttons and layout.



Figure 2.2: Angled view of the ZdalaMit RM-AAU029 replacement remote control, highlighting its ergonomic design.

3. SETUP

The ZdalaMit RM-AAU029 remote control is designed for immediate use with compatible Sony Sound Bar Systems. No programming or pairing procedures are required.

3.1 Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide open the battery compartment cover.
3. Insert two (2) new 1.5V AA alkaline batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Close the battery compartment cover securely.

Important: Use only new 1.5V AA alkaline batteries. Do not use rechargeable batteries, as they may not provide sufficient power or may cause damage to the remote. Batteries are not included with the remote control.

4. OPERATING INSTRUCTIONS

Once batteries are installed, the remote is ready for use. Point the remote control directly towards your Sony Sound Bar System and press the desired function button.

4.1 Basic Functions

- **Power On/Off:** Press the **I/O** button to turn the sound bar system on or off.
- **Volume Control:** Use the **MASTER VOL +** and **-** buttons to adjust the overall volume.
- **Input Selection:** Use buttons like **TV INPUT**, **BD**, **DVD**, **SAT**, **DMPORT** to select the audio input source.
- **Muting:** Press the **MUTING** button to temporarily silence the audio output.

4.2 Navigation and Menu Control

- **Directional Buttons (Arrows):** Use the **Up**, **Down**, **Left**, **Right** arrow buttons for navigating menus and selections.
- **ENTER Button:** Press the **ENTER** button to confirm a selection.
- **MENU/HOME:** Access the main menu or home screen of your sound bar system.
- **RETURN/EXIT:** Go back to the previous screen or exit a menu.

4.3 Playback Controls

- **Play/Pause:** Use the **Play** and **Pause** buttons for media playback control.
- **Stop:** Press the **Stop** button to end playback.
- **Skip/Fast Forward/Rewind:** Use the **Skip** and **Replay/Advance** buttons for track navigation or fast-forward/rewind.

Refer to your Sony Sound Bar System's original manual for specific functions of each button, as the remote replicates the original layout and functionality.

5. MAINTENANCE

Proper care and maintenance will ensure the longevity and optimal performance of your remote control.

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners, sprays, or abrasive materials, as they may damage the surface or internal components.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new ones.
- **Storage:** If the remote will not be used for an extended period, remove the batteries to prevent leakage and potential damage.
- **Avoid Exposure:** Keep the remote away from direct sunlight, heat sources, moisture, and extreme temperatures. Do not drop the remote or subject it to strong impacts.

6. TROUBLESHOOTING

If you experience issues with your remote control, please refer to the following troubleshooting steps:

Problem	Possible Cause	Solution
Remote is not working.	Batteries are dead or incorrectly installed.	Replace with new 1.5V AA alkaline batteries, ensuring correct polarity (+/-).
Remote has limited range or intermittent response.	Low battery power; Obstruction between remote and sound bar; Remote not pointed directly at sound bar.	Replace batteries. Remove any obstructions. Ensure direct line of sight to the sound bar's IR receiver.
Certain buttons do not function.	Remote is not compatible with your specific sound bar model; Button malfunction.	Verify your sound bar model is listed as compatible (HT-CT100, SS-MCT100, SA-WCT100, etc.). If compatible, contact support.
Remote feels sticky or buttons are hard to press.	Dirt or debris accumulation.	Clean the remote surface with a soft, dry cloth. Avoid liquid cleaners.

If the problem persists after attempting these solutions, please contact customer support for further assistance.

7. SPECIFICATIONS

Feature	Detail
Model Number	RM-AAU029
Brand	ZdalaMit
Compatible Devices	Sony Sound Bar Systems (HT-CT100, SS-MCT100, SA-WCT100, HTCT100, SSMCT100, SAWCT100)
Connectivity Technology	Infrared (IR)
Power Supply	2 x 1.5V AA Alkaline Batteries (not included)
Product Dimensions (L x W x H)	6.8 x 1.6 x 0.6 inches (approximately)
Item Weight	1.41 ounces (approximately)
Special Feature	Ergonomic design
Max Number of Supported Devices	1

8. SUPPORT

For any queries, technical assistance, or further support regarding your ZdalaMit RM-AAU029 Replacement Remote Control, please do not hesitate to contact our customer support team. We are committed to providing prompt and helpful assistance.

Please refer to the contact information provided with your purchase or visit the ZdalaMit official website for support details.