



Manuals.plus /

› MAIDeSITe /

› MAIDeSITe T2 Pro Plus Dual Motor Electric Standing Desk Frame User Manual

## MAIDeSITe T2 Pro Plus

# MAIDeSITe T2 Pro Plus Dual Motor Electric Standing Desk Frame User Manual

Model: T2 Pro Plus

## 1. INTRODUCTION

This manual provides essential instructions for the safe and efficient assembly, operation, and maintenance of your MAIDeSITe T2 Pro Plus Dual Motor Electric Standing Desk Frame. Please read this manual thoroughly before use and retain it for future reference.

The MAIDeSITe T2 Pro Plus is a height-adjustable electric standing desk frame featuring a powerful dual-motor system for smooth and quiet operation. It is designed to support various desktop sizes and promote a healthier work environment by allowing seamless transitions between sitting and standing positions.

## 2. SAFETY INSTRUCTIONS

- Ensure all components are securely fastened before use.
- Keep children and pets away from the desk during operation.
- Do not overload the desk. The maximum weight capacity is 125 kg.
- Ensure there are no obstructions in the desk's path during height adjustment.
- Do not sit or stand on the desk frame.
- Disconnect power before cleaning or maintenance.
- Use only the provided power adapter.
- The desk features an anti-collision system. Do not attempt to override it.
- The control panel includes a child lock function for safety.

## 3. PACKAGE CONTENTS

Verify that all components are present and undamaged before beginning assembly.

- MAIDeSITe T2 Pro Plus Desk Frame (legs, crossbar, feet)

- Control Panel with Smart Keyboard
- Dual Motor System
- Power Adapter and Cables
- Assembly Hardware (screws, tools if included)
- Instruction Manual (this document)

*Note: Desktop surface is sold separately.*

## 4. SETUP AND ASSEMBLY

---

Assembly typically requires two people. Ensure you have adequate space and the necessary tools (e.g., screwdriver, hex keys, if not provided).

### 4.1 Unpacking

Carefully remove all components from the packaging. Lay them out on a clean, soft surface to prevent scratches.

### 4.2 Frame Assembly

1. Attach the feet to the bottom of each leg column using the provided screws.
2. Connect the crossbar to the leg columns. Ensure proper alignment and secure all screws.
3. Install the dual motors into the designated slots within the frame structure.
4. Connect all motor and control panel cables to the main control box, ensuring they are routed neatly to avoid interference with movement.

# 30% Larger Adjustable Range

Bigger range, more DIY options, create a unique space

Standing Desk Frame

Best Seller

01/2024

[amazon.co.uk](https://amazon.co.uk)




Image: Overview of the MAIDeSITe T2 Pro Plus desk frame components, showing the legs, crossbar, and motor housing. This image illustrates the main parts before assembly.

## 4.3 Attaching the Desktop

Position your chosen desktop (not included) onto the assembled frame. Ensure it is centered and aligned. Mark the screw holes on the underside of the desktop. Drill pilot holes if necessary, then secure the desktop to the frame using appropriate screws.

# MAIDeSITE T2 Pro Plus



Image: A fully assembled MAIDeSITE T2 Pro Plus desk frame with a wooden desktop attached, ready for use. This shows the complete product setup.

## 4.4 Cable Management

Route all cables (power, control panel, and any peripheral cables) using the integrated cable management features or cable ties to prevent snagging during height adjustments. This ensures smooth operation and a tidy workspace.

## 5. OPERATING INSTRUCTIONS

### 5.1 Control Panel Overview

The MAIDeSITe T2 Pro Plus features a multi-function control panel with an LCD display, up/down buttons, memory presets, a sit-stand reminder, child lock, and a USB charging port.



Image: Close-up of the MAIDeSITe T2 Pro Plus smart control panel, showing the LCD display, up/down arrows, memory buttons (1, 2, 3, 4), 'SET' button, 'ON/OFF' button, and USB charging port. This highlights the user interface.

## 5.2 Adjusting Height

- Press and hold the **Up** (^) or **Down** (v) button to move the desk to your desired height. Release the button to stop.
- The LCD display will show the current height in centimeters.

## 5.3 Setting Memory Presets

The control panel allows you to save up to four preferred height settings.

1. Adjust the desk to the desired height.
2. Press the **'SET'** button. The display will flash.
3. Immediately press one of the memory buttons (**'1'**, **'2'**, **'3'**, or **'4'**) to save the current height to that position.
4. To recall a saved height, simply press the corresponding memory button. The desk will automatically move to that position.

## 5.4 Sit-Stand Reminder

To activate the sit-stand reminder:

1. Press the **'SET'** button.
2. Use the **Up (^)** or **Down (v)** buttons to cycle through reminder intervals (0.5h, 1h, 2h).
3. Press **'SET'** again to confirm your selection. The desk will beep to remind you to change position after the set interval.

## 5.5 Child Lock Function

To activate the child lock, press and hold the **'M'** button for 3 seconds. The display will show a lock icon. To deactivate, press and hold the **'M'** button again for 3 seconds.

## 5.6 Anti-Collision System

The desk is equipped with an anti-collision system. If the desk encounters an obstruction during adjustment, it will automatically stop and reverse slightly to prevent damage. Ensure the area around the desk is clear before operation.

# 6. MAINTENANCE

- **Cleaning:** Disconnect the power before cleaning. Wipe the desk frame with a soft, damp cloth. Avoid abrasive cleaners or solvents.
- **Inspection:** Periodically check all screws and connections to ensure they are tight. Retighten if necessary.
- **Cable Management:** Ensure cables remain tidy and are not pinched or tangled, especially during height adjustments.
- **Lubrication:** The motors and lifting columns are designed for maintenance-free operation and do not require lubrication.

# 7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Desk does not move.	Power cable disconnected, child lock active, overload.	Check power connection. Deactivate child lock. Reduce weight on desk.
Desk moves unevenly or makes unusual noise.	Loose connections, obstruction, uneven weight distribution.	Check all screws and connections. Clear any obstructions. Redistribute weight evenly.
Anti-collision system triggers frequently.	Obstruction in path, sensitive setting.	Ensure clear path. Refer to control panel settings for sensitivity adjustment (if available).
Memory presets not working.	Not saved correctly.	Re-save the memory presets following the instructions in Section 5.3.


If the problem persists after attempting these solutions, please contact MAIDeSiTe customer support.

## 8. SPECIFICATIONS

---

- **Model:** T2 Pro Plus
- **Brand:** MAIDeSiTe
- **Type:** 3-Stage Dual Motor Electric Standing Desk Frame
- **Height Adjustment Range:** 62 cm - 125 cm
- **Frame Width Adjustment Range:** 100 cm - 180 cm
- **Recommended Desktop Width:** 100 cm - 220 cm
- **Recommended Desktop Depth:** 60 cm - 100 cm
- **Lifting Speed:** 40 mm/s
- **Noise Level:** < 45 dB
- **Maximum Weight Capacity:** 125 kg
- **Material:** 100% High-Quality Industrial Carbon Steel
- **Features:** 4 Memory Presets, Sit-Stand Reminder, Child Lock, Anti-Collision System, USB Charging Port
- **Certifications:** TÜV RHEINLAND, UKCA
- **Item Weight:** 29 kg

# Maidesite, Best Choice !



 **Maidesite**

**Other**

**Cable Management Tray**



**Non-Porous Craft**



**Heavy-duty Foot**



**Triangle Stable Structure**



**Thick and Robust Column**



Image: Diagram illustrating the adjustable range of the MAIDeSITE T2 Pro Plus desk frame, showing a height range of 62 cm to 125 cm and a width range of 100 cm to 180 cm, along with recommended desktop dimensions.

# Exceptional Performance



**20000<sup>+</sup>**  
times tested



**Extended**  
lifespan

# 160KG



Image: Illustration highlighting the powerful dual motor system of the MAIDeSITE T2 Pro Plus, emphasizing its two motors, faster adjustment speed of 40mm/s, and quiet operation at less than 45dB.



# Superior Craftsmanship



Triangle  
Stable Structure



Eco-friendly  
Layer

 **Prüfungel**  
The German Institute for  
Product Testing

**Certified  
Quality**

Test period: 08/24

Company name:  
**MAIDESITE**

Product name:  
**Desk frame**

License number: 240809001  
[www.pruefungel.de/hohenverstellbarer-schreibtisch-maidesite](http://www.pruefungel.de/hohenverstellbarer-schreibtisch-maidesite)



Image: Illustration highlighting the superior craftsmanship of the MAIDeSITe T2 Pro Plus, featuring a triangle stable structure and certified quality (TÜV Rheinland, UKCA). This image emphasizes the structural integrity and quality standards.

# Smart Touch Bedienfeld



Up and Down



Memory 1/2/3/4



Sit-stand Reminder



Child Safety Lock



USB Charging Port



LCD Display

Image: Visual representation of the MAIDeSITE T2 Pro Plus's performance, indicating over 20,000 tests for extended lifespan. While the image shows '160KG', the official product specifications state a maximum weight capacity of 125 kg. Please adhere to the 125 kg limit for optimal performance and safety.

## 9. WARRANTY AND SUPPORT

MAIDeSITE provides comprehensive warranty and technical support for your T2 Pro Plus desk frame.

- **Desk Frame Warranty:** 5 years
- **Motor Warranty:** 3 years
- **Technical Support:** Lifetime technical support and installation guidance.

- **Return Policy:** 90-day unconditional return policy.
- **Customer Service:** 24-hour customer service.

For any questions, assistance, or warranty claims, please contact MAIDeSITE customer service through your purchase platform or the official MAIDeSITE website.

