

[Manuals.plus](#) /

› [A-Tech](#) /

› A-Tech 16GB (2x8GB) DDR3 1333MHz DIMM Memory Upgrade Kit Instruction Manual for Dell Inspiron 620 and 620s

A-Tech 16GB (2x8GB) DDR3 1333MHz DIMM

A-Tech 16GB (2x8GB) DDR3 1333MHz DIMM Memory Upgrade Kit Instruction Manual

For Dell Inspiron 620 and 620s Desktop Computers

1. INTRODUCTION

This manual provides instructions for installing and maintaining your A-Tech 16GB (2x8GB) DDR3 1333MHz DIMM memory upgrade kit. This kit is specifically designed for use with Dell Inspiron 620 and 620s desktop computer models. Proper installation ensures optimal performance and system stability.






Image 1.1: A-Tech 16GB DDR3 RAM kit in its retail packaging, showing two 8GB modules.

2. PRODUCT OVERVIEW AND SPECIFICATIONS

The A-Tech 16GB memory kit consists of two 8GB DDR3 DIMM modules. These modules are designed to enhance your computer's multitasking capabilities and overall system responsiveness.



Image 2.1: Two A-Tech 8GB DDR3 RAM modules, removed from packaging.

2.1. Technical Specifications

Feature	Detail
Capacity	16GB (2x 8GB Modules)
Type	DDR3 DIMM 240-Pin
Speed	1333MHz (PC3-10600 / PC3-10600U)
Rank	2Rx8 (Dual Rank x8)
ECC Type	Non-ECC Unbuffered (UDIMM)
Voltage	1.5V
Compatible Devices	Dell Inspiron 620, Dell Inspiron 620s




Image 2.2: Standard dimensions for a DDR3 DIMM module.

3. INSTALLATION GUIDE

Before beginning the installation, ensure you have read and understood all steps. Improper installation can damage your computer components. If you are unsure about any step, consult a qualified technician.

3.1. Safety Precautions

- **Power Off:** Completely shut down your computer and unplug it from the power outlet.
- **Ground Yourself:** Discharge any static electricity by touching a grounded metal object (e.g., the metal chassis of your computer) before handling components. Consider using an anti-static wrist strap.
- **Handle with Care:** Hold the RAM modules by their edges, avoiding contact with the gold connectors or the chips.

3.2. Step-by-Step Installation

1. **Open the Computer Case:** Remove the side panel of your Dell Inspiron 620 or 620s desktop computer to access the motherboard. Refer to your computer's specific manual for instructions on opening the case.
2. **Locate RAM Slots:** Identify the DDR3 DIMM slots on your motherboard. These are typically long slots near the CPU. Your Dell Inspiron 620/620s will have multiple slots.
3. **Prepare Slots (if replacing):** If you are replacing existing RAM, gently push down the small clips on both ends of the RAM slot to release the module. Carefully remove the old module.
4. **Align the Module:** Take one A-Tech 8GB DDR3 DIMM module. Observe the notch on the bottom edge of the module. Align this notch with the corresponding key in the RAM slot. The module will only fit one way. Do not force

it.

5. **Insert the Module:** With the module correctly aligned, place it into the slot. Apply even pressure to both ends of the module until it clicks into place. The clips on the ends of the slot should automatically snap upwards to secure the module. If they do not, gently push them up until they lock.
6. **Install Second Module:** Repeat steps 4 and 5 for the second A-Tech 8GB DDR3 DIMM module, installing it into the next available or designated slot for dual-channel operation (consult your Dell Inspiron manual for optimal slot configuration).
7. **Close the Computer Case:** Once both modules are securely installed, reattach the side panel of your computer.
8. **Reconnect Power:** Plug your computer back into the power outlet.

4. OPERATING YOUR SYSTEM WITH NEW MEMORY

After installation, power on your computer. The system should automatically detect the new memory. You may observe a slightly longer boot time on the first startup as the system initializes the new hardware. Once booted, you can verify the installed memory:

- **Windows:** Right-click on "This PC" or "My Computer," select "Properties." The "Installed RAM" or "Memory" value should reflect the total installed memory (e.g., 16.0 GB).
- **BIOS/UEFI:** Access your system's BIOS/UEFI settings during startup (usually by pressing F2, Del, or F12). Look for a "System Information" or "Memory" section to confirm the detected RAM.

5. MAINTENANCE

RAM modules generally require minimal maintenance. To ensure longevity and optimal performance:

- **Dust Removal:** Periodically clean the interior of your computer case to prevent dust buildup on components, including RAM modules. Use compressed air for this purpose, holding the can upright and spraying in short bursts.
- **Secure Connections:** Ensure the RAM modules remain firmly seated in their slots. Loose connections can lead to system instability.

6. TROUBLESHOOTING

If you encounter issues after installing the new memory, consider the following troubleshooting steps:

- **No Display / System Not Booting:**
 - Ensure the RAM modules are fully seated in their slots. Re-seat them by pressing down firmly until the clips lock.
 - Verify that the modules are installed in the correct slots according to your Dell Inspiron 620/620s motherboard manual for dual-channel configuration.
 - Try installing only one module at a time to identify if one of the modules is faulty.
 - Clear the CMOS (Complementary Metal-Oxide-Semiconductor) settings on your motherboard. Refer to your computer's manual for instructions on how to do this.
- **Incorrect Memory Detected:**
 - Check your system's BIOS/UEFI settings to ensure the memory is correctly recognized.
 - Ensure you have the latest BIOS/UEFI firmware for your Dell Inspiron 620/620s, as updates can improve memory compatibility.
- **System Instability / Blue Screens:**

- Run a memory diagnostic tool (e.g., Windows Memory Diagnostic) to check for errors.
- Ensure your system's power supply unit (PSU) is adequate for all installed components.

If issues persist, contact A-Tech Technical Support for further assistance.

7. WARRANTY AND SUPPORT

A-Tech provides a **Lifetime Warranty** for all memory modules. This warranty covers defects in materials and workmanship for the lifetime of the product.

For technical assistance, troubleshooting, or warranty claims, please contact A-Tech's complimentary United States based Tech Support. Contact information can be found on the official A-Tech website.



Image 7.1: A-Tech company logo.

© 2023 A-Tech. All rights reserved. Product specifications are subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B087K1S52F>

More documents and user manuals: <https://manuals.plus/>