

[Manuals.plus](#) /

› [PMD Beauty](#) /

› PMD Beauty Clean Pro Gold - Smart Facial Cleansing Device with Silicone Brush & 24K Gold ActiveWarmth Anti-Aging Massager - Waterproof - SonicGlow Vibration - Clear Pores & Blackheads Rose Instruction Manual

PMD Beauty 4002-RoseG

PMD Beauty Clean Pro Gold - Instruction Manual

Model: 4002-RoseG

INTRODUCTION

The PMD Clean Pro Gold is an advanced facial cleansing device designed to enhance your skincare routine. It integrates SonicGlow™ technology with ActiveWarmth™ heat therapy and 24K gold plating to provide a comprehensive solution for deep cleansing, anti-aging, and improved product absorption. This manual provides essential information for the proper setup, operation, and maintenance of your device.



Image: The PMD Clean Pro Gold device, showcasing its rose-colored silicone body and gold-plated massage head.

KEY FEATURES AND BENEFITS

- **SonicGlow™ Technology:** Breaks down dirt and oil from within the pores at 7,000 vibrations per minute, operating at a perfect frequency to lift, firm, and tone the skin.
- **ActiveWarmth™ Heat Therapy:** Assists in deeper absorption and effectiveness of skincare products by combining heat with SonicGlow™.
- **24K Gold Plated Massager:** Provides anti-inflammatory benefits and is known to increase elasticity and hydration.
- **Ultra-Hygienic Silicone:** Odor-resistant, hypoallergenic, and waterproof, ensuring a clean and safe experience. The brush head never needs replacing.
- **Waterproof Design:** Allows for safe use in the shower.
- **Rechargeable Battery:** Convenient and long-lasting power.
- **Ergonomic Design:** Comfortable to hold and use.
- **Self-Standing Base:** For easy storage and drying.

UNIQUE FEATURES

Pure Gold Plated
Facial Massager

Soft Silicone
Bristles

Waterproof

SonicGlow™
Power Button

ActiveWarmth™
Power Button

Ergonomic
Design

Rechargeable
Battery

Self-Standing



Image: An annotated diagram illustrating the unique features of the PMD Clean Pro Gold, including the pure gold plated facial massager, soft silicone bristles, waterproof design, SonicGlow™ power button, ActiveWarmth™ power button, ergonomic design, rechargeable battery, and self-standing capability.

SETUP

Charging the Device

Before first use, fully charge your PMD Clean Pro Gold device for 2-3 hours. The device comes with a charging cable. Connect the cable to the charging port on the device and plug the other end into a compatible USB power adapter (not included) or a USB port.

HOW TO CHARGE




Image: A visual guide demonstrating how to connect the charging cable to the PMD Clean Pro Gold device and a power source.

OPERATING INSTRUCTIONS

Daily Cleansing

1. Rinse your PMD Clean Pro Gold under warm water.
2. Apply your preferred cleanser directly to the silicone brush head.
3. Press the SonicGlow™ power button to turn on the device. You can select from two cleansing modes: Mode 1 (Gentle Vibration) or Mode 2 (Intense Vibration).
4. Move the device in circular motions, cleansing your entire face.
5. Rinse your face and the device thoroughly after use.

Anti-Aging Massage with ActiveWarmth™

1. After cleansing, apply your favorite serum or moisturizer to your skin.

2. Flip the device to the 24K gold-plated massage head.
3. Press the ActiveWarmth™ power button to activate the heat therapy. You can select from two anti-aging modes: Mode 3 (Gentle Pulsation) or Mode 4 (Intense Pulsation).
4. Gently glide the gold-plated side over your skin, massaging in your skincare products. The heat helps to open pores and improve absorption.

CUSTOMIZABLE FOR ALL SKIN TYPES



CLEANSING MODES

Mode 1 | Gentle Vibration
Mode 2 | Intense Vibration



ANTI-AGING MODES

Mode 3 | Gentle Pulsation
Mode 4 | Intense Pulsation



Image: A visual representation of the PMD Clean Pro Gold's two sides, illustrating the silicone cleansing bristles and the 24K gold-plated anti-aging massager, along with their respective cleansing and anti-aging modes.

Product Demonstration Video

Your browser does not support the video tag.

Video: An official product video demonstrating the features and usage of the PMD Clean Pro Gold, including its cleansing and anti-aging functions.

MAINTENANCE

Cleaning and Storage

Due to its ultra-hygienic silicone, the PMD Clean Pro Gold is odor-resistant and hypoallergenic. After each use, simply rinse the device under warm water with a mild soap to remove any cleanser residue. The device is fully waterproof, allowing for easy cleaning. Store the device in a clean, dry place. Its self-standing design makes it convenient to store upright.

ULTRA-HYGIENIC & WATERPROOF



Using ultra-hygienic silicone, the PMD Clean Pro Gold is odor-resistant, hypoallergenic, and waterproof.

Our hassle-free brush head **never needs replacing**.



Leave PMD Clean Pro Gold in the shower worry free.



Image: The PMD Clean Pro Gold device being rinsed under running water, demonstrating its waterproof and easy-to-clean silicone surface.

TROUBLESHOOTING

If you experience any issues with your PMD Clean Pro Gold, please consider the following:

- **Device not turning on:** Ensure the device is fully charged. Refer to the 'Charging the Device' section.
- **Weak vibrations:** The battery may be low. Charge the device.
- **Heat function not working:** Ensure the device is adequately charged and the ActiveWarmth™ button has been pressed.
- **General performance issues:** Ensure the device is clean and free from debris.

For persistent issues or concerns not addressed here, please contact PMD Beauty customer support.

SPECIFICATIONS

Attribute	Detail
Product Dimensions	2.1 x 1.3 x 6.75 inches
Item Weight	4.8 ounces
Item Model Number	4002-RoseG
Batteries	1 Lithium Ion battery (included)
Material	Silicone, Metal (24K Gold Plated)
Power Source	Battery Powered
Color	Rose

WARRANTY AND SUPPORT

PMD Beauty offers an unmatched 20-year warranty on the PMD Clean Pro Gold. For warranty claims, product support, or any inquiries, please visit the official PMD Beauty website or contact their customer service directly. Keep your proof of purchase for warranty purposes.

© 2023 PMD Beauty. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question