



Manuals.plus /

› noxgear /

› Noxgear 39g Wearable Bluetooth Speaker Instruction Manual

noxgear 39g

Noxgear 39g Wearable Bluetooth Speaker

Instruction Manual - Model: 39g

INTRODUCTION

The Noxgear 39g is an ultra-lightweight, magnetic clip-on wearable Bluetooth speaker designed for active lifestyles. It provides high-quality audio and hands-free communication, allowing you to stay aware of your surroundings while enjoying music or calls. Its durable, waterproof design ensures reliable performance in various environments.



39G

WEARABLE BLUETOOTH SPEAKER



15 HOURS
AVERAGE PLAY TIME



PATENTED DUAL-ATTACHMENT
MAGNETIC CLIP



SIMPLE CONTROL BUTTONS
FOR EVERY AUDIO ACTION



ULTRA-LIGHTWEIGHT 1.4OZ (39G)
DESIGNED FOR ACTIVE USE



DESIGNED IN OHIO



The Noxgear 39g speaker, showcasing its compact size and control buttons.

KEY FEATURES

- **Magnetic Clip-On Convenience:** Patented dual-attachment system with a secure magnetic mount and spring clip for zero-bounce comfort on clothing or gear.
- **Full Audio Control:** Dedicated buttons for play, pause, skip, volume, and digital assistant access, allowing phone-free operation.
- **Extended Playtime & Range:** Up to 15 hours of battery life and a stable 100-foot Bluetooth range.
- **Lightweight & Waterproof:** Weighs only 1.4 ounces (39g) and features an IPX7 waterproof rating, suitable for active use in all weather conditions.
- **Clear Calls & Digital Assistant:** Built-in microphone for crisp, hands-free calling and seamless access to your voice assistant.

PATENTED MAGNETIC CLIP

The only wearable speaker with a dual-attachment clip.

Clip it wherever it works for you – secure and comfortable.



The patented magnetic clip allows for secure and comfortable attachment to various apparel.

FREEDOM TO MOVE

Dedicated buttons for
total phone-free control

INTEGRATED
VOICE ASSISTANT



Enjoy audio without earbuds, keeping your ears open to your surroundings.

WHAT'S IN THE BOX

- Noxgear 39g Wearable Bluetooth Speaker
- USB charge cable

SETUP

Charging the Speaker

Before first use, fully charge your Noxgear 39g speaker. Connect the included USB charge cable to the speaker's charging port and a compatible USB power source. The LED indicator will show charging status. A full charge typically takes approximately 3 hours.



The speaker features a USB-C rechargeable port for convenient charging.

Bluetooth Pairing

1. Ensure the speaker is charged and powered off.
2. Press and hold the Power button until the LED indicator flashes, indicating pairing mode.
3. On your smartphone or tablet, navigate to the Bluetooth settings.
4. Select "Noxgear 39g" from the list of available devices.
5. Once connected, the LED indicator will show a steady light, and you will hear an audio prompt.

OPERATING INSTRUCTIONS

Controls Overview

The Noxgear 39g features intuitive buttons for easy control of your audio and calls without needing to access your phone.

SIMPLE PHONE-FREE AUDIO CONTROL

Separate buttons
for every action



Play/Pause

Volume Up/Down

Skip/Back



Play button
answers and ends calls



Double-press
activates digital assistant

Detailed view of the speaker's control buttons for phone-free operation.

- **Play/Pause Button:** Press once to play or pause audio.
- **Volume Up (+):** Press to increase volume.
- **Volume Down (-):** Press to decrease volume.
- **Next Track (>>):** Press to skip to the next song.
- **Previous Track (<<):** Press to go back to the previous song.
- **Answering/Ending Calls:** Press the Play/Pause button to answer an incoming call or end an ongoing call.
- **Activating Digital Assistant:** Double-press the Play/Pause button to activate your device's digital assistant (e.g., Siri, Google Assistant).

MAINTENANCE

Water Resistance (IPX7)

The Noxgear 39g speaker is IPX7 rated, meaning it can be submerged in up to 1 meter of water for 30 minutes. This

makes it suitable for use in rain, sweat, and showers. Ensure the charging port cover is securely closed before exposing the speaker to water.



- ✓ 5 separate buttons for every audio action, simple control
- ✓ Patented magnetic and spring clip
- ✓ Built-in mic with active noise suppression, crystal clear calls
- ✓ Ultra-lightweight 1.4 oz (39g), designed for active use
- ✓ Double-press voice assistant, hands-free commands
- ✓ US-based engineering and design



- ✗ 2-3 buttons, complicated control
- ✗ No magnetic clip, limited clip-on wearability
- ✗ No mic or muffled, echoey calls
- ✗ Heavy – bounces and tugs during use
- ✗ No access to Siri or Google
- ✗ Generic hardware, outsourced design

The IPX7 rating ensures the speaker is ready for sweat, rain, and even brief submersion.

Cleaning

To clean your speaker, wipe it with a soft, damp cloth. Do not use abrasive cleaners or solvents, as these may damage the device. Ensure the speaker is dry before charging.

TROUBLESHOOTING

Problem	Possible Solution
Speaker does not turn on.	Ensure the battery is charged. Connect the speaker to a power source using the USB charge cable.
Cannot pair with Bluetooth device.	Make sure the speaker is in pairing mode (flashing LED). Turn off and on Bluetooth on your device. Ensure the speaker is within 100ft range. Forget the device on your phone and try pairing again.
No sound or low volume.	Increase the volume on both the speaker and your connected device. Ensure the speaker is properly connected via Bluetooth.
Poor call quality.	Ensure the speaker is close to you. Check for strong Bluetooth connection. Avoid noisy environments if possible.
Battery life is shorter than expected.	Battery life can vary with volume level and usage. Ensure the speaker is fully charged before use.

TECHNICAL SPECIFICATIONS

Specification	Detail
Model Name	39g
Brand	noxgear
Mounting Type	Clip On, Magnetic Mount
Material	Plastic
Speaker Type	Outdoor
Special Feature	Portable, Stereo Pairing
Recommended Uses	Music, Outdoor
Compatible Devices	Smartphone, Tablet
Color	Black
Battery Life	Up to 15 Hours (Average Play Time) / 12 Hours (Specification)
Charging Time	3 Hours
Item Weight	1.37 ounces (39g)
Product Dimensions	1.46"D x 3.78"W x 3.98"H
Waterproof Rating	IPX7
Control Method	Touch
Wireless Communication Technology	Bluetooth
Bluetooth Range	100 feet (30 meters) / 10 Meters (Specification)
Number of Microphones	1
Speaker Maximum Output Power	10 Watts
UPC	857860005085

WARRANTY & SUPPORT

The Noxgear 39g Wearable Bluetooth Speaker comes with a 1-year warranty from the date of purchase, covering manufacturing defects. For technical support, warranty claims, or general inquiries, please visit the official Noxgear website or contact their customer service.

For more information, visit: [Noxgear Official Store](#)