

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

> [BaByliss](#) /

> [BaByliss 9000 High Performance Cordless Hair Straightener User Manual](#)

BaByliss 9000UPSDE

BaByliss 9000 High Performance Cordless Hair Straightener User Manual

Model: 9000UPSDE | Brand: BaByliss

INTRODUCTION

Welcome to the BaByliss 9000 High Performance Cordless Hair Straightener. This innovative device offers unparalleled freedom and flexibility for styling your hair anywhere, anytime. Featuring advanced micro-heating matrix technology and a powerful lithium-ion battery, it ensures fast heat-up and consistent performance. Please read this manual thoroughly before first use to ensure safe and optimal operation of your new straightener.

IMPORTANT SAFETY INFORMATION

When using electrical appliances, especially when children are present, basic safety precautions should always be followed, including the following:

- Always unplug the appliance immediately after use.
- Do not use while bathing or in a shower.
- Do not place or store appliance where it can fall or be pulled into a tub or sink.
- Do not place in or drop into water or other liquid.
- If an appliance falls into water, unplug it immediately. Do not reach into the water.
- Keep away from water.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended by the manufacturer.
- Never operate this appliance if it has a damaged cord or plug, if it is not working properly, or if it has been dropped or damaged, or dropped into water.
- Keep the cord away from heated surfaces. Do not wrap the cord around the appliance.
- Never block the air openings of the appliance or place it on a soft surface, such as a bed or couch, where the air openings may be blocked. Keep the air openings free of lint, hair, and the like.

- Never use while sleeping.
- Never drop or insert any object into any opening.
- Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
- Do not use an extension cord with this appliance.
- The plates are hot during use. Do not let eyes or bare skin touch heated surfaces.
- Do not place the appliance directly on any surface while it is hot or plugged in.
- Always store the straightener in its protective heat-resistant pouch or on a heat-resistant surface when not in use.

PRODUCT COMPONENTS

Your BaByliss 9000 Cordless Hair Straightener comes with the following components:

- BaByliss 9000 Cordless Hair Straightener
- Heat-resistant travel case
- Silicone plate guard
- Charging cable and adapter
- Heat mat



The BaByliss 9000 Cordless Hair Straightener shown with its sleek black heat-resistant travel case.



The straightener, case, and additional accessories including jewelry, demonstrating its portability and style.



A detailed view of the smooth, black ceramic plates designed for effortless gliding through hair.



A close-up of the magnetic charging port located at the end of the straightener, labeled 'DC IN: 8.4V 2A'.

SETUP

Initial Charging

Before using your BaByliss 9000 for the first time, it is recommended to fully charge the battery. This ensures optimal performance and battery longevity.

1. Connect the charging cable to the charging port at the end of the straightener.
2. Plug the adapter into a suitable power outlet.
3. The power button LED will indicate charging status (refer to 'Charging and Battery Life' section for details).
4. A full charge takes approximately 3 hours for 30 minutes of wireless styling at maximum temperature.



The BaByliss 9000 straightener with its magnetic charging cable connected to the port.

OPERATING INSTRUCTIONS

Turning On/Off

- To turn on: Press and hold the power button for two seconds until the indicator light illuminates and you hear an audible alert.
- To turn off: Press and hold the power button for two seconds until the indicator light turns off and you hear an audible alert.

Temperature Settings

The BaByliss 9000 offers three temperature settings to suit different hair types:

- 160°C (320°F) - Indicated by one LED light.
- 180°C (356°F) - Indicated by two LED lights.
- 200°C (392°F) - Indicated by three LED lights.

To change the temperature setting, briefly press the power button while the straightener is on. The LED indicators will change to reflect the selected temperature. The LEDs will flash until the desired temperature is reached, then remain solid.



A close-up view of the power button, which also serves as the battery indicator, and the three small LED lights indicating temperature settings.

Styling Hair

Ensure your hair is clean, dry, and tangle-free before styling. For best results, use a heat protectant spray.

1. Section your hair into manageable portions.
2. Take a section of hair and place it between the heating plates, close to the roots.
3. Gently close the plates and glide the straightener down the hair section from root to tip in one smooth, continuous motion.
4. Repeat for all sections of hair until desired style is achieved.
5. The rounded body of the straightener also allows for creating curls and waves. Simply rotate the straightener as you glide it down the hair section.



A woman demonstrating the use of the BaByliss 9000 Cordless Hair Straightener to straighten her hair.

CHARGING AND BATTERY LIFE

The BaByliss 9000 is powered by a high-performance lithium-ion battery, offering cordless convenience.

Battery Indicator

The power button LED changes color to indicate the battery charge level:

- **Green:** Charge level above 70%.
- **Yellow:** Charge level between 30% and 70%.
- **Flashing Yellow:** Charge level below 30%.
- **Red:** Battery needs recharging.

Charging Time and Runtime

- A full charge takes approximately 3 hours.
- Provides up to 30 minutes of wireless styling at maximum temperature on a full charge.
- The straightener can also be used while charging, though it may take longer to reach full temperature.

MAINTENANCE AND CLEANING

To ensure the longevity and optimal performance of your BaByliss 9000 straightener, follow these maintenance guidelines:

- Always ensure the straightener is turned off, unplugged, and completely cool before cleaning.
- Wipe the ceramic plates and the exterior of the straightener with a soft, damp cloth. Do not use abrasive cleaners or harsh chemicals.
- Ensure no water or moisture enters the internal components.
- Regularly check the charging port for any debris and clean gently if necessary.
- Store the straightener in its heat-resistant travel case or with the silicone plate guard when not in use, especially when traveling.



The BaByliss 9000 straightener shown in its closed position, ready for storage or transport, possibly with the silicone plate guard.

TROUBLESHOOTING

If you encounter any issues with your BaByliss 9000 straightener, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Straightener does not turn on.	Battery is depleted.	Charge the straightener fully.
Straightener does not heat up.	Not turned on correctly; low battery.	Ensure power button is held for 2 seconds. Check battery indicator and charge if necessary.
Battery life is shorter than expected.	Using at highest temperature; frequent short uses; battery degradation over time.	Reduce temperature setting if possible. Ensure full charges. Battery performance may naturally decrease over extended use.
Straightener turns off automatically.	Auto shut-off feature activated (after 5 minutes of inactivity); low battery.	This is a safety feature. Turn it back on. Charge the straightener if battery is low.

If the problem persists after trying these solutions, please contact BaByliss customer support.

SPECIFICATIONS

Feature	Detail
Brand	BaByliss
Model Name	BaByliss 9000
Item Model Number	9000UPSDE
Product Dimensions	15.75 x 1.18 x 0.01 cm
Item Weight	0.5 Kilograms
Power Source	Battery Powered
Material	Ceramic
Colour	Black
Temperature Settings	160°C, 180°C, 200°C

Feature	Detail
Charging Time	Approx. 3 hours for full charge
Wireless Styling Time	Up to 30 minutes (at max temperature)

WARRANTY AND SUPPORT

BaByliss products are manufactured to the highest standards and are rigorously tested. If you experience any issues with your BaByliss 9000 High Performance Cordless Hair Straightener, please refer to the troubleshooting section of this manual. For warranty information or further assistance, please contact BaByliss customer support through their official website or the retailer from whom you purchased the product. Keep your proof of purchase for warranty claims.