Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

VASAGLE LTV049B01

VASAGLE LTV049B01 TV Cabinet Instruction Manual

Model: LTV049B01

1. Introduction

Thank you for choosing the VASAGLE LTV049B01 TV Cabinet. This manual provides detailed instructions for assembly, safe operation, and maintenance of your new furniture. Please read it carefully before beginning assembly and keep it for future reference.



Image: The VASAGLE LTV049B01 TV Cabinet, featuring a rustic brown finish and black metal frame, positioned in a modern living room. It has a louvered door on the left and open shelves on the right, suitable for various media devices and decor.

2. Safety Information

- **General Safety:** Always follow the assembly instructions carefully. Ensure all parts are correctly installed and tightened before use.
- **Child Safety:** For safety reasons, children should not climb on the product or play with it. Keep small parts away from children during assembly.
- **Weight Capacity:** Do not exceed the maximum static load capacities specified in the "Specifications" section to prevent damage or injury.
- **Placement:** Place the TV cabinet on a flat, stable surface. Avoid placing it in areas with high humidity or direct sunlight.
- **Stability:** If the product includes anti-tip hardware, ensure it is properly installed to secure the cabinet to the wall.

3. Parts List

Before assembly, please verify that all components listed below are present and undamaged. Refer to the separate assembly diagram included in your package for detailed identification of each part and hardware.

- 1 x TV Cabinet Unit (disassembled components)
- 1 x Assembly Kit (includes screws, dowels, connectors, and a screwdriver)
- 1 x Instruction Manual (this document)

If any parts are missing or damaged, please contact customer support for assistance.

4. Assembly Instructions

Assembly is designed to be straightforward with numbered parts and clear diagrams. Please follow the steps below and refer to the included graphical assembly guide for visual assistance.

1. **Unpack and Identify:** Carefully unpack all components and lay them out on a clean, soft surface (e.g., a blanket or cardboard) to prevent scratches. Identify each part using the labels and the assembly diagram.
2. **Assemble the Frame:** Begin by connecting the main metal frame components using the provided screws. Ensure all connections are secure but do not overtighten initially.
3. **Attach Side Panels:** Secure the side panels to the assembled frame.
4. **Install Shelves:** Insert the fixed and adjustable shelves into their designated slots or attach them with the appropriate hardware.
5. **Assemble and Attach Door:** Assemble the louvered door and attach it to the cabinet using the hinges. Ensure the door opens and closes smoothly. Install the door knob.
6. **Install Back Panel:** Secure the back panel, ensuring the cable management holes are correctly oriented.
7. **Final Tightening:** Once all components are in place, carefully tighten all screws. Do not overtighten.
8. **Attach Adjustable Feet:** Screw in the adjustable feet to the bottom of the cabinet. Adjust them to ensure the cabinet is level and stable on your floor.
9. **Install Anti-Tip Kit (Optional but Recommended):** If an anti-tip kit is included, follow its specific instructions to secure the cabinet to a wall, especially if children are present.



Image: A hand installing the black knob on the louvered door of the TV cabinet, illustrating a step in the assembly process.

5. Operating and Usage

Your VASAGLE TV Cabinet is designed for versatile storage and display of your entertainment equipment and decorative items.

- **TV Placement:** Place your television securely on the top surface. Ensure the TV's base fits within the cabinet's dimensions and does not exceed the maximum weight capacity. This cabinet is suitable for TVs up to 50 inches.
- **Open Shelves:** Utilize the two open shelves for media devices such as soundbars, gaming consoles, DVD players, or streaming boxes. The open design allows for easy access and ventilation.
- **Closed Compartment:** The louvered door compartment provides concealed storage for items you wish to keep out of sight, such as cables, remote controls, or other accessories.
- **Cable Management:** Use the integrated cable management holes on the back panel to organize and route power cords and signal cables, keeping your setup tidy and preventing tangles.



Image: The TV cabinet displaying a television, soundbar, and various items on its open shelves, highlighting its functional use.



Image: A detailed view of the circular cable management holes on the back panel of the TV cabinet, with cables routed through them.

6. Maintenance

Proper care will ensure the longevity and appearance of your TV cabinet.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid using harsh chemicals, abrasive cleaners, or polishes that may damage the finish.
- **Spills:** Immediately wipe up any spills to prevent moisture damage.
- **Heat and Moisture:** Keep the cabinet away from direct heat sources and excessive moisture. Use coasters under drinks to protect the top surface.
- **Inspection:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary.

7. Troubleshooting

If you encounter any issues with your VASAGLE TV Cabinet, refer to the following common solutions:

- **Wobbly Cabinet:**
  - Ensure the cabinet is placed on a level surface.
  - Adjust the leveling feet on the bottom of the cabinet until it is stable.
  - Check all assembly screws and tighten any that are loose.
- **Door Not Closing Properly:**
  - Check the hinge alignment. Loosen hinge screws slightly, adjust the door, and then retighten.
  - Ensure no items inside the compartment are obstructing the door's path.
- **Missing Parts or Damaged Components:**
  - Carefully re-check the packaging and all contents against the parts list.
  - Contact VASAGLE customer support with your model number and a description of the issue for replacement parts.

8. Specifications

Model Number:	LTV049B01
Color:	Rustic Brown and Black
Material:	Particleboard, Steel
Overall Dimensions (L x W x H):	110 x 40 x 50 cm (43.3 x 15.7 x 19.7 inches)
Product Weight:	19.8 kg (43.6 lbs)
Max. Static Load Capacity (Top Surface):	30 kg (66 lbs)
Max. Static Load Capacity (Closed Shelf):	15 kg (33 lbs)
Max. Static Load Capacity (Each Open Shelf):	10 kg (22 lbs)
TV Size Compatibility:	Up to 50 inches



Image: A detailed diagram illustrating the overall and internal dimensions of the TV cabinet in centimeters.




Image: A visual guide demonstrating the compatible TV screen sizes (32", 40", 50") that can be placed on the 110 cm wide TV cabinet.

9. Warranty and Support

For warranty information, product support, or to order replacement parts, please contact VASAGLE customer service. Refer to your purchase documentation for specific contact details or visit the official VASAGLE website.
Please have your model number (LTV049B01) and purchase date ready when contacting support.

© 2024 VASAGLE. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B087QBT3T2

More documents and user manuals: **https://manuals.plus/**