

[Manuals.plus](#) /

› [OMOTON](#) /

› OMOTON Adjustable Cell Phone Stand User Manual

OMOTON 3

OMOTON Adjustable Cell Phone Stand User Manual

Model: 3

Brand: OMOTON

INTRODUCTION

This user manual provides detailed instructions for the OMOTON Adjustable Cell Phone Stand. Designed for convenience and ergonomic comfort, this stand allows for hands-free use of your mobile device, reducing neck strain and improving viewing angles for various activities.

PRODUCT FEATURES

- **Adjustable Height & Angle:** Features adjustable height (6.29-8.29 inches) and tilt range (up to 45 degrees) for comfortable hands-free use, helping to fix posture and reduce neck strain.
- **Wide Compatibility:** Compatible with all cellphones between 3.5 to 7.0 inches, even with a case (up to 0.75 inch in thickness), including iPhone SE 2 /11/11 Pro/11 Pro Max/ X/ Xs Max, Samsung Galaxy S20/ S10e / S9 Plus / S8/, Note 10 Plus/ Note G G8, Nexus 6P, etc.
- **Thoughtful Design:** Includes a reserved charging hole for convenient charging and a base that can be used for storing small items.
- **Weighted Anti-Slip Base:** Equipped with a reinforced base and an aluminum alloy rod for steady device support. Non-slip silicone pads on the bottom enhance stability.
- **Easy Installation:** Simple assembly by knocking in the aluminum rod. The stand is compact and lightweight, suitable for travel.

WHAT'S IN THE BOX

- Cell phone stand (unassembled components)

SETUP AND INSTALLATION

The OMOTON Cell Phone Stand is designed for quick and easy assembly. Follow these steps for proper setup:


Step 1: Identify Correct Orientation




Before installation, please identify the correct mounting direction of the phone stand



Insert the rod vertically into the base slot



Use the included screwdriver to secure the screws in the small holes on the bottom



Then place your phone on the phone stand to use properly

Before installation, carefully identify the correct mounting direction of the phone stand. Ensure the phone holder part is oriented correctly to avoid permanent assembly in the wrong direction.

Step 2: Insert Rod into Base



Insert the aluminum rod vertically into the designated slot on the base. Apply gentle pressure to secure it in place.

Step 3: Secure with Screwdriver (if applicable)



Use the included screwdriver to secure any screws in the small holes on the bottom of the base, ensuring a firm and stable connection.

Step 4: Place Your Phone

Improved Stability

Heavier metal base offers extra stability for stand & device



Once assembled, place your phone on the stand to use it properly. The stand is now ready for adjustment and use.

For a visual guide, you may refer to the official installation video:

Your browser does not support the video tag.

Official OMOTON Installation Guide Video. This video demonstrates the assembly process and key features of the adjustable phone stand.

OPERATING INSTRUCTIONS

The OMOTON Cell Phone Stand offers versatile adjustments for optimal viewing and convenience.

Adjusting Height and Angle



Height Adjustment

Helps to fix your posture and reduce your neck strain

The stand's height can be adjusted between 6.29 and 8.29 inches. Gently pull or push the aluminum rod to achieve your desired height. This helps in fixing your posture and reducing neck strain.

Comfortable Viewing Angle

It can be easily adjusted to the (10°~45°) angle by hand, providing you most comfortable viewing experience.



The phone holder can be tilted up to 45 degrees. Adjust the angle by hand to find the most comfortable viewing experience for watching videos, making calls, or browsing.

Device Placement and Compatibility



The stand supports phones between 3.5 to 7.0 inches, even with a case up to 0.75 inches thick. You can place your device both vertically and horizontally.



The design ensures universal compatibility, accommodating a wide range of smartphones and even some smaller tablets.

Charging and Storage

Easy-To-Charge Design

The reserved charging port makes it easy to charge your device at anytime



A reserved charging hole on the lower part of the holder allows for convenient charging while your device is on the stand.



Front Silicone Mat

Front silicone mat protects your phone from shocks and scratches



Bottom Silicone Pads

Anti-slip bottom silicone pads prevent the stand from sliding



The sturdy base of the stand can also be utilized for storing small items, helping to keep your desk organized.

MAINTENANCE

To ensure the longevity and optimal performance of your OMOTON Cell Phone Stand, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the stand regularly with a soft, dry cloth to remove dust and fingerprints. For stubborn marks, a slightly damp cloth can be used, followed by immediate drying. Avoid abrasive cleaners or solvents.
- **Storage:** When not in use, store the stand in a clean, dry place. Its compact and lightweight design makes it easy to store or transport.
- **Handling:** While durable, avoid dropping the stand or subjecting it to excessive force, which could damage the adjustable mechanisms or the base.

TROUBLESHOOTING

If you encounter any issues with your OMOTON Cell Phone Stand, refer to the following common troubleshooting tips:

- **Stand is Wobbly:**
 - Ensure the aluminum rod is fully inserted and secured into the base. If applicable, check that any securing screws are tightened.
 - Verify that the surface the stand is placed on is flat and stable.
- **Phone is Sliding:**
 - Check that the silicone pads on the phone holder and base are clean and free of dust or debris. Clean them with a damp cloth if necessary.
 - Ensure your phone's size is within the compatible range (3.5-7.0 inches) and that its case thickness does not exceed 0.75 inches.
- **Difficulty Adjusting Angle/Height:**
 - Apply firm but gentle pressure when adjusting. The mechanisms are designed to hold positions securely, so some resistance is normal.
 - Ensure no foreign objects are obstructing the moving parts.

If the issue persists, please contact OMOTON customer support for further assistance.

SPECIFICATIONS

Brand	OMOTON
Model Number	3
Product Dimensions	3.5 x 3.6 x 6 inches
Item Weight	7.4 ounces
Adjustable Height Range	6.29 - 8.29 inches
Adjustable Tilt Angle	Up to 45 degrees
Compatible Devices	Smartphones (3.5-7.0 inches, up to 0.75 inch case thickness)
Material	Aluminum alloy rod, reinforced base, silicone pads
Color	Black
Date First Available	April 27, 2020

WARRANTY AND SUPPORT

OMOTON stands behind the quality of its products. For any warranty claims, technical support, or inquiries regarding your cell phone stand, please refer to the following:

- **Official User Guide:** A detailed installation manual is available in PDF format for additional guidance. You can access it[here](#).
- **Contact Support:** For specific product support or warranty information, please visit the official OMOTON website or contact their customer service directly through the platform where the product was purchased.

© 2025 OMOTON. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question