

SOAR NCAA-BTH-CF

SOAR ShockBox XL Wireless Bluetooth Speaker

Model: NCAA-BTH-CF

INTRODUCTION

The SOAR ShockBox XL Wireless Bluetooth Speaker is designed for portable audio entertainment, featuring robust sound and dynamic LED lighting. It is ideal for various outdoor and indoor settings, offering multiple connectivity options and extended battery life. This manual provides essential information for the proper setup, operation, and maintenance of your speaker.

SAFETY INFORMATION

- Do not expose the speaker to extreme temperatures, direct sunlight, or high humidity.
- Avoid dropping or subjecting the speaker to strong impacts.
- Keep the speaker away from water and other liquids. If it gets wet, power it off immediately and allow it to dry completely before use.
- Do not attempt to disassemble, repair, or modify the speaker. This will void the warranty and may cause damage or injury.
- Use only the provided Micro USB cable for charging.
- Clean the speaker with a soft, dry cloth. Do not use abrasive cleaners or solvents.

PACKAGE CONTENTS

Please check the package for the following items:

- SOAR ShockBox XL Wireless Bluetooth Speaker
- Micro USB Charging Cable
- User Manual (this document)

PRODUCT OVERVIEW



Figure 1: Front view of the SOAR ShockBox XL speaker, showcasing the Alabama Crimson Tide logo on the speaker grille with active LED lighting. The speaker features a sturdy handle for portability.



Figure 2: The SOAR ShockBox XL speaker positioned outdoors on a wooden surface, demonstrating its use with a smartphone connected via Bluetooth for music playback. The speaker's LED lights are subtly visible.



Figure 3: A diagram illustrating the approximate dimensions of the SOAR ShockBox XL speaker: 9.45 inches in height, 6.7 inches in width, and 4 inches in depth.

SETUP

Initial Charging

Before first use, fully charge the speaker. Connect the Micro USB charging cable to the speaker's charging port and the other end to a USB power source (e.g., computer USB port, USB wall adapter). The LED indicator will show charging status and turn off when fully charged. A full charge provides over 5 hours of playtime.

Powering On/Off

Press and hold the Power button located on the top panel to turn the speaker on or off. A voice prompt will indicate the power status.

OPERATING INSTRUCTIONS

Bluetooth Pairing

1. Ensure the speaker is powered on and in Bluetooth pairing mode (indicated by a flashing LED).
2. On your mobile device, enable Bluetooth and search for available devices.
3. Select "SOAR ShockBox XL" from the list of devices.
4. Once paired, the speaker will provide an audible confirmation, and the LED will stop flashing.
5. You can now play audio from your device through the speaker. The wireless range is approximately 30 feet.

FM Radio Operation

To use the FM radio function:

- Press the Mode button to switch to FM Radio mode.
- Press and hold the Play/Pause button to auto-scan and save available FM stations.

- Use the Next/Previous track buttons to navigate between saved stations.

USB and AUX Input

- **USB Input:** Insert a USB drive containing audio files into the USB port. The speaker will automatically switch to USB mode and begin playback.
- **AUX Input:** Connect an audio device using a 3.5mm AUX cable (not included) to the AUX port. The speaker will switch to AUX mode for wired audio playback.

LED Light Modes

The speaker features multiple color LED lights that move to the beat of the music. Press the dedicated LED button (if available, or refer to specific button functions on the device) to cycle through different light modes or turn the lights off.

Stereo Pairing (TWS Function)

To achieve true wireless stereo sound, you can pair two SOAR ShockBox XL speakers together:

1. Ensure both speakers are powered on and not connected to any Bluetooth device.
2. On one speaker (this will be the primary speaker), press and hold the TWS pairing button (refer to speaker controls for exact button).
3. The speakers will automatically search for and connect to each other. A confirmation tone will sound once paired.
4. Connect your mobile device to the primary speaker via Bluetooth as described in the "Bluetooth Pairing" section.
5. Audio will now play in stereo through both speakers.

MAINTENANCE

- **Cleaning:** Wipe the speaker's exterior with a soft, lint-free cloth. Do not use liquid cleaners or aerosols.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures when not in use for extended periods.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the speaker regularly, even if not in active use.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Speaker does not turn on.	Low battery.	Charge the speaker fully.
Cannot pair via Bluetooth.	Speaker not in pairing mode; device Bluetooth off; too far from speaker.	Ensure speaker is in pairing mode. Turn Bluetooth on your device. Move device closer to speaker (within 30 ft).
No sound.	Volume too low; incorrect input mode; device not playing.	Increase speaker and device volume. Check if the correct input mode (Bluetooth, USB, AUX, FM) is selected. Ensure audio is playing on the connected device.
Poor FM radio reception.	Weak signal.	Relocate the speaker to an area with better reception.

SPECIFICATIONS

Model: NCAA-BTH-CF

Connectivity: Bluetooth 5.0, USB, AUX, FM Radio

Wireless Range: Up to 30 feet

Playtime: Over 5 hours per charge

Charging: Micro USB (cable included)

Features: Multi-color LED lights, Stereo Pairing (TWS) capability, Lightweight, Shockproof materials

Manufacturer: Prime Brands Group Inc.

WARRANTY AND SUPPORT

SOAR products are manufactured with high-quality materials and craftsmanship. This product is covered by a limited warranty against defects in materials and workmanship. For detailed warranty information or technical support, please visit the official SOAR website or contact their customer service department.

For further assistance, please refer to the contact information provided on the product packaging or the official SOAR brand store on Amazon: [Visit the SOAR Store](#).