

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Goji](#) /
- › [Goji GKIDBTB18 Wireless Bluetooth Kids Headphones User Manual](#)

Goji GKIDBTB18

Goji GKIDBTB18 Wireless Bluetooth Kids Headphones User Manual

Model: GKIDBTB18

INTRODUCTION

Thank you for choosing the Goji GKIDBTB18 Wireless Bluetooth Kids Headphones. This manual provides essential information for the safe and effective use, setup, operation, and maintenance of your headphones. Please read this manual thoroughly before using the product and retain it for future reference.

PRODUCT OVERVIEW


The Goji GKIDBTB18 headphones are designed for children, offering both wireless Bluetooth connectivity and a wired option via a 3.5mm jack. They feature a built-in rechargeable battery, volume control, and an integrated microphone.



This image displays the Goji GKIDBTB18 Wireless Bluetooth Kids Headphones in blue, showcasing the adjustable headband and cushioned earcups. The left earcup is marked with an 'L'.

Components and Controls

- **Earcups:** Cushioned for comfort, housing the speakers.
- **Headband:** Adjustable for a secure fit.
- **Power Button:** Used to turn the headphones on/off and for pairing.
- **Volume Controls:** Buttons to adjust the listening volume.
- **Microphone:** Integrated for hands-free communication.
- **Charging Port:** For recharging the built-in battery.
- **3.5mm Audio Jack:** For wired connection using the included cable.



This image shows the light blue 3.5mm audio cable included with the Goji GKIDBTB18 headphones, featuring a straight jack on one end and an L-shaped jack on the other for versatile connection.

SETUP

1. Charging the Headphones

1. Locate the charging port on the headphones.
2. Connect the provided charging cable to the headphones and the other end to a compatible USB power source (e.g., computer USB port, USB wall adapter).
3. The charging indicator light will illuminate, typically red, during charging.
4. Once fully charged, the indicator light will change color (e.g., turn off or turn blue/green). A full charge usually takes approximately 2-3 hours.
5. Disconnect the charging cable once charging is complete.

2. Initial Bluetooth Pairing

1. Ensure the headphones are fully charged.
2. With the headphones turned off, press and hold the Power button for approximately 5-7 seconds until the indicator light flashes rapidly, typically blue and red, indicating pairing mode.
3. On your device (smartphone, tablet, computer), enable Bluetooth and search for available devices.
4. Select "Goji GKIDBTB18" from the list of found devices.
5. Once connected, the indicator light on the headphones will typically flash slowly or turn solid blue.
6. If prompted for a password, enter "0000".

OPERATING INSTRUCTIONS

Powering On/Off

- **To Power On:** Press and hold the Power button for about 3 seconds until the indicator light illuminates.
- **To Power Off:** Press and hold the Power button for about 3-5 seconds until the indicator light turns off.

Bluetooth Connection

- After initial pairing, the headphones will automatically attempt to connect to the last paired device when powered on.
- If connection fails, ensure Bluetooth is enabled on your device and the headphones are within range.

Volume Control

- Use the **Volume Up (+)** button to increase the volume.
- Use the **Volume Down (-)** button to decrease the volume.
- *Note:* For children's safety, these headphones have a built-in volume limiter to protect hearing.

Using the Microphone

- The integrated microphone allows for hands-free calls when connected via Bluetooth to a smartphone.
- **To Answer/End a Call:** Press the Power/Multi-function button once.
- **To Reject a Call:** Press and hold the Power/Multi-function button for 2 seconds.

Wired Connection (3.5mm Audio Jack)

- Insert one end of the provided 3.5mm audio cable into the headphone's audio jack.
- Insert the other end into the 3.5mm audio output of your device (e.g., tablet, computer, MP3 player).
- When connected via cable, the Bluetooth function will automatically turn off.

MAINTENANCE AND CARE

- **Cleaning:** Wipe the headphones with a soft, dry, lint-free cloth. Do not use abrasive cleaners, alcohol, or chemical solvents.
- **Storage:** Store the headphones in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the headphones regularly, even if not in use for extended periods.
- **Water Exposure:** These headphones are not waterproof. Avoid exposure to water or excessive moisture.
- **Handling:** Handle the headphones gently. Avoid dropping them or subjecting them to strong impacts.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No sound from headphones.	Headphones not powered on, low battery, not paired, volume too low, incorrect audio source.	Ensure headphones are on and charged. Re-pair with device. Increase headphone and device volume. Check wired connection if applicable.
Cannot pair with device.	Headphones not in pairing mode, device Bluetooth off, too far from device, interference.	Put headphones in pairing mode (flashing red/blue). Ensure device Bluetooth is on. Move headphones closer to device. Turn off other Bluetooth devices nearby.
Battery not charging.	Charging cable not connected properly, faulty cable/charger, dirty charging port.	Ensure cable is securely connected. Try a different USB port or charger. Clean charging port gently.
Poor sound quality.	Weak Bluetooth signal, interference, low quality audio file.	Move closer to the paired device. Avoid obstacles between headphones and device. Try a different audio source.

SPECIFICATIONS

Model Name	GKIDBTB18
Brand	Goji
Connectivity Technology	Wireless (Bluetooth), Wired (3.5mm Jack)
Ear Placement	On Ear
Form Factor	On Ear
Colour	Blue
Included Components	Cable
Age Range (Description)	Kid
Product Dimensions	7.5 x 18 x 16 cm

WARRANTY AND SUPPORT

Goji products are designed and manufactured to the highest quality standards. For information regarding warranty coverage, technical support, or service inquiries, please refer to the warranty card included with your purchase or visit the official Goji website. Keep your proof of purchase for warranty claims.

For further assistance, you may also contact the retailer where the product was purchased.