Samsung VS20T7536T5/AA

Samsung Jet 75 Stick Cordless Lightweight Vacuum Cleaner Instruction Manual

Product Overview

The Samsung Jet™ 75 Complete Cordless Stick Vacuum is engineered for optimal convenience and performance. It offers up to 60 minutes of uninterrupted cleaning on a single charge, with the option to easily swap the battery for extended use. The Turbo Action Brush, featuring 200 Air Watts of intense suction power and 180° swivel flexibility, is effective across multiple surfaces. A 5-layer HEPA filtration system captures 99.999% of microdust, ensuring a thorough clean. Its lightweight design, at just 6.2 pounds, simplifies cleaning hard-to-reach areas. The Jet Cyclone system prevents dirt buildup on the filter, which is also dishwasher safe for easy maintenance. Additional tools, including a soft brush for hard floors, a mini motorized tool for allergens, and a crevice tool for tight spaces, enhance its versatility. The vacuum can be conveniently mounted on a wall for storage and simultaneous charging.

- **60 Minute Battery Life:** Enjoy up to 60 minutes of cleaning; battery is easily swappable.
- **Advanced Performance:** Delivers 200 Air Watts of suction power for effective cleaning on hardwood, tile, and carpeting.
- **Lightweight Design:** Weighs only 6.2 pounds, making it easy to maneuver for stairs, under furniture, and high areas.
- **Turbo Action Brush:** Rotates over 3,700 times per minute with 180° swivel for efficient cleaning of dust, hair, and debris on various surfaces.
- **Jet Cyclone:** Multi-cyclonic system prevents debris buildup on the filter, directing dirt into the dustbin.



Figure 1: Samsung Jet 75 Stick Cordless Lightweight Vacuum Cleaner, fully assembled.

Setup Guide

1. Unboxing and Initial Inspection

Carefully remove all components from the packaging. Verify that all parts listed in the packing list are present and undamaged. Keep packaging materials for potential future transport or returns.

2. Assembly

Connect the main body of the vacuum to the extension wand, and then attach the desired cleaning head (e.g., Turbo Action Brush) to the other end of the wand. Ensure all connections click securely into place.



Figure 2: The Samsung Jet 75 vacuum cleaner fully assembled, ready for use.

3. Charging the Battery

The battery should be fully charged before first use. Detach the battery from the main body by pressing the release button. Connect the battery to the charging station. The charging station can be wall-mounted for convenience, allowing the vacuum to charge while stored. A full charge provides up to 60 minutes of run time at the minimum power level with a non-motorized tool.



Figure 3: The removable 21.9V Lithium-Ion battery for the Samsung Jet 75.




Figure 4: The Samsung Jet 75 vacuum mounted on its wall-mounted charging station.

Operating Your Vacuum

1. Power On/Off and Suction Control

Press the power button on the handle to turn the vacuum on or off. Use the '+' and '-' buttons to adjust the suction power between different levels (e.g., Min, Mid, Max) to suit the cleaning task and surface type.



Figure 5: Close-up of the vacuum's control panel, showing power and suction level buttons.

2. Cleaning Different Surfaces

The Turbo Action Brush is designed for effective cleaning on hardwood, tile, and carpeting. Adjust the suction power as needed: lower settings for delicate surfaces or light debris, higher settings for carpets or stubborn dirt.

3. Using Attachments

The Samsung Jet 75 comes with several specialized tools for various cleaning needs:

- **Mini Motorized Tool:** Ideal for removing pet hair and allergens from upholstery and small areas.
- **Long-Reach Crevice Tool:** Perfect for accessing tight corners, gaps, and narrow spaces.
- **Combination Tool:** A versatile tool with a brush and wide nozzle for general cleaning of various surfaces.
- **Soft Brush:** Gentle yet effective for cleaning delicate surfaces like hardwood floors and furniture.



Figure 6: A selection of accessories and tools included with the Samsung Jet 75 vacuum.

Maintenance and Care

1. Emptying the Dustbin

To maintain optimal suction, empty the 0.8-liter dustbin regularly. Press the release button to detach the dustbin from the main body, then open it to dispose of collected debris. The Jet Cyclone system helps prevent dirt buildup, making emptying cleaner.



Figure 7: Exploded view showing the removable dustbin and multi-layer filtration system.

2. Cleaning Filters

The 5-layer HEPA filtration system is crucial for trapping fine dust and allergens. The filter is designed to be easily removed and is dishwasher safe for convenient cleaning. Ensure the filter is completely dry before reinserting it into the vacuum.

3. Cleaning the Turbo Action Brush

Periodically check the Turbo Action Brush for tangled hair or debris. Remove any obstructions to ensure the brush rotates freely and maintains effective cleaning performance.



Figure 8: The Turbo Action Brush head, designed for various floor types.

Troubleshooting Common Issues

- **No Power:** Ensure the battery is fully charged and correctly inserted. Check if the charging station is properly connected to a power source.
- **Reduced Suction:** Empty the dustbin. Clean all filters (pre-motor and HEPA) and ensure they are dry before reassembly. Check the brush head and wand for any blockages.
- **Brush Not Rotating:** Inspect the Turbo Action Brush for tangled hair or debris and remove any obstructions.
- **Unusual Noise:** Turn off the vacuum and check for any foreign objects lodged in the brush, wand, or dustbin.

Product Specifications

Feature	Specification
Brand	Samsung
Model Name	Jet™ 75 Complete Cordless Stick Vacuum
Model Number	VS20T7536T5/AA
Power Source	Battery Powered (21.9 Volts)
Battery Type	Lithium-Ion
Runtime	Up to 60 minutes (minimum power level with non-motorized tool)
Suction Power	200 Air Watts
Filter Type	HEPA Filter (5-layer system)
Dustbin Capacity	0.8 Liters
Item Weight	6.2 Pounds
Item Dimensions (L x W x H)	8.5"L x 9.8"W x 44.5"H
Surface Recommendation	Hardwood, Tile, Carpeting
Included Components	Mini Motorized Tool, Long-Reach Crevice Tool, Combination Tool, Soft Brush

Warranty and Customer Support

Warranty Information

The Samsung Jet 75 Stick Cordless Lightweight Vacuum Cleaner comes with a**1-year warranty covering parts and labor**. Please retain your proof of purchase for warranty claims.

Customer Support

For technical assistance, troubleshooting, or warranty service, please contact Samsung Customer Support. Refer to the official Samsung website or the user manual included in your product packaging for contact details and further support resources.