

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Samsung](#) /

› [Samsung Jet 70 Pet Cordless Stick Vacuum User Manual](#)

## Samsung VS15T7032R4/AA

# Samsung Jet 70 Pet Cordless Stick Vacuum User Manual

Model: VS15T7032R4/AA

<a href="#">Introduction</a>	<a href="#">What's in the Box</a>	<a href="#">Setup</a>	<a href="#">Operating Instructions</a>	<a href="#">Maintenance</a>	<a href="#">Specifications</a>
			<a href="#">Warranty &amp; Support</a>		

## 1. INTRODUCTION

The Samsung Jet 70 Pet Cordless Stick Vacuum (Model VS15T7032R4/AA) is designed for efficient and versatile cleaning across various surfaces. This manual provides essential information for the safe and effective operation, maintenance, and troubleshooting of your vacuum cleaner.


Key features include 150 Air Watts of suction power, a long-lasting battery, a lightweight design, and a multi-layered filtration system to capture microdust and allergens.

## 2. WHAT'S IN THE BOX

Upon unboxing, ensure all components are present:

- Samsung Jet 70 Pet Cordless Stick Vacuum (Main Body)
- Turbo Action Brush
- Long-Reach Crevice Tool
- Combination Tool
- Mini Motorized Tool
- Battery (Lithium-Ion)
- Charging Station / Wall Mount

# What's in the box?



- 1 Vacuum with Turbo Brush
- 2 Combo Brush
- 3 Mini Powered Brush
- 4 Reach/ Crevice tool
- 5 Battery

Image: All components included in the Samsung Jet 70 Pet Cordless Stick Vacuum package.

## 3. SETUP

### 3.1 Assembly

1. **Attach the Extension Pipe:** Insert the extension pipe into the main body of the vacuum until it clicks securely.

2. **Attach the Cleaning Head:** Connect your desired cleaning head (e.g., Turbo Action Brush) to the end of the extension pipe.
3. **Install the Battery:** Slide the Lithium-Ion battery into the designated slot on the main body until it locks into place.

### 3.2 Charging

The Samsung Jet 70 Pet features a convenient 2-in-1 charging station that can be mounted on a wall or used as a freestanding unit.

1. **Mounting (Optional):** Secure the charging station to a wall using appropriate hardware (not included) in a location near a power outlet.
2. **Placing the Vacuum:** Place the assembled vacuum onto the charging station. Ensure the charging contacts align.
3. **Charging Indicator:** The battery indicator lights on the vacuum will illuminate to show charging status. A full charge typically takes approximately 3.5 hours.



## Removable/Reusable Battery

Longer 40-minute run time for uninterrupted cleaning.\*

 3.5 hours Charging time	 Up to 40 min* Cleaning time	 Maintains 70% capacity after 5 years**
--------------------------------------------------------------------------------------------------------------------	-------------------------------------------------------------------------------------------------------------------------	---------------------------------------------------------------------------------------------------------------------------------------

\*Stated run time applies to the minimum power level with a non-motorized tool attached. Spare battery purchased separately.

Image: The 2-in-1 charging station allows for wall-mounted or freestanding charging and accessory storage.

## 4. OPERATING INSTRUCTIONS

### 4.1 Powering On/Off

Press the power button located on the handle to turn the vacuum on or off.

### 4.2 Adjusting Suction Power

The vacuum offers multiple power levels to suit different cleaning needs:

- **Minimum (Min):** Ideal for light cleaning and extending battery life.
- **Mid:** Standard power for everyday cleaning on various surfaces.
- **Max:** Provides maximum suction (up to 150 Air Watts) for deep cleaning on carpets or heavily soiled areas.

Use the '+' and '-' buttons on the handle to cycle through the power settings.

### 4.3 Cleaning Different Surfaces

The Turbo Action Brush is suitable for hard floors, tiles, and carpets. For optimal performance:

- **Hard Floors/Tiles:** Use Mid or Max power for effective dust and debris pickup.
- **Carpets/Rugs:** Max power is recommended for deeper cleaning. The brush is designed to prevent tangles from hair.



## Lightweight Design

Easily maneuver to vacuum stairs, under sofas, or above high cabinets.



### Physical Specification

Dimensions (WxHxD): 9 $\frac{7}{8}$ " x 44 $\frac{3}{4}$ " x 8 $\frac{1}{2}$ "

Weight: 5.73 lbs.

Image: The vacuum demonstrates advanced cleaning performance on hard surfaces.



## Combination Tool

Dusting and upholstery tool picks up dirt on furniture.

Image: The Turbo Action Brush is designed to clean dust, hair, and other debris on multiple surfaces.

## 4.4 Using Attachments

The vacuum can be converted into a handheld unit by detaching the extension pipe. Various tools are included for specialized cleaning:

- **Long-Reach Crevice Tool:** For narrow gaps, corners, and hard-to-reach areas.
- **Combination Tool:** Features a brush and a wide nozzle for versatile cleaning of upholstery, shelves, and delicate surfaces.
- **Mini Motorized Tool:** Specifically designed for pet hair and fine dust on upholstery, stairs, and car interiors.

## 5. MAINTENANCE

### 5.1 Emptying the Dustbin

Regularly empty the 0.8-liter dustbin to maintain optimal suction power. The Jet Cyclone technology helps prevent dirt buildup on the filter.

1. **Detach Dustbin:** Press the release button to detach the dustbin from the main body.
2. **Empty Contents:** Open the dustbin lid and empty the collected debris into a trash receptacle.
3. **Reattach Dustbin:** Securely reattach the dustbin to the vacuum.

## 5.2 Cleaning Filters

The 5-layer filtration system includes washable components to ensure efficient air purification.

- **Main Cyclone & Metal Mesh Grille Filter:** These separate large and medium-sized dust particles. Clean as needed by tapping out debris.
- **Washable Microfilter:** This filter captures fine dust. It is dishwasher safe for convenient cleaning. Ensure it is completely dry before reinserting.
- **Ultra Fine Dust Filter:** Prevents emission of 99.999% of microdust. Clean by tapping out debris.




Image: The 5-layer filtration system captures pet dander, pollen, and microdust.

## 5.3 Brush Head Maintenance

The Turbo Action Brush is designed to be tangle-free. Periodically check the brush head for any entangled hair or debris and remove it manually if necessary.

## 6. TROUBLESHOOTING

If you encounter issues with your Samsung Jet 70 Pet Cordless Stick Vacuum, refer to the following common solutions:

- **No Power:**
  - Ensure the battery is fully charged and correctly inserted.
  - Check if the charging station is properly connected to a power outlet.
- **Reduced Suction:**
  - Empty the dustbin if it is full.
  - Clean all filters (Main Cyclone, Metal Mesh Grille, Washable Microfilter, Ultra Fine Dust Filter).

- Check the extension pipe and cleaning head for blockages.

- **Brush Head Not Rotating:**

- Ensure the brush head is securely attached.
- Remove any hair or debris tangled around the brush roller.

- **Short Battery Life:**

- Battery life is shorter on Max power setting. Use lower settings for longer runtime.
- Ensure the battery is fully charged before use.

For persistent issues, contact Samsung customer support.

## 7. SPECIFICATIONS

Feature	Detail
Brand	Samsung
Model Name	Jet™ 70 Pet Cordless Stick Vacuum
Model Number	VS15T7032R4/AA
Power Source	Battery Powered (Lithium-Ion)
Voltage	21.6 Volts
Wattage	150 watts (Air Watts)
Runtime	Up to 40 minutes (on minimum power level with non-motorized tool)
Battery Charge Time	3.5 Hours
Dustbin Capacity	0.8 Liters
Filtration System	5-Layer, 99.999% microdust filtration
Special Features	Clog Reducing Technology, Lightweight, Washable Filter
Item Weight	5.8 Pounds
Dimensions (L x W x H)	9.8"L x 8.5"W x 44.2"H

## 8. WARRANTY AND SUPPORT

### 8.1 Manufacturer's Warranty

The Samsung Jet 70 Pet Cordless Stick Vacuum comes with a **1-year warranty** covering parts and labor. Please retain your proof of purchase for warranty claims.

### 8.2 Customer Support

For further assistance, technical support, or to inquire about replacement parts, please visit the official Samsung

support website or contact their customer service line. Refer to the product packaging or Samsung's official website for the most current contact information.

**Online Support:** [Samsung Support](#)

