

[Manuals.plus](#) /

› [ICE COOREL](#) /

› ICE COOREL Gaming Laptop Cooling Pad (Model: 6 Fans) - User Manual

ICE COOREL 6 Fans

ICE COOREL Gaming Laptop Cooling Pad (Model: 6 Fans)

User Manual

1. INTRODUCTION

Thank you for choosing the ICE COOREL Gaming Laptop Cooling Pad. This device is designed to enhance your laptop's performance and user comfort by providing efficient cooling and ergonomic adjustability. It features six high-speed fans, customizable RGB lighting, an LCD display for fan speed control, and dual USB ports for connectivity.



Image 1.1: Overview of the ICE COOREL Gaming Laptop Cooling Pad.

2. SAFETY INFORMATION

- Do not expose the cooling pad to water or excessive moisture.
- Avoid placing heavy objects on the cooling pad.

- Keep out of reach of children.
- Use only with compatible laptop sizes (15-17.3 inches).
- Disconnect power before cleaning.
- Do not attempt to disassemble or repair the unit yourself. Contact support if issues arise.

3. SETUP INSTRUCTIONS

1. **Unpack the Cooling Pad:** Carefully remove the cooling pad from its packaging. Ensure all components, including the USB cable, are present.
2. **Position the Cooling Pad:** Place the cooling pad on a stable, flat surface.
3. **Adjust Height (Optional):** The cooling pad offers 6 adjustable height settings for ergonomic comfort. Lift the stand at the rear of the pad and select your desired height. Ensure the stand is securely locked into place.




Image 3.1: Adjusting the height for ergonomic viewing.

4. **Place Your Laptop:** Carefully place your laptop on the cooling pad. The pad is designed for laptops between 15 and 17.3 inches. Utilize the two silicone sleeves for thicker laptops to ensure stability.

5. **Connect Power:** Connect the included USB cable from one of the cooling pad's USB ports to an available USB port on your laptop. This will power the cooling pad.




Image 3.2: Connecting the USB cable for power and utilizing the additional USB port.

6. **Utilize Phone Stand (Optional):** The cooling pad includes a retractable phone stand on the side. Pull it out to hold your mobile phone for convenient access.

4. OPERATING INSTRUCTIONS

The ICE COOREL Gaming Laptop Cooling Pad features an intuitive LCD display and control buttons for managing fan speed and RGB lighting.



Image 4.1: LCD Display and Control Panel.

4.1 Power On/Off

- Press the **Power Button** (🔌) once to turn the cooling pad on or off.

4.2 Adjusting Fan Speed

The cooling pad has multiple fan speed gears, indicated on the LCD screen. The fans operate quietly even at maximum settings.

- Press the **"+" button** to increase the fan speed.
- Press the **"-" button** to decrease the fan speed.
- The LCD screen will display the current fan speed level (e.g., 0-MAX).
- To switch between fan modes (e.g., all fans, specific rows), long-press the **Power Button** for 2-3 seconds. There are 3 fan modes available.



Image 4.2: Six transparent cooling fans providing dynamic cooling.

4.3 Controlling RGB Lighting

The cooling pad features seven RGB light modes to enhance your gaming or work environment.

- Press the **RGB Light Button** (🔌) to cycle through the seven available RGB light modes.
- To turn the RGB lights on or off, press and hold the **RGB Light Button** for 2-3 seconds.



Image 4.3: RGB lighting modes on the cooling pad.

5. MAINTENANCE

- **Cleaning:** Regularly clean the cooling pad to prevent dust accumulation, which can hinder fan performance. Use a soft, dry cloth to wipe down the surfaces. For dust inside the fans, use compressed air.
- **Storage:** When not in use for extended periods, store the cooling pad in a cool, dry place away from direct sunlight.



Image 5.1: The metal mesh surface allows for easy cleaning and optimal airflow.

6. TROUBLESHOOTING

Problem	Possible Solution
Fans are not spinning.	Ensure the USB cable is securely connected to both the cooling pad and your laptop. Verify your laptop's USB port is functional. Try a different USB port. Press the Power Button on the cooling pad to turn it on.
RGB lights are not working.	Press the RGB Light Button to cycle through modes. Long-press the RGB Light Button for 2-3 seconds to ensure they are not turned off. Ensure the cooling pad is receiving power via the USB connection.
Cooling performance is poor.	Increase the fan speed using the "+" button. Ensure the cooling pad's air vents are not obstructed. Clean any dust accumulation on the fans and mesh surface.
Cooling pad is unstable.	Ensure the height adjustment stand is securely locked. Verify your laptop is centered on the pad. Use the provided silicone sleeves if your laptop is thicker.

7. SPECIFICATIONS

Feature	Detail
---------	--------

Feature	Detail
Model	6 Fans
Product Dimensions	16 x 12 x 1.4 inches (40.64 x 30.48 x 3.56 cm)
Item Weight	3 pounds (1360 grams)
Material	Metal
Color	Black
Fan Quantity	6
RGB Light Modes	7
Height Adjustment	6 levels
USB Ports	2 (1 for power input, 1 for external devices)
Compatible Laptop Size	15-17.3 inches




Image 7.1: Product dimensions and laptop size compatibility.

8. WARRANTY AND SUPPORT

8.1 Limited Warranty

This ICE COOREL product is covered by a limited warranty. Please refer to the product packaging or the official ICE COOREL website for specific warranty terms and conditions. Keep your purchase receipt as proof of purchase.

8.2 Customer Support

For technical assistance, troubleshooting not covered in this manual, or warranty inquiries, please visit the official ICE COOREL website or contact their customer service department. Contact information can typically be found on the product packaging or the brand's official online presence.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question