Joyathome Solar Cross Garden Stake

Joyathome Solar Cross Garden Stake Outdoor Lights

Model: Solar Cross Garden Stake

1. Introduction

This manual provides instructions for the proper setup, operation, and maintenance of your Joyathome Solar Cross Garden Stake Outdoor Light. Please read this manual thoroughly before use to ensure optimal performance and longevity of your product.



Image 1.1: The Joyathome Solar Cross Garden Stake illuminated at night, showcasing its decorative warm white LED lights.



Image 1.2: Two Solar Cross Garden Stakes providing gentle illumination in an outdoor remembrance setting.

2. Product Overview and Components

The Joyathome Solar Cross Garden Stake is designed to provide decorative lighting for gardens, yards, or remembrance sites. It features a cross shape formed by 24 LED decorative flowers, powered by an integrated solar panel.

Key Features:

- **Solar Powered:** Automatically charges during the day and illuminates at night.
- **Decorative Design:** Features 24 LED warm white lights arranged in a cross shape with flower accents.
- **Durable Construction:** Made with metal and designed to be waterproof and corrosion-resistant for outdoor use.
- **Easy Installation:** No wiring required; simple assembly and placement.

Components:

1. Cross Light Assembly (with integrated solar panel)
2. Ground Stake




Image 2.1: Close-up view of the product's components, highlighting the luminous flower material, the solar panel, and the secure ground stake design.

3. Setup Instructions

Follow these steps to assemble and install your solar cross garden stake:

1. **Unpack Components:** Carefully remove all parts from the packaging.
2. **Assemble Stake:** Connect the ground stake to the main cross light assembly. Ensure it is securely fastened.
3. **Select Location:** Choose an outdoor location that receives direct sunlight for at least 6-8 hours daily. This is crucial for the solar panel to charge effectively. Avoid areas under trees or shadows from buildings.
4. **Activate Device:** Locate the ON/OFF switch, usually on the underside or back of the solar panel. Slide the switch to the "ON" position.
5. **Install in Ground:** Gently push the assembled stake into the soil. Ensure the solar panel is facing upwards

towards the sun and is not obstructed.




Image 3.1: Product dimensions, showing the total height of approximately 40 inches when fully assembled.

4. Operating Instructions

The Joyathome Solar Cross Garden Stake operates automatically once activated and properly charged.

1. **Initial Charge:** For first-time use, allow the solar light to charge in direct sunlight for a full day (at least 8-10 hours) with the switch in the "ON" position.
2. **Automatic Operation:** The built-in light sensor will automatically turn the lights on at dusk and off at dawn.
3. **Charging:** The solar panel converts sunlight into electricity, which is stored in the rechargeable battery during the day.
4. **Illumination:** At night, the stored energy powers the LED lights, providing illumination for up to 10 hours on a full charge.



Image 4.1: Illustration of the automatic ON/OFF switch functionality, demonstrating daytime charging and nighttime illumination.

5. Maintenance

To ensure your solar cross garden stake continues to function effectively, periodic maintenance is recommended:

- **Clean Solar Panel:** Regularly wipe the solar panel with a soft, damp cloth to remove dust, dirt, or debris. A clean panel ensures maximum sunlight absorption and charging efficiency.
- **Clear Obstructions:** Ensure no leaves, branches, or other objects are blocking the solar panel from direct sunlight.
- **Weather Resistance:** The product is designed to be waterproof and corrosion-resistant, suitable for various outdoor weather conditions including rain, snow, and sun. However, extreme weather conditions may affect performance.
- **Battery Replacement:** The product includes 1 AA battery. If the light duration significantly decreases over time, the rechargeable battery may need replacement. Use only a rechargeable AA battery of the same type and capacity.




Image 5.1: The solar cross light is designed to be resistant to various weather conditions, including rain, snow, and direct sunlight.

6. Troubleshooting

If your solar cross garden stake is not performing as expected, consider the following:

- **Light Does Not Turn On:**
  - Ensure the ON/OFF switch is in the "ON" position.
  - Verify the solar panel is receiving direct sunlight for sufficient charging.
  - Check if the solar panel is dirty or obstructed. Clean if necessary.
  - The battery may be depleted or faulty. Try replacing the rechargeable AA battery.
- **Light Duration is Short:**
  - Ensure the solar panel is exposed to direct sunlight for the maximum duration possible during the day.
  - Environmental factors like cloudy weather or shorter daylight hours in winter can reduce charging efficiency.

- The battery may be aging. Consider replacing the rechargeable AA battery.

- **Light is Dim:**
  - Similar to short duration, ensure adequate charging.
  - Clean the solar panel and the light-emitting surfaces.

7. Specifications

Brand	Joyathome
Model	Solar Cross Garden Stake
Item Weight	1.1 pounds (0.5 Kilograms)
Frame Material	Metal
Light Color	Warm White
Number of Light Sources	24 LED
Recommended Uses	Outdoor (Garden, Grave, Flowerbed, Landscape, Walkway)
Voltage	2 Volts
Batteries	1 AA rechargeable battery (included)
Item Dimensions (L x W x H)	40.9 x 10.43 inches (approximate total height)
UPC	694026800340

8. Warranty and Support

Joyathome provides a worry-free after-sales guarantee for this product. This includes:

- 100% satisfaction guarantee.
- Reliable customer services with 24-hour support for inquiries.
- 100 days free return.
- 360-day free replacement warranty.

For support or warranty claims, please refer to your purchase documentation or contact Joyathome customer service directly through the retailer where the product was purchased.

© 2025 Joyathome. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question