

## Casio AE-1200WH

# Casio AE-1200WH Series Digital Watch Instruction Manual

Model: AE-1200WH-1CVCF

### 1. INTRODUCTION

Thank you for choosing the Casio AE-1200WH Series Digital Watch. This manual provides essential information and instructions to help you set up, operate, and maintain your watch. Please read this manual carefully to ensure proper use and to fully utilize all features of your new timepiece.




Image: Casio AE-1200WH-1CVCF Digital Watch, featuring a black resin band and a multi-function digital display with world map.

## 2. KEY FEATURES

- **World Time:** Displays current time in 48 cities (31 time zones).
- **100M Water Resistance:** Suitable for swimming and snorkeling.
- **Multi-Function Digital Display:** Includes time, date, day of week, and an LC analog display.
- **Five Daily Alarms:** Set up to five independent daily alarms.
- **1/100 Second Stopwatch:** Measures elapsed time, split time, and 1st-2nd place times.
- **Countdown Timer:** Set a timer for specific durations.
- **LED Light with Afterglow:** Illuminates the display for easy reading in low light conditions.
- **10-Year Battery Life:** Extended battery performance for long-term use.



10-Year Battery



100M Water Resistant



Multiple Alarms



World Time

## 3. SETUP

---

### 3.1 Initial Setup

1. Upon first use, ensure any protective films or battery tabs are removed from the watch face and buttons.
2. The watch may display a default time. You will need to set your home city and current time.

### 3.2 Setting Home City and Time

1. In Timekeeping Mode, press and hold the **ADJUST** button (top left) until the city code starts to flash. This indicates the setting mode.
2. Use the **SEARCH** button (bottom right) to scroll through the city codes until your desired home city is displayed.
3. Press the **MODE** button (bottom left) to move to the next setting (e.g., DST, 12/24-hour format, seconds, hour, minute, year, month, day).
4. Use the **SEARCH** button (bottom right) to change the flashing value.
5. Once all settings are correct, press the **ADJUST** button (top left) to exit the setting mode.

## 4. OPERATING MODES

---

Your Casio AE-1200WH watch features several modes accessible via the **MODE** button (bottom left).

### 4.1 Timekeeping Mode

This is the default mode, displaying the current time, date, and day of the week for your home city. The small LC analog display also shows the current time.

### 4.2 World Time Mode

To view times in different cities:

1. From Timekeeping Mode, press the **MODE** button (bottom left) to cycle to World Time Mode.
2. Use the **SEARCH** button (bottom right) to scroll through the available city codes. The world map display will highlight the selected time zone.

3. To return to Timekeeping Mode, press the **MODE** button until the main time display reappears.

Video: Demonstrates the World Time and Illuminator features of the Casio AE-1200 watch, showing how to cycle through different time zones and activate the backlight.

## 4.3 Alarm Mode

Your watch has five independent daily alarms.

1. From Timekeeping Mode, press the **MODE** button (bottom left) to cycle to Alarm Mode.
2. Use the **SEARCH** button (bottom right) to select the desired alarm number (AL1 to AL5).
3. Press and hold the **ADJUST** button (top left) until the alarm time starts to flash.
4. Use the **SEARCH** button to change the hour and minute settings. Press **MODE** to switch between hour and minute.
5. Press **ADJUST** to set the alarm. You can also toggle the hourly time signal (SIG) on/off in this mode.

## 4.4 Stopwatch Mode

The stopwatch measures elapsed time up to 23 hours, 59 minutes, 59.99 seconds.

1. From Timekeeping Mode, press the **MODE** button (bottom left) to cycle to Stopwatch Mode.
2. Press the **START/STOP** button (top right) to start and stop the stopwatch.
3. Press the **ADJUST** button (top left) to reset the stopwatch to zero.

## 4.5 Countdown Timer Mode

The countdown timer can be set for up to 24 hours.

1. From Timekeeping Mode, press the **MODE** button (bottom left) to cycle to Countdown Timer Mode.
2. Press and hold the **ADJUST** button (top left) until the timer setting starts to flash.
3. Use the **SEARCH** button (bottom right) to set the desired countdown time. Press **MODE** to switch between hours and minutes.
4. Press **ADJUST** to set the timer. Press **START/STOP** (top right) to start and stop the countdown.

## 4.6 LED Light (Illuminator)

To illuminate the display:

- Press the **LIGHT** button (top right) to activate the LED backlight. The light will stay on for a few seconds.

Video: Highlights the 10-year battery, 100M water resistance, LED light, stopwatch, and multi-time zone features of the Casio AE-1200 watch.

# 5. MAINTENANCE

## 5.1 Water Resistance

This watch is water resistant to 100 meters (330 feet). This means it is suitable for everyday use, swimming, and snorkeling. It is **not** suitable for scuba diving or prolonged exposure to high-pressure water activities.

- Do not operate buttons while the watch is wet or submerged.
- Avoid exposing the watch to hot water or steam, as this can damage the seals.

## 5.2 Battery Life

The watch is equipped with a long-life lithium metal battery designed to last approximately 10 years. When the

display becomes dim or functions become erratic, it may be time to replace the battery. Battery replacement should be performed by a qualified technician.

5.3 Cleaning

Wipe the watch regularly with a soft, dry cloth to remove dirt and moisture. For resin bands, you can use a mild soap solution and rinse thoroughly, then dry completely. Avoid using harsh chemicals or abrasive cleaners.

6. TROUBLESHOOTING

- **Display is blank or dim:** The battery may be low. Replace the battery.
- **Time is incorrect:** Re-set the home city and current time as described in Section 3.2. Ensure Daylight Saving Time (DST) settings are correct for your region.
- **Buttons are unresponsive:** Ensure the watch is not wet. If the issue persists, a reset may be required (refer to the full Casio module manual for specific reset procedures).


7. SPECIFICATIONS


- **Model Number:** AE-1200WH-1CVCF
- **Case Dimensions:** 39.5 mm (width)
- **Product Dimensions:** 9.84 x 1.57 x 0.79 inches
- **Weight:** 4.97 ounces
- **Water Resistance:** 100 meters (330 feet)
- **Movement:** Japanese Quartz
- **Battery Type:** 1 Lithium Metal battery (included)
- **Battery Life:** Approximately 10 years
- **Case Material:** Resin
- **Dial Window Material:** Mineral

8. WARRANTY AND SUPPORT

For warranty information, detailed troubleshooting, or further assistance, please refer to the official Casio website or contact Casio customer support. Keep your purchase receipt as proof of purchase for warranty claims.


Related Documents - AE-1200WH

	<p><a href="#">Casio LAW-21 Модуль 2789: Руководство пользователя и характеристики</a></p> <p>Полное руководство пользователя для часов Casio LAW-21 (Модуль 2789). Содержит инструкции по эксплуатации, уходу, описания режимов работы (текущее время, мировое время, таймер, секундомер, будильник) и технические характеристики.</p>
	<p><a href="#">Casio ECW-M100 Watch User Manual</a></p> <p>Comprehensive user manual for the Casio ECW-M100 watch, detailing its features, operation, water resistance, alarms, stopwatch, world time, and technical specifications. Includes instructions for setting time, alarms, and using various modes.</p>




[Casio 3202 Operation Guide: Multi-function Watch with Barometer, Altimeter, Thermometer](#)

This is the official operation guide for the Casio 3202 multi-function digital watch. Learn how to use its advanced features including barometer, thermometer, altimeter, world time, stopwatch, countdown timer, and alarm functions. Essential reading for owners.



[Casio 5161 Operation Guide: Master Your Watch](#)

Comprehensive operation guide for the Casio 5161 watch, covering setup, features like atomic timekeeping and world time, alarms, stopwatch, and power management.



[Casio Watch Model 3458 Operation Guide](#)

Comprehensive operation guide for the Casio Watch Model 3458, covering timekeeping, world time, alarms, countdown timer, stopwatch, and reference information.



[CASIO 5176 Operation Guide: Features, Functions, and Specifications](#)

Comprehensive operation guide for the CASIO 5176 watch, detailing its features like barometer, thermometer, altimeter, world time, stopwatch, alarms, and specifications. Learn how to use all functions for outdoor activities.