

[Manuals.plus](#) /

› [AR Blue Clean](#) /

› AR Blue Clean e-2000 HRD High Pressure Washer User Manual

AR Blue Clean e-2000 HRD

AR Blue Clean e-2000 HRD High Pressure Washer User Manual

Model: e-2000 HRD

1. INTRODUCTION

This manual contains important information regarding the safe operation, maintenance, and troubleshooting of your AR Blue Clean e-2000 HRD High Pressure Washer. Please read it thoroughly before using the appliance and keep it for future reference. Proper use and maintenance will ensure optimal performance and extend the life of your pressure washer.

The AR Blue Clean e-2000 HRD is designed for cleaning resistant dirt on outdoor domestic surfaces, gates, benches, garden furniture and tools, bicycles, motorcycles, cars, campers, stairs, and swimming pools.



Figure 1.1: Front view of the AR Blue Clean e-2000 HRD High Pressure Washer.

2. PRODUCT FEATURES

- **Italian Design and Development:** Engineered and developed in Italy by Annovi Reverberi S.p.A., featuring exclusive equipment and design.
- **Powerful Performance:** Maximum pressure of 150 bar, absorbed power of 2.0 kW, and a maximum flow rate of 440 liters per hour. Supports water supply temperatures up to 50°C.
- **Versatile Applications:** Ideal for cleaning stubborn dirt from various outdoor surfaces including gates, benches, garden furniture, bicycles, motorcycles, cars, campers, stairs, and pools.
- **Self-Priming Function:** Capable of drawing water from an external tank if connection to the main water supply is not possible.
- **Automatic Shut-off (Total Stop System):** The pressure washer stops automatically when the gun lever is released, saving energy and increasing the machine's lifespan.

3. PACKAGE CONTENTS

Verify that all components are present and undamaged upon unpacking. The package includes:

- High Pressure Washer Unit
- Gun
- Lance
- Rotating Jet Nozzle

- Adjustable Jet Nozzle
- High-Pressure Foam Kit (1 liter)
- High-Pressure Hose (8 meters)
- Drain Cleaning Hose (6 meters)
- Patio Cleaner

ACCESSORI INCLUSI



1. Pistola
2. Prolunga lancia
3. Ugello rotante
4. Ugello regolabile

5. Tubo alta pressione
6. Kit schiumogeno
7. Lavapavimenti
8. Sonda sturatubi

Figure 3.1: All included accessories for the AR Blue Clean e-2000 HRD High Pressure Washer.

4. SETUP INSTRUCTIONS

4.1 Assembly

1. **Attach the Handle:** Secure the ergonomic handle to the main unit.
2. **Connect High-Pressure Hose:** Connect one end of the 8-meter high-pressure hose to the pressure washer's outlet and the other end to the gun. Ensure connections are tight.
3. **Attach Lance and Nozzle:** Insert the lance into the gun, then attach the desired nozzle (rotating or adjustable jet)

to the lance.

4. **Water Inlet Connection:** Connect a garden hose to the water inlet filter on the pressure washer. Ensure the water supply is clean and free of debris.
5. **Power Connection:** Plug the power cord into a suitable electrical outlet.



Figure 4.1: Detail of the pressure washer's main components, including the ergonomic handle, rotary selector, and water inlet filter.

4.2 Self-Priming Function

If a direct water supply connection is not available, the pressure washer can draw water from an external tank. To use this function:

1. Place the external tank on a stable surface, ensuring it is filled with clean water.
2. Connect a suitable suction hose (not included) to the water inlet of the pressure washer and immerse the other end into the water tank.
3. Ensure all air is purged from the system before starting the unit.



Figure 4.2: Diagram showing the pressure washer drawing water from an external tank using the self-priming function.

5. OPERATING INSTRUCTIONS

5.1 Starting the Pressure Washer

1. Ensure all connections are secure and the water supply is turned on.
2. Turn the rotary selector switch to the "ON" position.
3. Squeeze the gun trigger to release any trapped air and allow water to flow through until a steady stream is achieved.
4. The motor will start, and the unit will be ready for use.



IDEALE PER LA PULIZIA DELL'ESTERNO CASA, CANCELLATE, PANCHINE, SCALE, PAVIMENTI, PISCINE, BICICLETTE, MOTO, AUTO E CAMPER

Figure 5.1: The pressure washer in operation, cleaning a motorcycle.

5.2 Using Accessories

- **Rotating Jet Nozzle:** Provides a powerful, concentrated stream for removing stubborn dirt.
- **Adjustable Jet Nozzle:** Allows adjustment from a concentrated stream to a wide fan spray for various cleaning tasks.
- **High-Pressure Foam Kit:** Fill the container with appropriate detergent. Attach to the gun for applying foam.
- **Drain Cleaning Hose:** Insert the nozzle end into the drain. The high-pressure water will propel the hose and clear blockages.
- **Patio Cleaner:** Attach to the gun for efficient and splash-free cleaning of flat surfaces like patios and driveways.



Figure 5.2: The drain cleaning hose accessory for clearing blockages.



Figure 5.3: The Patio Cleaner accessory for cleaning large flat surfaces.



Figure 5.4: The high-pressure foam kit for detergent application.

5.3 Shutting Down

1. Release the gun trigger. The Total Stop System will automatically shut off the motor.
2. Turn the rotary selector switch to the "OFF" position.
3. Turn off the water supply.
4. Squeeze the gun trigger to release any remaining pressure in the system.
5. Unplug the power cord.

6. MAINTENANCE

Regular maintenance ensures the longevity and efficient operation of your pressure washer.

- **Water Inlet Filter:** Regularly inspect and clean the water inlet filter to prevent debris from entering the pump.
- **Nozzle Cleaning:** If the spray pattern becomes irregular or pressure drops, clean the nozzle orifice with the provided needle tool.
- **Hose and Connections:** Check hoses and connections for leaks or damage before each use. Replace damaged parts immediately.
- **Storage:** Before storing, especially in freezing temperatures, ensure all water is drained from the pump and hoses.

to prevent damage. Store the unit in a dry, protected area.



Figure 6.1: Back view of the pressure washer, showing the hose reel and accessory storage for organized maintenance.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Motor does not start	No power supply; Power switch off; Thermal protector activated	Check power connection; Turn power switch on; Allow motor to cool down
No water pressure or low pressure	Water supply off; Inlet filter clogged; Air in pump; Nozzle clogged	Turn on water supply; Clean inlet filter; Purge air from pump; Clean nozzle
Pulsating pressure	Air in pump; Nozzle partially clogged; Water supply insufficient	Purge air from pump; Clean nozzle; Ensure adequate water supply

Problem	Possible Cause	Solution
Water leaks	Loose connections; Damaged O-rings or seals	Tighten connections; Replace damaged O-rings or seals

If problems persist after attempting these solutions, please contact customer support.

8. SPECIFICATIONS

- **Brand:** AR Blue Clean
- **Model Number:** e-2000 HRD
- **Power Source:** Corded Electric
- **Color:** Blue
- **Item Weight:** 14450 Grams (14.45 kg)
- **Hose Length:** 8 Meters
- **Product Dimensions (L x W x H):**38L x 32.5W x 82.1H cm
- **Tank Volume:** 440 Liters (Note: This specification likely refers to the maximum flow rate, not an internal tank volume.)
- **Maximum Flow Rate:** 440 Liters per hour
- **Maximum Pressure:** 150 bar (2175 PSI)
- **Absorbed Power:** 2.0 kW
- **Maximum Water Supply Temperature:** 50°C

9. WARRANTY AND SUPPORT

For detailed warranty information, please refer to the official warranty document included with your product packaging or visit the AR Blue Clean official website. For technical support or spare parts, please contact AR Blue Clean customer service.

A digital copy of the installation manual is available[here](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question