

[Manuals.plus](#) /

› [NORDISK](#) /

› NORDISK Midgard 9.2 Tent Instruction Manual

NORDISK Midgard 9.2

NORDISK Midgard 9.2 Tent Instruction Manual

Model: 242031

1. INTRODUCTION

Thank you for choosing the NORDISK Midgard 9.2 Tent. This manual provides essential information for the safe and effective use of your tent. The Midgard 9.2 is a versatile 6-person tent designed for various outdoor conditions, featuring a unique two-pole structure that maximizes internal space and four large entrances for excellent ventilation and accessibility. Constructed from durable technical cotton, it is suitable for year-round use. The integrated floor simplifies setup and offers enhanced protection against the elements.



Image 1.1: The NORDISK Midgard 9.2 tent, showcasing its distinctive shape and overall design.

2. SAFETY INSTRUCTIONS

- **Fire Safety:** Keep all flame and heat sources away from the tent fabric. The tent is not fireproof.
- **Ventilation:** Ensure adequate ventilation, especially when using cooking equipment or heaters inside the tent, to prevent carbon monoxide poisoning.
- **Site Selection:** Choose a flat, clear area free from sharp objects. Avoid pitching under trees with dead branches or in areas prone to flash floods.
- **Weather Conditions:** In strong winds or heavy rain, ensure all guy ropes are securely fastened and pegs are firmly in the ground. Disassemble the tent if extreme weather is expected.
- **Children:** Supervise children around the tent to prevent accidents.

3. PACKAGE CONTENTS

Before setup, verify that all components are present:

- Tent Body (Flysheet with integrated floor)
- Main Poles (2)
- Pegs

- Guy Ropes
- Carry Bag

4. SETUP INSTRUCTIONS

The NORDISK Midgard 9.2 tent features a freestanding design with a two-pole structure for straightforward assembly.

1. **Unpack and Lay Out:** Remove the tent from its carry bag and lay the tent body flat on your chosen pitch site. Ensure the integrated floor is spread evenly.
2. **Assemble Poles:** Connect the pole sections to form the two main poles.
3. **Insert Poles:** Locate the pole sleeves or attachment points on the tent. Insert the assembled poles into their designated positions. The Midgard 9.2 uses a two-pole system, avoiding a central pole to maximize internal space.
4. **Raise the Tent:** Once both poles are in place, carefully raise the tent structure.
5. **Secure the Base:** Peg down the corners and sides of the tent's integrated floor firmly into the ground.
6. **Attach Guy Ropes:** Extend and peg out all guy ropes to provide stability and tension to the tent. Adjust the tension as needed to ensure the tent is taut and stable.
7. **Check Entrances:** Ensure all four entrances can be opened and closed smoothly.




Image 4.1: A diagram illustrating the dimensions and internal layout of the Midgard 9.2 tent, including space for occupants.

The Midgard 9.2 tent is designed to be linked with a NORDISK Vimur tent using a zipper, expanding your living space. Refer to the Vimur manual for specific linking instructions.

5. OPERATING INSTRUCTIONS (USAGE)

The Midgard 9.2 tent is designed for comfort and versatility in various outdoor settings.

- **Entrances:** The tent features four large entrances, allowing for flexible entry and exit points and excellent cross-ventilation. Each entrance can be zipped open or closed as needed.

- **Ventilation:** Utilize the multiple entrances and any integrated vents to manage airflow and minimize condensation inside the tent. Opening entrances on opposite sides can create a refreshing breeze.
- **Internal Space:** The two-pole structure eliminates a central pole, providing an unobstructed and spacious interior, ideal for up to 6 people. The height of 270cm offers ample headroom.
- **Year-Round Use:** The technical cotton material provides breathability in warm weather and insulation in cooler conditions, making the tent suitable for all seasons.



Image 5.1: The Midgard 9.2 tent with all four entrances open, demonstrating its spacious design and ventilation capabilities.



Image 5.2: An interior view of the Midgard 9.2 tent, showing ample space for sleeping pads and gear, highlighting the absence of a central pole.

6. MAINTENANCE

Proper maintenance will extend the lifespan of your NORDISK Midgard 9.2 Tent.

- **Cleaning:** Clean the tent using a soft brush and lukewarm water. Avoid harsh detergents or washing machines, as this can damage the waterproof coating and fabric. The manufacturer recommends hand washing.
- **Drying:** Always ensure the tent is completely dry before packing it away. Packing a damp tent can lead to mildew, odor, and fabric degradation. Air dry in a shaded, well-ventilated area.
- **Storage:** Store the tent in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Zipper Care:** Keep zippers clean and free of dirt. Lubricate occasionally with a silicone-based zipper lubricant to ensure smooth operation.
- **Technical Cotton Care:** Technical cotton benefits from being 'seasoned' by getting wet and drying a few times,

which allows the cotton fibers to swell and seal the weave, enhancing its natural water resistance.

7. TROUBLESHOOTING

Here are solutions to common issues you might encounter:

- **Condensation:** Ensure proper ventilation by opening vents and entrances. Condensation is natural, especially in humid conditions or with many occupants.
- **Tent Instability:** Re-check all pegs and guy ropes. Ensure they are taut and securely anchored. In windy conditions, consider adding extra guy ropes or using stronger pegs.
- **Leaking:** While the floor is 100% waterproof and the flysheet is 350mm water-resistant, prolonged heavy rain or damaged fabric can lead to leaks. Inspect seams and fabric for damage. Ensure the tent is pitched correctly to allow water runoff.
- **Zipper Snagging:** Gently pull the fabric away from the zipper teeth while operating. Keep zippers clean.

8. SPECIFICATIONS

Feature	Detail
Brand	NORDISK
Model	Midgard 9.2
Model Number	242031
Material (Flysheet)	Technical Cotton (35% Cotton, 65% Polyester)
Material (Floor)	150D Tarpaulin
Water Pressure Resistance (Flysheet)	350 mm
Water Resistance (Floor)	100% Waterproof
Size (L x W x H)	303 x 303 x 270 cm
Weight	Approx. 29 kg
Occupancy	6 people
Season	All-season (4-season)
Shape	Triangular (Pyramid)
Mounting Type	Freestanding
Fastener Type	Zipper
Special Features	Waterproof
Color	Natural

9. WARRANTY AND SUPPORT

Warranty information for the NORDISK Midgard 9.2 Tent is not explicitly provided in the product details. For specific warranty terms and conditions, please refer to the official NORDISK website or contact your retailer directly. For product support, technical assistance, or inquiries regarding parts, please contact the NORDISK customer service department or the authorized dealer from whom you purchased the tent. Keep your proof of purchase handy when contacting support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question