Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

MEEDEN AFB-6048-YM

MEEDEN 10-Drawer Artist Supply Storage Box

Model: AFB-6048-YM

Introduction

The MEEDEN 10-Drawer Artist Supply Storage Box is a versatile and elegant solution for organizing a wide array of art supplies. Crafted from high-quality, hand-sanded beechwood with durable finger-joint construction, this storage box is designed to keep your pastels, pencils, pens, markers, brushes, and other tools neatly categorized and easily accessible. Its robust design ensures longevity and provides a beautiful addition to any studio or workspace.



Figure 1: The MEEDEN 10-Drawer Artist Supply Storage Box, showcasing its natural beechwood finish and compact design.

Setup

The MEEDEN 10-Drawer Artist Supply Storage Box comes fully assembled, requiring no complex setup. Simply unpack the unit from its packaging and place it on a stable, flat surface in your desired workspace. Ensure the surface can support the weight of the box and its contents (approximately 13.6 pounds empty, plus the weight of your supplies).




Figure 2: Product dimensions for optimal placement. The box measures 15.75 inches in width, 9.75 inches in depth, and 10.75 inches in height.

Operating Instructions

The storage box features ten smooth-gliding drawers, each with five fixed compartments designed to help organize various art materials. The drawers are fully removable, allowing you to bring specific sets of supplies closer to your work area for convenience.

- **Accessing Drawers:** Gently pull the brass knob on each drawer to slide it open. The smooth mechanism ensures easy access to your supplies.
- **Organizing Supplies:** Utilize the five compartments within each drawer to separate different types or colors of art supplies. This helps maintain order and makes finding specific items quick and efficient.
- **Removing Drawers:** For extended use or to transport a specific set of supplies, simply pull the drawer completely

out of its slot. This allows for flexible arrangement of your workspace.

- **Replacing Drawers:** Align the drawer with its corresponding slot and gently push it back into the main unit until it is flush.



Figure 3: Multiple drawers open, demonstrating the ample storage capacity and organizational potential for different art mediums.



Figure 4: A closer look at the fully removable drawers, allowing for convenient access and arrangement of supplies during creative work.

Maintenance

Proper care will ensure the longevity and continued aesthetic appeal of your MEEDEN Artist Supply Storage Box.

- **Cleaning:** Wipe the exterior and interior surfaces with a dry, soft cloth. Avoid using abrasive cleaners or harsh chemicals, as these can damage the polished beechwood finish.
- **Dusting:** Regularly dust the box to prevent accumulation, especially within the drawer compartments.
- **Wood Care:** As the box is made of natural beechwood, avoid prolonged exposure to direct sunlight or extreme humidity, which can cause warping or discoloration.
- **Hardware:** The high-quality galvanized hardware is designed to be rust-resistant. If needed, gently wipe the brass knobs with a dry cloth to maintain their shine.



Figure 5: The storage box is constructed from FSC-certified German Beechwood, known for its durability and fine grain.



Figure 6: Detail of the high-quality galvanized brass hardware, designed for durability and rust resistance.

Troubleshooting

Problem	Possible Cause	Solution
Drawers feel stiff or do not slide smoothly.	Dust or debris in the drawer tracks; minor wood expansion/contraction.	Remove the drawer and wipe the tracks clean with a dry cloth. Ensure no foreign objects are obstructing the path. If wood expansion is suspected, ensure the box is in a stable environment with consistent temperature and humidity.

Problem	Possible Cause	Solution
Drawers appear loose or slide out too easily.	Natural variation in wood fit; product design for full removability.	This is often a characteristic of the design, allowing for full drawer removal. If excessive, ensure the box is on a perfectly level surface. For delicate items, consider adding a thin, non-slip liner to the bottom of the drawers.
Minor cosmetic imperfections (e.g., small splinters).	Natural wood characteristics; minor manufacturing variations.	Gently sand the affected area with fine-grit sandpaper (220-grit or higher) if necessary. Wipe clean with a dry cloth.

Specifications

Feature	Detail
Brand	MEEDEN
Model Number	AFB-6048-YM
Color	Beechwood
Material	Beech Wood
Product Dimensions (W x D x H)	15.75" x 9.75" x 10.75" (40cm x 24.7cm x 27.3cm)
Number of Drawers	10
Assembly Required	No
Item Weight	13.6 pounds (6.17 kg)
Finish Type	Polished
Care Instructions	Wipe with Dry Cloth

Warranty and Support

MEEDEN stands behind the quality of its products. If you are not satisfied with your MEEDEN 10-Drawer Artist Supply Storage Box for any reason, you may return it for a prompt, no-hassle refund or replacement.
For further assistance or to explore more MEEDEN products, please visit the official MEEDEN Store:

Visit the MEEDEN Store

© 2025 MEEDEN. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B087ZGFL7L

More documents and user manuals: **https://manuals.plus/**