

[Manuals.plus](#) /

› [XIAOMI](#) /

› XIAOMI Mi Robot Vacuum-Mop P Water Tank 550 MI Instruction Manual (Model SKV4124TY)

XIAOMI SKV4124TY

XIAOMI Mi Robot Vacuum-Mop P Water Tank 550 MI

INSTRUCTION MANUAL (MODEL: SKV4124TY)

Introduction

This manual provides essential instructions for the proper use, installation, and maintenance of your XIAOMI Mi Robot Vacuum-Mop P Water Tank 550 MI. Please read this manual thoroughly before using the product to ensure optimal performance and longevity. This water tank is designed as a replacement or spare part for the Mi Robot Vacuum-Mop P.

Safety Information

- Ensure the water tank is correctly installed before operating the robot vacuum.
- Use only clean, filtered water in the tank. Do not add detergents, cleaning solutions, or essential oils, as these may damage the robot's internal components or clog the water outlets.
- Do not submerge the entire water tank in water for cleaning. Refer to the 'Maintenance' section for proper cleaning procedures.
- Keep out of reach of children.
- If the water tank appears damaged or leaks, discontinue use immediately and replace it.

Package Contents

- 1 x Mi Robot Vacuum-Mop P Water Tank (550 MI)

Product Overview

Familiarize yourself with the components of your new water tank.



Figure 1: Top view of the water tank, showing the main body and the water fill cap with a droplet icon.



Figure 2: Side view of the water tank, highlighting its transparent section for easy water level monitoring.



Figure 3: Bottom view of the water tank, illustrating the attachment pins that secure it to the robot vacuum.



Figure 4: Close-up of the water fill cap, showing the mechanism for opening and closing the water inlet.

Setup

1. **Remove Old Tank (if applicable):** If replacing an existing water tank, gently press the release button or mechanism on your Mi Robot Vacuum-Mop P to detach the old tank.
2. **Open Water Fill Cap:** Locate the water fill cap on the top of the new water tank (refer to Figure 1 and Figure 4). Open it by lifting or sliding the cap.
3. **Fill with Water:** Carefully fill the tank with clean, filtered water. Do not exceed the maximum fill line, if indicated. Avoid using hot water.
4. **Close Water Fill Cap:** Securely close the water fill cap to prevent leaks during operation.
5. **Install Tank:** Align the water tank with the designated slot on your Mi Robot Vacuum-Mop P. Gently push it into place until you hear a click, indicating it is securely attached. Ensure the attachment pins (Figure 3) are properly seated.

Operating Instructions

Once the water tank is filled and installed, the Mi Robot Vacuum-Mop P will automatically detect its presence and enable mopping functions. Refer to your Mi Robot Vacuum-Mop P's main instruction manual for specific operating modes and settings related to mopping.

- **Water Flow Control:** Water flow is typically controlled via the Mi Home app settings for your robot vacuum. Adjust the water level according to your floor type and cleaning needs.
- **Monitoring Water Level:** Periodically check the water level through the transparent section of the tank (Figure 2) to ensure sufficient water for cleaning tasks.
- **Refilling:** When the water level is low, remove the tank, refill it as described in the 'Setup' section, and reattach it to the robot.

Maintenance

Regular maintenance ensures the water tank functions correctly and prevents issues.

- **Empty After Use:** It is recommended to empty any remaining water from the tank after each mopping session to prevent stagnant water and potential odor buildup.
- **Rinse Regularly:** Rinse the inside of the water tank with clean water periodically.
- **Clean Water Outlets:** If you notice reduced water flow, inspect the small water outlets on the bottom of the tank for any blockages. Use a soft brush or cloth to gently clear them. Do not use sharp objects.
- **Air Dry:** After cleaning, allow the water tank to air dry completely before storing or refilling.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, solvents, or harsh chemicals on the water tank, as these can damage the plastic.

Troubleshooting

- **No Water Dispensing:**
 - Ensure the water tank is properly filled and securely installed.
 - Check if the water outlets on the bottom of the tank are clogged. Clean them if necessary.
 - Verify that the mopping function is enabled in the robot's app settings.
- **Water Leakage:**
 - Ensure the water fill cap is securely closed.
 - Check if the water tank is correctly seated and clicked into place on the robot.
 - Inspect the tank for any cracks or damage. If damaged, replace the tank.
- **Odor from Tank:**
 - Empty and thoroughly rinse the tank with clean water. Allow it to air dry completely.
 - Always empty the tank after each use to prevent stagnant water.

Specifications

Brand	XIAOMI
Model Name	SKV4124TY
Capacity	550 Milliliters (Note: Product description states 550ml, specifications state 300ml. Please verify with product packaging.)

Included Components	Water Tank
Item Weight	328.8 Grams
Compatible Devices	Mi Robot Vacuum-Mop P

Warranty and Support

This product comes with a manufacturer's warranty. Please refer to your purchase documentation or the official XIAOMI website for detailed warranty terms and conditions.

Manufacturer Warranty Description: 1 year.

For technical support or service inquiries, please contact XIAOMI customer service through their official channels.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question

Open the live page

<https://manuals.plus/asin/B0881PKPH5>

More documents and user manuals: <https://manuals.plus/>