

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Intel](#) /
- › [Intel XEON E-2224G 3.5GHz Processor Instruction Manual](#)

Intel CM8068404173806

Intel XEON E-2224G 3.5GHz Processor Instruction Manual

Model: CM8068404173806

INTRODUCTION

This manual provides essential information for the installation, operation, maintenance, and troubleshooting of your Intel XEON E-2224G 3.5GHz processor. The Intel XEON E-2224G is a high-performance CPU designed for server and workstation environments, offering robust processing capabilities for demanding applications.



Image: Intel XEON inside logo, indicating the processor's brand and series.

SETUP AND INSTALLATION

Proper installation is crucial for the optimal performance and longevity of your processor. Always handle the CPU with care, touching only the edges to avoid damaging the contacts or integrated heat spreader (IHS).

1. **Compatibility Check:** Ensure your motherboard supports the Intel XEON E-2224G processor and has an LGA 1151 socket. Refer to your motherboard's documentation for CPU compatibility.
2. **Prepare the Motherboard:** Open the CPU socket retention lever on the motherboard. Carefully lift the load plate.
3. **Install the Processor:** Align the triangular mark on the processor with the corresponding mark on the CPU socket. Gently place the processor into the socket without forcing it. The processor should sit flat in the socket.
4. **Secure the Processor:** Close the load plate over the processor and push down the retention lever until it locks into place.
5. **Apply Thermal Paste:** Apply a small amount of high-quality thermal paste to the center of the processor's IHS. This ensures efficient heat transfer to the CPU cooler.
6. **Install CPU Cooler:** Mount the compatible CPU cooler according to its manufacturer's instructions. Ensure it makes firm, even contact with the processor's IHS. Connect the CPU cooler fan to the designated header on the motherboard.



Image: Bottom view of the Intel XEON E-2224G processor, displaying the contact pads that interface with the motherboard socket. Handle with care to avoid damage.



Image: Combined view of the Intel XEON E-2224G processor, showing both the top (with Intel logo) and bottom (with contact pads) surfaces. This illustrates the overall physical appearance of the CPU.

OPERATING GUIDELINES

Once installed, the Intel XEON E-2224G processor operates automatically within your system. Key considerations for optimal operation include:

- **BIOS/UEFI Configuration:** After initial installation, enter your system's BIOS/UEFI settings to verify that the processor is recognized correctly. Ensure that all system settings, including memory and power management, are configured appropriately for your hardware.
- **Thermal Management:** Monitor CPU temperatures using system monitoring software. Ensure that the CPU cooler is functioning correctly and that airflow within the computer case is adequate to prevent overheating. High temperatures can lead to performance throttling or system instability.
- **Driver Updates:** Keep your motherboard chipset drivers and operating system updated to ensure full compatibility and optimal performance with the processor.

MAINTENANCE

Regular maintenance helps ensure the longevity and stable performance of your Intel XEON E-2224G processor.

- **Dust Removal:** Periodically clean dust from the CPU cooler heatsink and fan using compressed air. Dust accumulation can impede airflow and reduce cooling efficiency.
- **Thermal Paste Inspection:** Every few years, or if you notice increased CPU temperatures, consider reapplying thermal paste. Old thermal paste can dry out and lose effectiveness. This requires carefully removing the CPU cooler, cleaning off old paste, and applying new paste.
- **System Airflow:** Ensure that your computer case has good airflow. Keep intake and exhaust vents clear of obstructions.

TROUBLESHOOTING

If you encounter issues with your system after installing the Intel XEON E-2224G processor, consider the following troubleshooting steps:

- **No Display/System Not Booting:**

- Verify that the CPU is correctly seated in the socket and the retention lever is locked.
- Ensure the CPU power connector from the power supply is securely plugged into the motherboard.
- Check RAM modules for proper seating.
- Clear the CMOS (Complementary Metal-Oxide-Semiconductor) settings on your motherboard.

- **Overheating Issues:**

- Confirm the CPU cooler is properly installed and making good contact with the CPU.
- Check if the CPU cooler fan is spinning.
- Ensure adequate thermal paste application.
- Improve case airflow by cleaning dust and managing cables.

- **System Instability/Crashes:**

- Update motherboard BIOS/UEFI to the latest version.
- Run memory diagnostic tools to check for RAM issues.
- Ensure power supply unit (PSU) provides sufficient and stable power.

If problems persist, consult your motherboard's manual or Intel's official support resources.

SPECIFICATIONS

Feature	Detail
Brand	Intel
Model Number	CM8068404173806
CPU Manufacturer	Intel
CPU Model	Quad Core Xeon E-2224G
CPU Speed	3.5 GHz
CPU Socket	LGA 1151
Item Weight	0.705 ounces
ASIN	B0882HXDGY
Date First Available	April 22, 2020

WARRANTY AND SUPPORT

Intel processors typically come with a limited warranty. For specific warranty terms and conditions, please refer to the official Intel website or the documentation included with your purchase.

For technical assistance, driver downloads, and additional support resources, visit the official Intel Support website:

[Intel Official Support](#)

When contacting support, have your processor model number (CM8068404173806) and any relevant system

information ready.