

[Manuals.plus](#) /

> [AMACOOOL](#) /

> AMACOOOL F320 10000mAh Battery Operated Camping Fan with LED Light - User Manual

## AMACOOOL F320

# AMACOOOL F320 10000mAh Battery Operated Camping Fan with LED Light - User Manual

## INTRODUCTION

---

This manual provides detailed instructions for the safe and efficient operation of your AMACOOOL F320 10000mAh Battery Operated Camping Fan with LED Light. Please read this manual thoroughly before use and retain it for future reference.



The AMACOOOL F320 10000mAh Battery Operated Camping Fan with LED Light.

## PRODUCT FEATURES

- **High Capacity Battery:** Equipped with a built-in 10000mAh polymer battery, providing up to 35 hours of operation at low speed and 8 hours at highest speed. The fan is rechargeable and can also be powered via a USB cable from a 5V/2A power source or AC adapter.
- **Adjustable Airflow:** Features a 7-inch fan head with 3 wind speeds. The powerful yet quiet motor allows for 360-degree rotation (left to right, up and down) to circulate air from any desired angle without causing disturbance.
- **Versatile Placement:** Includes a foldable hook on the bottom for hanging in tents, on branches, or inside vehicles. It can also be wall-mounted or placed on a desk.
- **Integrated LED Lighting:** Contains 12 bright white LEDs with 3 brightness settings. Use the brightest mode as a lantern for camping, or a dimmer setting as a nightlight.
- **Portable Design:** Compact size (6.29 x 2.36 x 8.49 inches) and lightweight (1 lb) for easy carrying and storage, making it suitable for daily use, camping, travel, and emergency situations.



**Built in 10000mAh  
Rechargeable Battery  
Last up to 35H**

The AMACOOOL F320 features a 10000mAh battery for extended use.

# Hanging Hook & 3 Brightness



The integrated hanging hook and adjustable LED light brightness.

## PACKAGE CONTENTS

---

Please check the package for the following items:

- 1 x AMACOOOL F320 Camping Fan with LED Light
- 1 x USB Charging Cable
- 1 x User Manual

## SETUP

---

### Initial Charging

Before first use, fully charge the fan. Connect the provided USB charging cable to the fan's Micro USB port and to a 5V/2A power source (e.g., wall adapter, power bank, computer USB port). The charging indicator light will show the charging status.

### Placement Options

- **Desktop Use:** Place the fan on a flat, stable surface. Adjust the fan head to your desired angle.

- **Hanging Use:** Unfold the integrated hook located on the bottom of the fan's base. Hang the fan from a tent loop, branch, or any suitable fixture. Ensure the hook is securely fastened.
- **Wall Mounting:** The fan can be mounted on a wall using appropriate hardware (not included) through the designated mounting holes on the base.



The fan head can be rotated 360 degrees for optimal airflow.

### Video: Demonstrating Hanging Feature

Your browser does not support the video tag.

This video demonstrates how to utilize the integrated hanging hook for versatile placement.

## OPERATING INSTRUCTIONS

### Fan Operation

1. **Power On/Off:** Press the fan button (usually marked with a fan icon) once to turn on the fan at low speed.
2. **Adjust Speed:** Press the fan button repeatedly to cycle through the 3 available wind speeds (Low > Medium > High).

3. **Power Off:** After the highest speed, pressing the button again will turn the fan off.

## LED Light Operation

1. **Power On/Off:** Press the light button (usually marked with a light bulb icon) once to turn on the LED light at the lowest brightness setting.
2. **Adjust Brightness:** Press the light button repeatedly to cycle through the 3 available brightness settings (Low > Medium > High).
3. **Power Off:** After the highest brightness, pressing the button again will turn the LED light off.

## Charging the Fan

When the battery is low, the indicator light will change color (e.g., from blue to red). Connect the fan to a 5V/2A power source using the provided USB cable. The indicator light will show charging status and turn solid when fully charged.



The fan features a USB-C port for convenient charging.

## Video: Demonstrating Fan and Light Operation

Your browser does not support the video tag.

This video illustrates the fan speed and LED light adjustments.

## MAINTENANCE

---

### Cleaning

- Ensure the fan is turned off and unplugged before cleaning.
- Use a soft, dry cloth to wipe the exterior of the fan.
- To clean the fan blades, carefully remove the front grille (if detachable, refer to product diagrams for specific instructions) and use a soft brush or cloth to remove dust. Reattach the grille securely before use.
- Do not use abrasive cleaners, solvents, or immerse the fan in water.

### Storage

When not in use for extended periods, store the fan in a cool, dry place away from direct sunlight and extreme temperatures. Ensure the battery is partially charged (around 50%) before storage to prolong its lifespan.

## TROUBLESHOOTING

---

Problem	Possible Cause	Solution
Fan does not turn on.	Battery is depleted.	Charge the fan using the provided USB cable.
Fan speed is weak.	Battery is low.	Charge the fan.
LED light does not turn on.	Battery is depleted.	Charge the fan.
Fan makes unusual noise.	Obstruction in fan blades.	Turn off and unplug the fan. Carefully check for and remove any obstructions.
Charging is slow or not working.	Faulty cable or power source.	Try a different USB cable or a different 5V/2A power adapter.

## SPECIFICATIONS

---

Feature	Detail
Model Number	F320
Brand	AMACOOOL
Battery Capacity	10000mAh Polymer Battery
Fan Size	7 inches
Wind Speeds	3 Levels
LED Lights	12 LEDs, 3 Brightness Settings
Input Voltage	5V
Wattage	5 watts

Feature	Detail
Noise Level	30 Decibels
Product Dimensions	2.36"D x 6.29"W x 8.49"H
Item Weight	16 ounces
Material	Plastic
Connector Type	Micro USB

## SAFETY INFORMATION

---

- Do not insert fingers or any objects into the fan grille when the fan is operating.
- Keep the fan away from water and moisture. Do not use in wet environments.
- Do not attempt to disassemble or repair the fan yourself. Contact customer support for assistance.
- Keep out of reach of children and pets.
- Use only the specified charging voltage (5V/2A). Using incompatible chargers may damage the device or pose a safety risk.
- Avoid exposing the fan to extreme temperatures or direct sunlight for prolonged periods.

## WARRANTY AND SUPPORT

---

AMACOOOL offers a **365-day free replacement** for this product from the date of purchase, covering manufacturing defects. For any product inquiries, technical support, or warranty claims, please contact AMACOOOL customer service. Please have your model number (F320) and proof of purchase ready when contacting support.

For faster assistance, please visit the AMACOOOL official store or contact us through the platform where you purchased the product.