

[Manuals.plus](#) /

› [Kid Trax](#) /

› Kid Trax Real Rigs Toddler Recycling Truck Instruction Manual

Kid Trax KT1535TG

Kid Trax Real Rigs Toddler Recycling Truck Instruction Manual

Model: KT1535TG

INTRODUCTION

The Kid Trax Real Rigs Recycling Truck is an interactive ride-on toy designed for toddlers aged 1.5 to 4 years. This manual provides essential information for setup, operation, maintenance, and troubleshooting to ensure safe and enjoyable use of the product.

This tot-sized recycling truck features over 100 voice lines, sound effects, songs, and expressions that respond to your child's interactions. It includes nine recyclable accessories for collecting and sorting, a working lever to dump recycling, and a simple push-button drive system.

WHAT'S IN THE BOX

- Kid Trax Real Rigs Recycling Truck Ride On
- Charger
- 6-Volt Battery
- 9 Recycling Accessory Toys

SETUP

Initial assembly is required. Please follow the instructions carefully.

Battery Charging

Before first use, fully charge the 6-volt battery for the recommended duration (refer to the separate charging instructions if provided with the product). The charger plugs directly into the truck, eliminating the need for battery removal for charging.



Image: The Kid Trax Recycling Truck highlighting the 6V battery and charger, indicating easy plug-in charging.

Assembly

Assembly typically involves attaching the steering wheel, wheels, and the dump handle. A screwdriver may be required. Ensure all connections are secure before use.

OPERATING INSTRUCTIONS

The Real Rigs Recycling Truck offers an engaging and interactive play experience.

Powering On and Driving

Locate the ON/OFF switch, usually near the steering wheel, and turn it to the 'ON' position. The truck's eyes will move, and it will begin to talk and play sounds.

Your browser does not support the video tag.

Video: Official product video demonstrating the interactive features and driving of the Kid Trax Real Rigs Recycling Truck. To drive, press the push-button drive located on the steering wheel. The truck has one forward speed of 1.5 MPH,

providing a safe and manageable pace for young children.



Image: Close-up of the truck's front, showing its moving eyes and mouth, emphasizing its interactive personality with over 100 phrases, sounds, and songs.

Interactive Recycling Features

The truck comes with 9 recyclable accessories. Children can insert these accessories into the shape-sorting slots on the back of the truck. The truck will respond with voice lines and sound effects as items are inserted.



Working lever to dump recycling haul

Image: A child actively sorting the included recycling items into the designated slots on the back of the truck. To empty the collected recycling, use the working lever to dump out the contents from the back of the truck.



Image: A child pulling the lever on the side of the truck to activate the dumping mechanism for the collected recycling.

MAINTENANCE

To ensure the longevity and proper functioning of your Kid Trax Recycling Truck, follow these maintenance guidelines:

- Keep the truck clean by wiping it with a damp cloth. Avoid using harsh chemicals.
- Store the truck in a dry, covered area to protect it from weather elements, as moisture can damage the battery and electronics.
- Regularly check the battery and charger for any signs of damage.
- Ensure all screws and connections remain tight.

TROUBLESHOOTING

If you encounter issues with your Recycling Truck, try the following common solutions:

Problem	Solution
Truck does not move or is slow.	Ensure the battery is fully charged. Check that the ON/OFF switch is in the 'ON' position. Verify the push-button drive is being pressed correctly.
Sounds or lights are not working.	Check battery charge. Ensure the truck is powered on. Inspect for any loose wiring connections if accessible.
Recycling accessories are not recognized.	Ensure accessories are inserted fully and correctly into the designated shape-sorting slots.

If problems persist, please refer to the Warranty & Support section for further assistance.

SPECIFICATIONS

- **Product Dimensions:** 33.17 x 19.37 x 20.24 inches
- **Item Weight:** 28 pounds
- **Recommended Age:** 18 months - 4 years
- **Max Rider Weight:** 44 pounds (as per product images)
- **Speed:** 1 forward speed, 1.5 MPH
- **Battery:** 6-volt rechargeable battery
- **Features:** Over 100 voice lines, sound effects, songs, moving mouth and eyes, 9 recyclable accessories, working dump lever, Power Trax rubber traction strip tires.



Image: The Kid Trax Recycling Truck with overlays indicating it's for one rider, ages 1.5-4 years, and has a 44 lb max weight capacity.

SAFETY INFORMATION

Adult Supervision Suggested

Always ensure that children are supervised by an adult while operating the ride-on toy. Do not allow children to operate the toy near streets, swimming pools, or other hazardous areas. Ensure the toy is used on flat, stable surfaces.

WARRANTY & SUPPORT

For warranty information or technical support, please refer to the documentation included with your product or visit the official Kid Trax website. You may also contact Pacific Cycle, Inc., the manufacturer, for assistance. User Guide (PDF) and User Manual (PDF) are available for download:[Download User Manual](#)

© 2024 Kid Trax. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question