



Manuals.plus /

› TAYAMA /

› Tayama TO-2000R 12 Qt. Turbo Oven Instruction Manual

TAYAMA TO-2000R

Tayama TO-2000R 12 Qt. Turbo Oven Instruction Manual

Model: TO-2000R | Brand: TAYAMA

1. INTRODUCTION AND OVERVIEW

The Tayama TO-2000R Turbo Oven is a versatile 12-quart convection oven designed for efficient and healthy cooking. It utilizes circulating fan-forced heated air to cook food 3 to 5 times faster than traditional ovens, while preserving nutrients and keeping meats tender. This multi-purpose appliance can be used for baking, grilling, roasting, or steaming, and allows for cooking without added fats or oil, reducing cholesterol intake.

The oven features a durable tempered glass bowl, allowing you to monitor your food as it cooks. Its simple knob controls for time and temperature ensure easy operation. This manual provides detailed instructions for safe and effective use of your Tayama TO-2000R Turbo Oven.



Figure 1: Fully assembled Tayama TO-2000R 12 Qt. Turbo Oven.

2. PRODUCT COMPONENTS

Your Tayama TO-2000R Turbo Oven comes with the following components:

- **Convection Cooking Lid:** Contains the heating element, fan, and control panel.
- **Glass Bowl:** 12-quart capacity, made of tempered glass.
- **Oven Stand:** Provides a stable base for the glass bowl.
- **Low Rack:** For cooking items closer to the heating element.
- **High Rack:** For cooking items further from the heating element.
- **Tongs:** For safely handling hot food and racks.
- **Power Cord:** Detachable power supply cord.
- **Instruction Manual:** This document.
- **Warranty Card:** Information regarding your product warranty.



Figure 2: Disassembled components of the Tayama TO-2000R Turbo Oven.

3. SETUP AND ASSEMBLY

Before first use, wash all removable parts (glass bowl, racks, tongs) with warm, soapy water. Wipe the convection cooking lid with a damp cloth. Ensure all parts are completely dry before assembly.

1. Place the oven stand on a stable, heat-resistant surface.
2. Carefully place the tempered glass bowl into the oven stand.
3. Insert either the low or high rack into the glass bowl, depending on your cooking needs.
4. Place the convection cooking lid securely on top of the glass bowl. Ensure the handle is in the down/locked position to enable power.
5. Connect the power cord to the back of the convection cooking lid and then plug it into a grounded electrical outlet.



Figure 3: Tayama TO-2000R Turbo Oven with lid handle up, revealing the interior and rack.

4. OPERATING INSTRUCTIONS

The Tayama TO-2000R features simple knob controls for setting time and temperature.

4.1 Setting Time and Temperature

1. Ensure the oven is properly assembled and plugged in.
2. Place your food on the appropriate rack inside the glass bowl.
3. Lower the convection cooking lid handle to the down/locked position. The power indicator light will illuminate.
4. Turn the **TEMPERATURE** knob to your desired cooking temperature (range: 125°C to 250°C / 257°F to

482°F).

5. Turn the **TIMER** knob to your desired cooking time (up to 60 minutes). The heat indicator light will illuminate, and the oven will begin cooking.
6. The oven will automatically shut off and a bell will ring when the set time has elapsed.

4.2 Handle Safety Feature

The oven is equipped with a safety switch in the handle. If the handle is lifted during operation, the heating element and fan will automatically turn off. Lowering the handle will resume cooking if time remains on the timer.



Figure 4: Control panel with Timer and Temperature knobs.

5. COOKING TIPS

- **Preheating:** While not always necessary due to rapid heating, preheating for 5-10 minutes can be beneficial for certain recipes, especially baked goods.
- **Rack Placement:** Use the high rack for thinner items or when you want food closer to the heating element for faster browning. Use the low rack for thicker items or when you need more space between the food and the heating element.
- **Even Cooking:** For very large items or when cooking multiple items, it may be beneficial to flip or rotate food halfway through the cooking process to ensure even browning.
- **Cooking from Frozen:** The turbo oven can cook many foods directly from frozen, often requiring only a slight increase in cooking time compared to thawed items.
- **Healthy Cooking:** The convection technology allows fat to drip away from food, collecting in the bottom of the glass bowl, promoting healthier meals.

6. MAINTENANCE AND CLEANING

Proper maintenance and cleaning will extend the life of your Tayama TO-2000R Turbo Oven.

- **Convection Cooking Lid: DO NOT IMMERSE IN WATER OR ANY LIQUID.** Wipe the exterior and interior of the lid with a damp cloth after each use. For stubborn grease, use a mild detergent on the cloth. Ensure the lid is completely dry before storage.
- **Glass Bowl:** The tempered glass bowl can be washed by hand with warm, soapy water. It is also dishwasher safe.

- **Racks and Tongs:** The low rack, high rack, and tongs are dishwasher safe or can be washed by hand with warm, soapy water.
- **Oven Stand:** Wipe the plastic oven stand with a damp cloth.
- **Storage:** Ensure all parts are clean and dry before storing. The oven can be disassembled for more compact storage.

7. TROUBLESHOOTING

If you encounter issues with your Tayama TO-2000R Turbo Oven, please refer to the following common solutions:

- **Oven does not turn on:**
 - Ensure the power cord is securely plugged into both the oven and a working electrical outlet.
 - Check that the convection cooking lid handle is fully lowered into the ON position. The safety switch prevents operation if the handle is up.
 - Verify that both the Temperature and Timer knobs are set to desired values and not in the 'OFF' position.
- **Food is not cooking evenly:**
 - Ensure food is placed centrally on the rack.
 - Avoid overcrowding the oven. Cook in smaller batches if necessary.
 - Consider flipping or rotating food halfway through the cooking cycle.
 - Check that the selected temperature and time are appropriate for the food type and quantity.
- **Smoke or unusual odor:**
 - A small amount of smoke or odor may occur during initial use; this is normal.
 - If excessive smoke occurs, immediately unplug the oven. This may indicate food residue or grease buildup on the heating element. Clean the lid thoroughly once cooled.

For further assistance, please contact customer support.

8. SPECIFICATIONS

Feature	Detail
Brand	TAYAMA
Model Name	TO-2000R
Capacity	12 Quarts
Color	White
Product Dimensions	13"D x 15"W x 14"H
Item Weight	12.67 pounds
Material	Tempered Glass
Control Type	Knob Control
Special Feature	Programmable
Power Source	AC Adapter
Number of Shelves	2
Care Instructions	Hand Wash (Glass bowl is dishwasher safe)

9. WARRANTY AND SUPPORT

Your Tayama TO-2000R Turbo Oven is covered by a **1 Year Limited Warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal household use.

For warranty claims, technical support, or any questions regarding your product, please refer to the contact information provided on your warranty card or visit the official TAYAMA website.

Please retain your proof of purchase for warranty validation.