

TACTACAM 5.0

TACTACAM 5.0 Hunting Action Camera User Manual

Model: 5.0 (C-FB-5)



1. INTRODUCTION

This manual provides comprehensive instructions for the TACTACAM 5.0 Hunting Action Camera. Designed for outdoor enthusiasts, this camera captures high-quality video and images of hunting activities. Please read this manual thoroughly before using your device to ensure proper operation and longevity.



Image 1.1: TACTACAM 5.0 Hunting Action Camera. This image displays the cylindrical black camera with green power and mode buttons on top, and the lens visible at one end.

2. PACKAGE CONTENTS

Verify that all items listed below are included in your package:

- TACTACAM 5.0 Hunting Action Camera
- Carrying Case
- Battery
- USB Cable



Image 2.1: TACTACAM 5.0 Camera and Accessories. This image shows the camera along with its battery, USB cable, cleaning cloth, and carrying pouch.

3. SETUP

3.1. Battery Charging and Installation

1. Insert the provided battery into the camera's battery compartment.
2. Connect the camera to a power source using the supplied USB cable to fully charge the battery before first use. The charging indicator light will show the charging status.

3.2. Micro SD Card Installation

A Micro SD card (not included) is required for recording. For optimal performance, use a high-speed Micro SD card (U3 rating recommended).

1. Locate the Micro SD card slot on the camera.
2. Insert the Micro SD card with the contacts facing down until it clicks into place.

3.3. Mounting the Camera

The TACTACAM 5.0 is designed to attach to various equipment. Ensure the camera is securely mounted to prevent movement during recording.



Image 3.1: TACTACAM 5.0 Mounted on a Rifle. The camera is shown attached to the barrel of a rifle, positioned next to a scope.

4. OPERATING INSTRUCTIONS

4.1. Power On/Off

- To power on, press and hold the Power/Record button until the indicator lights illuminate.
- To power off, press and hold the Power/Record button until the indicator lights turn off.

4.2. Recording Video and Capturing Images

The camera supports Ultra HD 4K video resolution for clear and detailed recordings.

- Press the Power/Record button once to start recording video. Press again to stop.
- Refer to the camera's on-screen menu or app for specific settings related to video resolution (e.g., 4K) and image capture modes.




Image 4.1: 4K Resolution Comparison. This image compares a 720p resolution image of a turkey's head with a 4K resolution image, highlighting the increased detail in 4K.

4.3. Zoom Functionality

The TACTACAM 5.0 features an 8x zoom capability, allowing for closer views of distant subjects.

8x zoom



Image 4.2: 8x Zoom Comparison. This image shows a side-by-side comparison of a deer in a field, demonstrating the effect of 8x zoom versus a standard view.

4.4. Image Stabilization

Integrated image stabilization technology helps reduce blur and shake, resulting in clearer footage, especially during dynamic activities.

Image Stabilization Technology



Takes the “shock” out of the shot

Image 4.3: Image Stabilization Technology in use. A hunter is shown holding a crossbow with the TACTACAM 5.0 mounted, illustrating the camera's use in action.

4.5. Connectivity and App Usage

The TACTACAM app allows for remote control, live viewing, and sharing of your recordings. Connect your camera to your smartphone via Wi-Fi.

Download the Tactacam App



Share your hunt

Image 4.4: TACTACAM App on Smartphone. A smartphone screen displays the TACTACAM app interface, showing a live view from the camera.

4.6. Weatherproof Design

The camera is designed to withstand various weather conditions, making it suitable for outdoor use.

Weatherproof



Image 4.5: Weatherproof TACTACAM 5.0. The camera is shown with water droplets on its surface, demonstrating its resistance to moisture.

5. MAINTENANCE

5.1. Cleaning

- Use a soft, dry cloth to clean the camera body.
- For the lens, use a specialized lens cleaning cloth and solution to avoid scratches.
- Do not use harsh chemicals or abrasive materials.

5.2. Storage

- Store the camera in a cool, dry place away from direct sunlight and extreme temperatures.
- Remove the battery if storing for extended periods to prevent leakage.

6. TROUBLESHOOTING

- **Camera Not Powering On:** Ensure the battery is fully charged and correctly installed.
- **Recording Issues:** Verify that a compatible Micro SD card (U3 recommended) is inserted and has sufficient free space. Format the SD card if necessary (this will erase all data).
- **Poor Battery Life:** Ensure the battery is fully charged before each use. Minimize Wi-Fi usage and review camera settings that might consume more power.
- **Connectivity Problems:** Ensure Wi-Fi is enabled on the camera and your smartphone. Try restarting both devices.

If you encounter persistent issues not covered here, please contact TACTACAM customer support.







7. SPECIFICATIONS

Feature	Detail
Brand	TACTACAM
Model Number	C-FB-5
Item Weight	13 ounces
Package Dimensions	9.88 x 5.47 x 2.76 inches
Color	Black
Special Features	Waterproof
Photo Sensor Technology	CMOS
Video Capture Resolution	4K
Maximum Focal Length	30
Maximum Aperture	5 f
Flash Memory Type	Micro SD
Video Capture Format	MP4
Supported Audio Format	MP3, AAC
Screen Size	2 Inches
Connectivity Technology	USB

8. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the official TACTACAM website or contact their customer service directly. You can also visit the [TACTACAM Store on Amazon](#) for additional resources.



	<p>Tactacam 6.0 Instruction Manual - User Guide</p> <p>Comprehensive instruction manual for the Tactacam 6.0 camera, covering setup, features, recording, app connectivity, troubleshooting, and warranty information.</p>
	<p>Tactacam Reveal Pro 3.0 Cellular Camera Instruction Manual</p> <p>Comprehensive instruction manual for the Tactacam Reveal Pro 3.0 cellular trail camera, covering setup, best practices, troubleshooting, and warranty information.</p>
	<p>Tactacam Reveal Cellular Camera Instruction Manual</p> <p>User manual for the Tactacam Reveal Cellular Camera, detailing setup, app integration, camera settings, specifications, and troubleshooting for optimal performance in wildlife monitoring.</p>
	<p>Tactacam Reveal Pro 3.0 Cellular Camera Instruction Manual</p> <p>Comprehensive instruction manual for the Tactacam Reveal Pro 3.0 cellular camera, covering setup, best practices, troubleshooting, and warranty information.</p>
	<p>Tactacam Reveal X-Pro Cellular Camera Instruction Manual</p> <p>This document provides comprehensive instructions for setting up, operating, and troubleshooting the Tactacam Reveal X-Pro cellular trail camera. It covers app download, camera features, best practices for placement and battery usage, common issues, and warranty information.</p>
	<p>Tactacam Reveal SK Cellular Camera Instruction Manual</p> <p>Comprehensive instruction manual for the Tactacam Reveal SK cellular trail camera, covering setup, operation, best practices, specifications, product care, and warranty information.</p>