Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

TAKARA TOMY MP-51

TAKARA TOMY Transformers Masterpiece MP-51 Arcee Action Figure Instruction Manual

1. Introduction

This manual provides instructions for the assembly, transformation, and care of your TAKARA TOMY Transformers Masterpiece MP-51 Arcee action figure. Please read all instructions carefully before handling the product to ensure proper use and to avoid damage.

Safety Information

WARNING: CHOKING HAZARD - Small Parts. This product contains small parts and may have sharp points. It is not suitable for children under 3 years of age. Recommended for ages 15 and up. Adult supervision is advised during initial handling and transformation.

Keep all packaging materials away from children. Dispose of packaging responsibly.

2. Package Contents

Verify that all components listed below are present in your package:

- 1 x Arcee Figure
- 3 x Alternate Face Plates (e.g., neutral, surprised, sad expressions)
- 3 x Blast Effects
- 1 x Holster
- 1 x Crusher Weapon
- 3 x Blaster Accessories
- 1 x Character Card
- 1 x Original Japanese-language Instructions (for reference)



Image: Arcee figure in robot mode, showcasing its design and articulation.

3. Setup and Transformation

The MP-51 Arcee figure is designed to transform between robot mode and vehicle mode. Handle all joints and panels with care during transformation to prevent damage.

3.1. Robot Mode to Vehicle Mode

1. Carefully detach any accessories from the figure.
2. Begin folding and collapsing the limbs and body panels as indicated in the detailed transformation steps (refer to the included Japanese instructions for visual guidance).
3. Ensure all panels align and tab securely into place to form the futuristic car vehicle mode.



Image: Arcee figure fully transformed into its sleek vehicle mode.

3.2. Vehicle Mode to Robot Mode

1. Carefully un-tab and unfold the vehicle panels.
2. Extend the limbs and articulate the joints to form the robot mode.
3. Ensure all parts are correctly positioned and locked into place for stability.



Image: Rear view of Arcee in robot mode, highlighting the streamlined backpack.

4. Operating the Figure

The MP-51 Arcee figure features multiple points of articulation and interchangeable parts for dynamic posing and display.

4.1. Posing and Articulation

- Gently manipulate the joints (shoulders, elbows, hips, knees, ankles) to achieve desired poses. Avoid excessive force to prevent breakage.
- The figure's design allows for a wide range of motion, replicating iconic poses from the animation.



Image: Arcee in a dynamic action pose, demonstrating articulation and weapon use.

4.2. Attaching Accessories

- **Alternate Faces:** To change Arcee's expression, carefully remove the current face plate and snap a new one into place.
- **Weapons:** The blaster accessories and crusher weapon can be held in Arcee's hands. The holster can be attached to the figure for weapon storage.
- **Blast Effects:** These effects can be attached to the barrels of the blasters to simulate firing.



Image: Two Arcee figures showcasing various poses and the use of blast effects with blasters.



Image: Arcee figure displaying one of its interchangeable face plates, showing a surprised expression.



Image: Arcee figures demonstrating another interchangeable face plate with a sad expression, alongside a standard pose.

5. Care and Maintenance

Proper care will ensure the longevity of your MP-51 Arcee figure.

- **Cleaning:** Use a soft, dry cloth to gently wipe away dust. For stubborn dirt, a slightly damp cloth with mild soap can be used, followed by immediate drying. Avoid harsh chemicals or abrasive materials.
- **Storage:** Store the figure away from direct sunlight, extreme temperatures, and high humidity to prevent discoloration or material degradation. Keep it in a stable environment where it won't fall or be crushed.
- **Handling:** Always handle the figure by its main body parts. Avoid gripping small, delicate components or forcing joints beyond their intended range of motion.

6. Troubleshooting

If you encounter any issues with your MP-51 Arcee figure, consider the following:

- **Stiff Joints:** If a joint feels too stiff, gently work it back and forth a few times. Do not apply excessive force. In

some cases, a small amount of silicone shock oil (specifically designed for plastic models) can be applied to the joint, but use sparingly and test in an inconspicuous area first.

- **Loose Joints:** If a joint is too loose, it may be possible to tighten it by applying a very thin layer of clear nail polish or a specialized joint-tightening fluid to the ball joint or peg, allowing it to dry completely before reassembling.
- **Parts Not Fitting:** During transformation, ensure all tabs and slots are correctly aligned. Refer to the transformation diagrams in the original instructions if you are having difficulty. Do not force parts together.
- **Missing or Damaged Parts:** If you believe a part is missing or damaged upon opening the package, contact the retailer or manufacturer's customer support.

7. Specifications

Feature	Detail
Model Name	Arcee MP-51
Brand	TAKARA TOMY
Series	Transformers Masterpiece
Figure Type	Action Figure
Material	Plastic
Dimensions (L x W x H)	5.91" x 1.97" x 3.15" (approximate)
Number of Pieces	1 (figure)
Operation Mode	Manual Transformation
Recommended Age	Ages 15 and up

8. Warranty and Support

For information regarding product warranty, returns, or technical support, please refer to the purchase documentation or contact the retailer from whom the product was acquired. Manufacturer contact details may also be available on the product packaging or official brand website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B088CBY6R9

More documents and user manuals: **https://manuals.plus/**